Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HANGSUN HOC760

HANGSUN HOC760 Water Flosser User Manual

Cordless Rechargeable Dental Oral Irrigator

1. Introduction

This user manual provides essential information for the safe and effective operation of your HANGSUN HOC760 Water Flosser. Please read it thoroughly before first use and retain it for future reference.
The HANGSUN HOC760 is a cordless, rechargeable dental oral irrigator designed to enhance your oral hygiene routine by effectively removing food particles and plaque from hard-to-reach areas, promoting gum health, and preventing bad breath and cavities.

2. Safety Information

May contain electrical safety warnings and precautions for use with certain medical conditions. Always follow the directions for use and care.
Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.

3. Product Components

The HANGSUN HOC760 Water Flosser package includes the main unit, multiple jet tips, and a USB charging cable.



Image: HANGSUN HOC760 Water Flosser main unit, showing its sleek black design, control panel, detachable water tank, and the assortment of 8 different jet tips included in the package. The product box is also visible.

Main Unit Features:

- On/Off Button: To power the device on or off.

- Mode Button: To cycle through different flossing modes.
- Mode Indicators: Lights indicating Normal, Soft, or Pulse mode.
- Charge Indicator: Light indicating charging status.
- 300ML Detachable Water Tank: Large capacity for continuous flossing.
- IPX7 Waterproof Design: Allows for safe use in the shower.
- USB Charging Port: For convenient recharging.

Jet Tips:

The water flosser is equipped with 8 nozzles designed for various oral care needs and family use.



Image: A close-up view of the 8 multifunctional jet tips included with the HANGSUN HOC760 Water Flosser. These include 5 standard jet tips (with different colored rings for family members), 1 orthodontic tip, 1 periodontal tip, and 1 tongue cleaner tip.

- 5x Standard Jet Tips: For daily teeth cleaning. Differentiated by color for individual family members.
- 1x Orthodontic Tip: Designed for cleaning around braces, bridges, and other dental work.
- 1x Periodontal Tip: For gentle cleaning and massaging gums, reaching deep below the gumline.

- 1x Tongue Cleaner Tip: For effectively cleaning the tongue coating and bacteria.

4. Setup

1. **Charge the Device:** Before first use, ensure the device is fully charged. Connect the included USB charging cable to the charging port (ensure the port cover is open) and plug the other end into a 5V1A adapter, power bank, or laptop USB port. A full charge takes approximately 3 hours and provides up to 21 days of use.
2. **Attach a Jet Tip:** Select the desired jet tip and firmly push it into the opening at the top of the main unit until it clicks into place.
3. **Fill the Water Tank:** Open the detachable water tank. Fill the 300ML tank with lukewarm water. For optimal results, you may also use mouthwash. Ensure the charge port is tightly covered before use, especially if using in the shower.



Image: A visual guide demonstrating the setup and usage steps: 1. Add water to the tank. 2. Install the jet tip. 3. Choose the suitable pressure mode. 4. Put the tip into your mouth and direct it at a 90-degree angle to your gumline. 5. Turn it on to clean the teeth.

5. Operating Instructions

1. **Select a Flossing Mode:** Press the "Mode" button to cycle through the available modes:
    - **NORMAL:** For powerful removal of food particles, suitable for experienced users.
    - **SOFT:** For gentle cleaning of sensitive teeth, recommended for first-time users.
    - **PULSE:** For massaging gums and rinsing.

    When using the electric flosser for the first time, it is recommended to start with the "SOFT" mode.
2. **Position the Tip:** Lean over a sink. Place the jet tip into your mouth, directing it at a 90-degree angle to your gumline.
3. **Begin Flossing:** Press the "On/Off" button to start the water flow. Move the tip along your gumline, pausing briefly between teeth to allow the water jet to clean thoroughly.
4. **Continue Cleaning:** Continue until you have cleaned all areas of your mouth. The device may have an automatic

shut-off feature after a set time (e.g., 2 minutes).

5. **Empty and Clean:** After each use, empty any remaining water from the tank and rinse it thoroughly.

Benefits of Regular Use:

- Effectively removes teeth stains.
- Aids in the care of periodontal disease.
- Assists with cleaning braces and dental implants.
- Prevents bad breath.
- Promotes gum health and prevents bleeding gums.



Image: A close-up of the HANGSUN Water Flosser's control panel, highlighting the On/Off button, Mode button, and indicator lights for Normal, Soft, and Pulse modes, allowing users to personalize their flossing experience.

Official Product Video:

▶ **Watch video online**

Get Healthy Teeth Care with Hangsun HOC760 Water Flosser

Video: "Get Healthy Teeth Care with Hangsun HOC760 Water Flosser" - This official seller video demonstrates the key features and benefits of the HANGSUN HOC760 Water Flosser, including its design, multiple tips, and ease of use for comprehensive oral hygiene.

6. Maintenance

- **Daily Cleaning:** After each use, empty any remaining water from the tank. Rinse the water tank and the main unit under running water.
- **Tip Replacement:** It is recommended to replace the jet nozzle every 3 months for optimal performance and hygiene.
- **Deep Cleaning:** Periodically, you may wish to deep clean the water tank and internal components. Refer to the full user manual for detailed instructions on deep cleaning.
- **Storage:** Store the device in a cool, dry place away from direct sunlight when not in use.



Image: The HANGSUN HOC760 Water Flosser shown with its 300ML detachable water tank separated from the main unit, illustrating the ease of filling and cleaning the reservoir.

7. Troubleshooting

If you encounter any issues with your HANGSUN HOC760 Water Flosser, please refer to the following common troubleshooting tips:

Problem	Possible Cause	Solution
No water flow	Water tank is empty; Tip is clogged; Device not powered on.	Refill water tank; Clean or replace tip; Press On/Off button.

Problem	Possible Cause	Solution
Weak water pressure	Low battery; Tip is partially clogged; Incorrect mode selected.	Recharge device; Clean tip; Switch to Normal mode.
Device not charging	Charging cable not properly connected; Faulty adapter/USB port.	Ensure secure connection; Try a different adapter/USB port.

For persistent issues, please contact customer support as detailed in the Warranty and Support section.

8. Specifications

- **Model Number:** HOC760
- **Brand:** HANGSUN
- **Power Source:** Battery Powered (10 Lithium Ion batteries included)
- **Water Tank Capacity:** 300ML
- **Special Features:** Portable, Rotatable Tip, Rechargeable, IPX7 Waterproof
- **Product Dimensions:** 10.39 x 5.08 x 2.72 inches
- **Item Weight:** 1.12 Pounds
- **First Available Date:** December 12, 2022
- **Manufacturer:** Hangsun

9. Warranty and Support

The HANGSUN dental flosser comes with **24 months after-sale service**.
For any questions or support, please do not hesitate to contact customer service through your Amazon account:

1. Go to "Account service"
2. Navigate to "Order history"
3. Select this product
4. Click "Ask product question"

This ensures you receive direct assistance from the manufacturer or authorized support.

© 2025 HANGSUN. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BLVM69CW

More documents and user manuals: **https://manuals.plus/**