Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Tribesigns HOGA-F1650

Tribesigns Shoe Cabinet with Doors

Model: HOGA-F1650

Instruction Manual

1. Introduction

Thank you for choosing the Tribesigns Shoe Cabinet with Doors. This modern and functional storage solution is designed to help organize your footwear and enhance the aesthetic of your living space. Crafted from durable manufactured wood and metal, this cabinet features a sleek design with geometric motif doors and ample storage capacity. Please read this manual carefully before assembly and use to ensure proper installation and longevity of your product.



Figure 1: Tribesigns Shoe Cabinet with Doors (White/Gold)

This image displays the Tribesigns Shoe Cabinet with Doors in a white finish with gold accents, featuring two doors with a geometric pattern, standing on gold metal legs. It is shown in an entryway setting with a vase of flowers and decorative items on top.

2. Safety Information

Please observe the following safety precautions to prevent injury or damage to the product:

- Always assemble the product on a soft, clean surface to prevent scratches.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as needed.
- Do not overload the shelves. Refer to the specifications for weight limits.
- For stability, it is recommended to anchor the cabinet to a wall, especially if children are present. Anti-tip hardware may be included or can be purchased separately.
- Keep small parts and packaging materials away from children and pets during assembly.

3. Package Contents

Before beginning assembly, verify that all parts and hardware are present. If any items are missing or damaged, please contact customer service.

3.1. Components

- Cabinet Panels (Top, Bottom, Sides, Back)
- Adjustable Shelves (5 total)
- Doors (2 total)
- Metal Legs (4 total)
- Door Handles (2 total)

3.2. Hardware

- Screws of various sizes
- Dowel Pins
- Cam Locks and Cam Dowels
- Hinges
- Adjustable Feet
- Allen Wrench (Hex Key)
- Small Screwdriver

Note: An electric drill is recommended for faster and easier assembly, though not strictly required. Two people are preferred for assembly.

4. Setup and Assembly Instructions

Follow these steps carefully for proper assembly. Refer to the included diagram for visual guidance.

1. **Prepare the Area:** Clear a spacious, clean, and soft area for assembly to prevent damage to the cabinet parts.
2. **Attach Metal Legs:** Secure the four metal legs to the bottom panel of the cabinet using the provided screws. Ensure they are firmly attached. The adjustable feet on the legs can be rotated to level the cabinet on uneven floors.
3. **Assemble Side Panels:** Connect the side panels to the bottom panel using dowel pins and cam locks. Follow the pre-drilled holes.
4. **Install Fixed Shelves:** Insert the fixed shelves into their designated slots, securing them with cam locks.
5. **Attach Top Panel:** Place the top panel onto the assembled structure, aligning it with the cam dowels and securing with cam locks.
6. **Install Back Panel:** Carefully align and attach the back panel to the rear of the cabinet using small nails or screws.
7. **Attach Hinges to Doors:** Secure the hinges to the cabinet doors.
8. **Mount Doors:** Attach the doors to the cabinet frame by connecting the hinges to the pre-drilled holes on the side panels. Adjust hinges as necessary to ensure doors are aligned and close properly.
9. **Install Handles:** Attach the gold door handles to the front of the doors.
10. **Insert Adjustable Shelves:** Place the remaining shelves into the desired positions using the adjustable shelf pins. These shelves are removable to accommodate different shoe heights, including boots.




Figure 2: Cabinet Dimensions and Internal Layout

This image provides detailed dimensions of the Tribesigns Shoe Cabinet, including its overall height (37.4 inches), width (31.49 inches), and depth (14.96 inches). It also shows the internal shelf spacing, indicating adjustable shelf heights for various shoe types.



Figure 3: Adjustable Shelf Configuration

This image illustrates the removable partition boards within the shoe cabinet, demonstrating how shelves can be removed to create taller compartments for items like boots or shoe boxes, offering flexible storage options.

5. Operating Instructions (Usage)

The Tribesigns Shoe Cabinet is designed for efficient and discreet shoe storage. Its five-tier internal structure can accommodate approximately 15-20 pairs of shoes, depending on their size and style.

- **Shoe Storage:** Open the two front doors to access the internal shelves. Arrange your shoes neatly on the shelves. Utilize the adjustable shelves to customize compartment heights for different types of footwear, such as sneakers, flats, or boots.
- **Top Surface:** The sturdy top surface can be used for decorative items, keys, mail, or other entryway essentials.
- **Bottom Space:** The space beneath the cabinet, elevated by the metal legs, can be used for additional pairs of shoes or slippers for easy access.



Figure 4: Cabinet in a Bedroom Setting

This image shows the Tribesigns Shoe Cabinet placed in a bedroom, demonstrating its versatility beyond just an entryway. It is styled with decorative items on top and shoes stored underneath, highlighting its functional and aesthetic appeal.

6. Care and Maintenance

To maintain the appearance and longevity of your shoe cabinet, follow these care instructions:

- **Cleaning:** Wipe the surfaces with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as they may damage the finish.
- **Spills:** Immediately wipe up any spills to prevent moisture damage to the manufactured wood.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration.
- **Stability Check:** Periodically check all screws and connections to ensure they remain tight. Re-tighten if necessary to maintain stability.
- **Leveling:** Adjust the feet at the base of the metal legs if the cabinet becomes wobbly on uneven surfaces.



Figure 5: Door Surface Detail

This image provides a close-up view of the cabinet doors, highlighting the stylish geometric pattern that adds an elegant touch to the furniture piece.

7. Troubleshooting

If you encounter any issues with your Tribesigns Shoe Cabinet, refer to the following common problems and solutions:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Cabinet is wobbly.	Uneven floor; loose connections.	Adjust the leveling feet on the metal legs. Ensure all screws are tightened.
Doors are uneven or do not close properly.	Hinges are not aligned or adjusted correctly.	Adjust the screws on the hinges to align the doors. Refer to the hinge adjustment instructions if available in the assembly guide.
Missing parts or hardware.	Packaging error.	Contact Tribesigns customer service with your purchase details.
Difficulty during assembly.	Complex steps; lack of proper tools.	Ensure you have an electric drill (recommended) and a second person to assist. Review the assembly steps carefully.

8. Specifications

Feature	Detail
Brand	Tribesigns
Model Number	HOGA-F1650
Color	White/Gold
Product Dimensions	14.96"D x 31.5"W x 37.4"H
Item Weight	75 Pounds
Weight Limit	110 Pounds
Material	Engineered Wood (Top, Back), Metal (Frame)
Number of Shelves	5 (Adjustable)
Mounting Type	Floor Mount (Freestanding)
Special Features	Adjustable Shelf, Double Doors
Assembly Required	Yes

9. Warranty and Support

Tribesigns provides a worry-free **1-year warranty** for this product, covering defective and missing parts. For any questions, concerns, or assistance with assembly or product issues, please contact Tribesigns customer service. Have your model number (HOGA-F1650) and purchase information ready when contacting support.
You can visit the official Tribesigns store for more information and support: Tribesigns Store on Amazon

© 2023 Tribesigns. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BLYZJN5V

More documents and user manuals: **https://manuals.plus/**