Manuals+
Q & A | Deep Search | Upload

TECURS SPT-WK007

TECURS Wireless Gaming Keyboard User Manual

Model: SPT-WK007

Introduction

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your TECURS Wireless Gaming Keyboard. Please read this manual thoroughly before using the product to ensure proper function and longevity.

Package Contents

Upon opening the package, verify that all items listed below are present and in good condition:

- TECURS Wireless Gaming Keyboard
- USB Receiver (2.4 GHz)
- USB Charging Cable (Micro USB)
- User Manual



Image: The TECURS Wireless Gaming Keyboard, its USB receiver, USB charging cable, and user manual laid out on a surface.

Setup

1. Connecting the Keyboard

1. Locate the USB receiver. It is typically stored in a compartment on the keyboard or included separately in the packaging.
2. Insert the USB receiver into an available USB port on your computer, laptop, or compatible gaming console (PS4, PS5).
3. Turn on the keyboard using the power switch, usually located on the top edge or underside of the keyboard. The keyboard should automatically connect to the receiver.

Image: The TECURS Wireless Gaming Keyboard shown with its compact USB receiver, illustrating the wireless connection method.

2. Initial Charging

The keyboard comes with a built-in rechargeable Lithium-ion battery. For optimal performance, it is recommended to fully charge the keyboard before first use.

- Connect the Micro USB charging cable to the keyboard's charging port and the other end to a USB power source (e.g., computer USB port, USB wall adapter).
- An indicator light will typically show the charging status. Refer to the keyboard's specific indicator behavior for details.



Image: An illustration demonstrating the battery life of the keyboard: up to 15 days with backlight off and 10 hours with backlight on, based on a 1000mAh battery.

3. Wireless Range

The keyboard operates wirelessly with a receiving distance of 8-10 meters, providing flexibility in your workspace or gaming setup.

Image: A visual representation of the wireless keyboard's effective receiving distance, typically 8-10 meters, highlighting freedom from cables.

Operating Instructions

1. Basic Typing

The keyboard features a QWERTZ layout (German layout) with standard key functions. Simply begin typing after successful connection.

2. Backlight Control

The keyboard includes an RGB backlight feature. Use the dedicated backlight control keys (often located near the function keys or as a combination with the Fn key) to:

- Turn the backlight on/off.
- Adjust brightness levels.
- Cycle through different color modes or effects.

Refer to the keyboard's specific key legends for exact backlight control combinations.

3. Multimedia Keys

Dedicated multimedia keys are provided for quick access to functions such as volume control, play/pause, and track skipping. These keys are typically located above the function key row.

4. System Compatibility

The keyboard is compatible with various operating systems and devices:

- **Operating Systems:** Windows, Mac, Linux
- **Compatible Devices:** PC, Laptops, PS4, PS5, Game Consoles



Image: An infographic detailing the keyboard's dimensions (437mm length, 149mm width, 20mm thickness), key life of 50 million clicks, compatibility with Mac/Windows, individual multimedia buttons, and an adjustable stand.

5. Quiet Operation

The keyboard features silent keys designed to minimize typing noise, making it suitable for quiet environments.

Image: A person typing on the backlit keyboard in a dimly lit room, with a sleeping child in the background, emphasizing the low noise operation.

Image: Children using the keyboard in a library setting, illustrating its suitability for environments where low noise is preferred.

Maintenance

1. Cleaning

To clean your keyboard:

- Turn off the keyboard and disconnect it from any power source.
- Use a soft, lint-free cloth lightly dampened with water or a mild cleaning solution.
- Wipe the keycaps and surface gently. Avoid excessive moisture.
- For dust and debris between keys, use compressed air.

Note: The keyboard is designed to be waterproof, offering protection against accidental spills. However, it is not designed for immersion in water.

2. Battery Care

To prolong battery life:

- Avoid fully discharging the battery frequently.

- Charge the keyboard regularly, especially if it will be stored for an extended period.
- Store the keyboard in a cool, dry place.

Troubleshooting

Problem	Possible Cause	Solution
Keyboard not responding	Low battery; USB receiver not connected; Keyboard not powered on; Driver issue.	Charge the keyboard; Ensure USB receiver is securely plugged in; Turn on the keyboard; Try a different USB port; Restart your device.
Backlight not working	Backlight turned off; Low battery.	Press the backlight control key(s) to turn it on or adjust brightness; Charge the keyboard.
Keys are sticky or unresponsive	Debris under keys; Liquid spill.	Clean the keyboard using compressed air or a damp cloth; If liquid spill, turn off immediately, clean, and allow to dry completely before use.
Short battery life	Frequent backlight use; Battery degradation over time.	Reduce backlight brightness or turn it off when not needed; Ensure full charge cycles; If battery life significantly degrades, consider contacting support.

Specifications

Feature	Detail
Brand	TECURS
Model Number	SPT-WK007
Connectivity Technology	2.4 GHz Wireless (USB Receiver)
Keyboard Layout	QWERTZ (German Layout)
Backlight	RGB, Adjustable
Special Features	Ergonomic, Rechargeable, Backlit, Integrated Stand, Waterproof
Compatible Operating Systems	Windows, Mac, Linux, PS4, PS5
Compatible Devices	PC, Laptop, Game Console
Battery Type	Lithium-ion (1 included)
Charging Port	Micro USB
Dimensions (L x W x H)	43.7 cm x 14.9 cm x 2 cm
Recommended Use	Business, Gaming

Warranty and Support

For warranty information and technical support, please refer to the documentation provided with your purchase or visit the official TECURS website. Keep your proof of purchase for warranty claims.

© 2025 TECURS. All rights reserved.

Related Documents - SPT-WK007

	TECURS WK007 Wireless Gaming Keyboard User Manual - Backlit, Silent, Multimedia Keys Comprehensive user manual for the TECURS WK007 wireless gaming keyboard. Learn about setup, features, functions, troubleshooting, and safety precautions for this backlit, silent, ultra-slim keyboard with multimedia keys for Mac and Windows.
	TECURS MK206 Multi-Device Mechanical Keyboard User Manual Comprehensive user manual for the TECURS MK206 Multi-Device Mechanical Keyboard, detailing product parameters, package contents, compatible systems, connection methods (2.4G wireless and Bluetooth), shortcut keys, functions, and important safety precautions. Learn how to set up and use your keyboard for optimal performance.
	GM003 Wired Gaming Mouse Macro Configuration Guide Step-by-step instructions for configuring macros on the GM003 Wired Gaming Mouse using its software, including recording keystrokes and assigning them to mouse buttons for enhanced gaming performance.
	TECURS MK205 Mechanical Gaming Keyboard User Manual - Features, Specs, and Safety Comprehensive user manual for the TECURS MK205 mechanical gaming keyboard. Learn about its features, specifications, key functions, macro definition, and important safety precautions. Includes LED modes, multimedia controls, and compatibility information.
	TECURS KB510 Mechanical Keyboard User Manual and Features Comprehensive guide to the TECURS KB510 wireless mechanical keyboard, covering specifications, package contents, compatible systems, product overview, function descriptions, backlight operations, connection modes (Wired, Bluetooth, 2.4G), troubleshooting, power management, and important safety precautions.
	TECURS GM001 Wireless Mouse User Manual & Specifications Comprehensive guide to the TECURS GM001 wireless mouse, covering specifications, setup, product overview, power saving, safety precautions, troubleshooting, and DPI settings.