Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Langsdom BS17

Langsdom Bone Conduction Headphones User Manual

Model: BS17

Introduction

Thank you for choosing Langsdom Bone Conduction Headphones. These open-ear wireless Bluetooth headphones are designed to provide a unique audio experience while maintaining situational awareness. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your device.

Product Overview



Figure 1: Langsdom Bone Conduction Headphones (Model BS17)

A pair of black Langsdom bone conduction headphones, featuring an open-ear design with a flexible neckband connecting the two earpieces. The earpieces are designed to rest near the ear, not cover it, allowing for situational awareness. The Langsdom logo is visible on one of the earpieces.

The Langsdom Bone Conduction Headphones utilize advanced bone conduction technology to deliver sound through your cheekbones, leaving your ears open to ambient sounds. This design is ideal for sports, outdoor activities, and situations where awareness of your surroundings is crucial. They feature Bluetooth v5.2 for stable connectivity, integrated controls, and are IPX7 waterproof.

Setup

1. Initial Charging

Before first use, fully charge the headphones. Connect the supplied USB Type-C charging cable to the charging port on the headphones and the other end to a compatible USB power source (e.g., computer USB port, wall adapter). A full charge takes approximately 1 hour.

2. Bluetooth Pairing

1. Ensure the headphones are powered off.

2. Press and hold the power button until the LED indicator flashes blue and red alternately, indicating pairing mode.
3. On your device (smartphone, tablet, computer), enable Bluetooth and search for available devices.
4. Select "Langsdom BS17" (or similar name) from the list of found devices.
5. Once connected, the LED indicator will flash blue slowly, and a voice prompt will confirm the connection.
6. The headphones will automatically reconnect to the last paired device when powered on, if within range.

Operating Instructions

Power On/Off

- **Power On:** Press and hold the power button for 3 seconds.
- **Power Off:** Press and hold the power button for 5 seconds.

Music Playback

- **Play/Pause:** Press the multi-function button once.
- **Next Track:** Press and hold the volume + button.
- **Previous Track:** Press and hold the volume - button.
- **Volume Up:** Short press the volume + button.
- **Volume Down:** Short press the volume - button.

Call Management

- **Answer/End Call:** Press the multi-function button once during an incoming call.
- **Reject Call:** Press and hold the multi-function button for 2 seconds during an incoming call.

Voice Assistant

- **Activate Voice Assistant (Alexa, Siri, etc.):** Double-press the multi-function button.

Charging

The headphones are equipped with an 8-hour battery life and support Type-C fast charging. When the battery is low, a voice prompt will indicate "Battery Low".

- Connect the Type-C cable to the charging port.
- The LED indicator will show red during charging and turn blue when fully charged.
- Charging time is approximately 1 hour for a full charge.

Water Resistance (IPX7)

These headphones are IPX7 waterproof, meaning they can withstand immersion in water up to 1 meter for 30 minutes. This makes them suitable for use during workouts, in light rain, or when exposed to sweat. However, they are not designed for swimming or prolonged submersion.

- Do not charge the headphones if the charging port is wet.
- Ensure the charging port cover (if present) is securely closed before exposure to water.

Maintenance

- Clean the headphones regularly with a soft, dry cloth.
- Avoid using abrasive cleaners or solvents.
- Store the headphones in a cool, dry place away from direct sunlight and extreme temperatures.
- Do not attempt to disassemble or modify the headphones, as this will void the warranty.

Troubleshooting

Problem	Possible Cause	Solution
Cannot power on	Low battery	Charge the headphones fully.
Cannot pair with device	Headphones not in pairing mode; Bluetooth off on device; device too far.	Ensure headphones are in pairing mode (flashing blue/red). Turn on Bluetooth on your device. Move device closer to headphones.
No sound	Volume too low; not connected; incorrect audio output selected.	Increase headphone and device volume. Re-pair headphones. Check device's audio output settings.
Poor sound quality	Interference; device too far; low battery.	Move away from sources of interference. Move device closer. Charge headphones.

Specifications

Brand	Langsdom
Model Number	BS17
Color	Black
Form Factor	Bone Conduction
Ear Placement	Open Ear
Connectivity Technology	Wireless (Bluetooth v5.2)
Wireless Communication Technology	Bluetooth
Control Type	Media Control, Voice
Frequency Range	20 Hz - 20,000 Hz
Battery Life	Up to 8 hours
Charging Time	Approx. 1 hour
Charging Port	USB Type-C
Water Resistance Rating	IPX7

Item Weight	3.2 ounces
Package Dimensions	10 x 5.5 x 2 inches

Warranty and Support

Langsdom products are manufactured with high-quality standards. For any issues or support inquiries, please refer to your purchase documentation or contact the retailer/manufacturer directly. Keep your proof of purchase for warranty claims.
For further assistance, please visit the official Langsdom store or contact customer service through the platform where you purchased the product.

© 2024 Langsdom. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BNPPXQP3

More documents and user manuals: **https://manuals.plus/**