Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun 8467cc

Braun Series 8 8467cc Electric Foil Shaver User Manual

Model: 8467cc

Introduction

Thank you for choosing the Braun Series 8 8467cc Electric Foil Shaver. This manual provides essential information for the safe and effective use, maintenance, and care of your new electric razor. Please read these instructions thoroughly before using the appliance and keep them for future reference.

Important Safety Information

Avoid exposing the shaver to heat or sunlight to prevent damage. Be present during delivery to receive product handling instructions. Use alcohol-based cleaning solution with care to prevent skin irritation or ingestion. Always disconnect the shaver from the power outlet before cleaning with water. Do not use the shaver if the foil or trimmer is damaged, as this may cause injury. Keep out of reach of children.

Package Contents

Upon unpacking, please ensure all items listed below are present:

- Braun Series 8 Electric Foil Shaver
- 4-in-1 SmartCare Center
- Cleaning Cartridge (initial supply)
- Travel Case
- Cleaning Brush
- Charging Cord
- User Manual (this document)
- Clean & Renew Refill Cartridges (6 Count, 4ct)



Image: The Braun Series 8 8467cc electric shaver, its SmartCare Center, travel case, and a stack of cleaning solution cartridges. This image displays the complete product package contents.

Setup

Initial Charging

1. Connect the charging cord to the shaver and a power outlet.
2. Allow the shaver to fully charge before first use. A full charge provides approximately 60 minutes of shaving time.
3. A 5-minute quick charge is available for a single shave.

SmartCare Center Setup

1. Open the SmartCare Center lid.
2. Insert a cleaning cartridge into the base until it clicks into place.
3. Close the lid.
4. Place the shaver head-down into the SmartCare Center. Ensure it is properly seated for charging and cleaning.

Operating Instructions

Shaving

- Press the On/Off button to start the shaver.
- Hold the shaver at a right angle (90°) to your skin.
- Stretch your skin and shave against the direction of hair growth.
- The 40-degree adapting head and floating blades will gently adapt to your facial contours for a close shave.
- Braun's unique Sonic Technology with 10,000 micro-vibrations assists in capturing more hair.

Wet & Dry Use

The Braun Series 8 shaver is designed for both dry shaving and wet shaving with foam or gel, and can be used in the shower. Always ensure the shaver is disconnected from the power supply when used with water.

Precision Beard Trimmer

Slide the precision trimmer up to trim sideburns, mustaches, or longer hairs before shaving.

Maintenance and Cleaning

Cleaning with SmartCare Center

1. After shaving, place the shaver head-down into the SmartCare Center.
2. Press the start button on the SmartCare Center. It will intelligently select a cleaning program, hygienically clean, lubricate, dry, and charge your razor.
3. The alcohol-based cleaning solution ensures optimal hygiene and a refreshing scent.

Manual Cleaning

- **Quick Cleaning:** Rinse the shaver head under hot running water after each use.
- **Thorough Cleaning:** Remove the foil and cutter cassette. Tap out any loose hairs. Use the cleaning brush to remove hairs from the shaver head and the inner parts. Do not use the brush on the foil itself, as this may damage it. Rinse thoroughly.

Replacing Parts

For optimal performance, replace the foil and cutter cassette every 18 months, or when worn. Replace the cleaning cartridge in the SmartCare Center when the fluid level is low or when the cleaning indicator light illuminates.

Troubleshooting

Problem	Possible Cause	Solution
Shaver does not turn on.	Battery is depleted.	Charge the shaver for at least 5 minutes for a quick shave, or fully charge for 60 minutes.
Poor shaving performance.	Foil/cutter cassette is worn or dirty.	Clean the shaver head thoroughly or replace the foil and cutter cassette.
SmartCare Center not cleaning.	Cleaning cartridge is empty or shaver not seated correctly.	Replace the cleaning cartridge or ensure the shaver is properly placed in the center.

For further assistance, please contact Braun customer service.

Specifications

Brand: Braun

Model Name: Electric Razor for Men (Series 8 8467cc)

Power Source: Rechargeable Li-Ion Battery

Battery Life: Up to 60 minutes (5-minute quick charge available)

Recommended Uses: Beard shaving

Included Components: Cartridge, Cleaning Brush, Travel Case, Charging Cord, SmartCare Center

Special Features: 40-degree adapting head, floating blades, Sonic Technology (10,000 micro-vibrations), Wet & Dry use, Precision Beard Trimmer, 4-in-1 SmartCare Center

Warranty and Support

Braun products are manufactured to the highest quality standards. This product comes with a manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions. For technical support, replacement parts, or service, please visit the official Braun website or contact their customer service line.
Visit the Braun Store on Amazon for more information and product accessories.

© 2023 Braun. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BP58X95W

More documents and user manuals: **https://manuals.plus/**