Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Lite Brite 02355

Lite-Brite Touch Instruction Manual

Model: 02355

Introduction

Experience light and art like never before with the all-new Lite-Brite Touch! This innovative toy introduces a new way to play with light, eliminating the need for traditional pegs. Simply press the buttons on the light board to illuminate them and change their colors, allowing you to create vibrant pictures. The Lite-Brite Touch also includes engaging games and offers a lightweight, portable design, making it ideal for various settings.



Image: The Lite-Brite Touch device shown alongside its product packaging, highlighting its interactive features.

Included Components

- 1 Lite-Brite Touch Unit
- Instruction Manual

Setup

Powering Your Lite-Brite Touch

The Lite-Brite Touch can be powered by either batteries or a USB connection.

- **Battery Installation:** Locate the battery compartment on the back of the unit. Insert 3 AA batteries, ensuring correct polarity (+/-). Batteries are included with the product.
- **USB Power:** Connect a compatible USB cable (not included) to the USB port on the device and to a power source (e.g., USB wall adapter, computer USB port).



Image: Rear view of the Lite-Brite Touch, indicating the battery compartment and power switch for setup.

Operating Instructions

Basic Operation

1. **Power On:** Locate the power switch on the side of the Lite-Brite Touch and slide it to the "ON" position.
2. **Button Interaction:** Press any of the 100 light-up buttons on the board. Each press will cycle through 7 different colors.
3. **Modes:** The Lite-Brite Touch features three primary modes:

- **Create Mode:** Design your own art by pressing buttons to change their colors.
- **Play Mode:** Engage in one of three built-in games.
- **Animate Mode:** Apply one of five different animation effects to your creations.



Image: A child is shown comfortably using the Lite-Brite Touch while relaxing on a couch, demonstrating its portable nature.

Features

- **100 Light-Up Buttons:** Press to swap through a variety of colors.
- **7 Colors:** Choose from a spectrum of 7 vibrant colors for your designs.
- **5 Animations:** Bring your creations to life with 5 different animation effects.
- **Save & Recall Images:** Store your finished designs and display them later.
- **Portable Design:** Lightweight and compact, perfect for travel or quiet play anywhere.



Image: The Lite-Brite Touch unit illuminated with a vibrant rainbow pattern, showcasing its color capabilities.

Games

The Lite-Brite Touch includes 3 fun and engaging games:

- **Lite Break:** A game designed to test your reflexes.
- **Lite Match:** Challenge your memory and pattern recognition.
- **Lite Snake:** A classic game adapted for the Lite-Brite platform.

These games can be played solo or with a friend for competitive fun.

Art Creation

Unleash your creativity with the Lite-Brite Touch. You can either follow pre-designed templates or create your own unique masterpieces.

- **12 Art Guides:** Use the included templates to easily create dazzling works of art.

- **Free Design:** Press buttons to change colors and design any picture you can imagine.



Image: A sheet displaying 12 different art guides or templates for users to follow on the Lite-Brite Touch.



Image: A child in a car seat is shown using the Lite-Brite Touch, with a template guide visible, demonstrating its portability for travel.

Maintenance

To ensure the longevity of your Lite-Brite Touch, keep it clean and dry.

- Wipe the surface with a soft, dry cloth.
- Avoid using abrasive cleaners or solvents.
- Do not immerse the device in water.
- When not in use for extended periods, remove batteries to prevent leakage.

Troubleshooting

Common Issues and Solutions

Problem	Solution

Problem	Solution
Device does not turn on.	◦ Ensure batteries are correctly installed with proper polarity. ◦ Replace old batteries with new ones. ◦ Verify USB cable connection if using USB power. ◦ Check if the power switch is in the "ON" position.
Buttons are not changing colors.	◦ Ensure the device is powered on. ◦ Press the button firmly. ◦ If only some buttons are affected, contact customer support.

Specifications

Attribute	Detail
Brand	Lite Brite
Model Name	Lite-Brite Touch
Item Model Number	02355
Age Range (Recommended)	6 years and up
Color	Lite-brite Touch
Material	Plastic
Item Dimensions (L x W x H)	1.2 x 5.8 x 6.7 inches
Item Weight	1.22 pounds
Batteries	3 AA batteries required (included)
Power Source	Battery or USB
Manufacturer	Basic Fun
UPC	885561023558

Safety Information

No specific safety warnings applicable beyond general toy safety guidelines. Always supervise young children during play.

Warranty and Support

For information regarding warranty, returns, or technical support, please refer to the manufacturer's official website or contact their customer service department. Specific warranty details are not provided in this manual.
Manufacturer: Basic Fun

© 2023 Lite Brite. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How do I clear the screen on the Lite-Brite Touch (Model 02355)?

While the provided manual for the Lite-Brite Touch (Model 02355) does not explicitly list a single "clear all" button, you can clear your screen using the following methods based on the device's operation: Manual...

Read full answer

Open the live page

https://manuals.plus/asin/B0BPJZC26G

More documents and user manuals: **https://manuals.plus/**