Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Wipkviey T25

Wipkviey T25 Drone Accessory Kit User Manual

Essential guide for installation, operation, and maintenance of your T25 drone accessories.

1. Introduction

This manual provides detailed instructions for the Wipkviey T25 drone accessory kit. It covers the components included, their proper installation, usage, and maintenance to ensure optimal performance and longevity of your drone.

2. Package Contents

Verify that all items listed below are present in your accessory kit:

- 4 x Propeller Guards
- 4 x Replacement Blades
- 1 x Screwdriver
- 1 x Modular 3.7V 600mAh Li-po Rechargeable Battery
- 1 x Charging Cable



Image 2.1: All components included in the Wipkviey T25 Drone Accessory Kit. This includes four propellers, one modular battery, one charging cable, four propeller guards, and one screwdriver.

3. Setup

3.1. Battery Charging

Before first use, fully charge the modular Li-po battery. Use the provided charging cable and connect it to a compatible USB power source (e.g., computer USB port, USB wall adapter).

- **Charging Time:** Approximately 40 minutes for a full charge.
- **Charging Indicator:** The LED on the charging cable will be continuously lit during charging. Once the battery is fully charged, the LED will turn off.



Image 3.1: The Wipkviey T25 drone with its modular battery installed, highlighting the ease of battery replacement and indicating approximately 10 minutes of flight time per battery.

3.2. Propeller Installation

Ensure correct propeller orientation for stable flight. Each propeller is marked with 'A' or 'B'. Match these markings to the corresponding motor shafts on the drone.

1. Identify the 'A' and 'B' markings on the replacement blades.
2. Match 'A' propellers to motor shafts marked 'A', and 'B' propellers to motor shafts marked 'B'.
3. Gently push the propeller onto the motor shaft until it is securely seated. Do not force.



Image 3.2: Diagram illustrating the correct placement of 'A' and 'B' marked propellers on the Wipkviey T25 drone. 'A' propellers are typically installed diagonally opposite each other, as are 'B' propellers, ensuring proper lift and stability.

3.3. Propeller Guard Installation

Attach the propeller guards to the drone's arms to protect the propellers from impacts. Align the guard with the drone arm and snap it into place. Ensure all four guards are securely fastened before flight.

4. Operating Guidelines

This accessory kit enhances your Wipkviey T25 drone experience. For detailed flight instructions, refer to your drone's main user manual. The modular battery provides approximately 10 minutes of flight time per charge. Always ensure the battery is fully charged and propellers are correctly installed before each flight.

5. Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the drone and accessories. Avoid using harsh chemicals or

solvents.

- **Propeller Inspection:** Regularly inspect propellers for cracks, bends, or damage. Replace any damaged blades immediately using the provided screwdriver.
- **Battery Care:** Store the battery in a cool, dry place away from direct sunlight. Do not overcharge or completely discharge the battery. If storing for extended periods, charge the battery to approximately 50% capacity.
- **Propeller Guards:** Check propeller guards for any damage after impacts. Replace if cracked or broken to maintain protection.

6. Troubleshooting

6.1. Battery Not Charging

- Ensure the charging cable is securely connected to both the battery and the USB power source.
- Verify that the USB power source is functional. Try a different USB port or adapter.
- Check the charging indicator: If the LED is off when connected, the battery might already be fully charged or there's a connection issue.

6.2. Drone Unstable After Propeller Replacement

- Recheck propeller installation. Ensure 'A' propellers are on 'A' motor shafts and 'B' propellers are on 'B' motor shafts. Incorrect placement will cause instability.
- Ensure propellers are fully seated and not loose.
- Inspect new propellers for any manufacturing defects or damage.

7. Specifications

Feature	Detail
Brand	Wipkviey
Model	T25
Battery Type	Modular Li-po
Battery Voltage	3.7 V
Battery Capacity	600 mAh
Charging Time	Approx. 40 minutes
Usage Time (per battery)	Approx. 10 minutes
Included Components	4 Propeller Guards, 4 Replacement Blades, 1 Screwdriver, 1 Li-po Battery, 1 Charging Cable

8. Warranty Information

Wipkviey products are designed for quality and reliability. This accessory kit is covered by a standard manufacturer's warranty against defects in materials and workmanship. Please retain your proof of purchase for warranty claims. For specific warranty terms and conditions, refer to the documentation provided with your original drone purchase or contact customer support.

9. Customer Support

If you encounter any issues or have questions regarding your Wipkviey T25 drone accessory kit, please contact our customer support team. For the fastest service, have your product model number (T25) and purchase details ready.

Email: support@wipkviey.com (Example Email)

Website: www.wipkviey.com (Example Website)

© 2023 Wipkviey. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BQC86SX4

More documents and user manuals: **https://manuals.plus/**