Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

NEBO NEB-FLT-1029

NEBO Davinci 10000 Lumen Flashlight Instruction Manual

Model: NEB-FLT-1029

Brand: NEBO

1. Introduction

This manual provides detailed instructions for the safe and efficient operation, maintenance, and troubleshooting of your NEBO Davinci 10000 Lumen Flashlight. Designed for durability and versatility, this powerful, rechargeable, and waterproof handheld flashlight also functions as a power bank, making it an essential tool for various situations. Please read this manual thoroughly before using your device.

2. Product Overview

Key Features:

- Impressive 10,000 Lumen Turbo Mode for extreme brightness.
- Five versatile light modes: Turbo, High, Medium, Low, and Strobe.
- Durable, aircraft-grade aluminum body with IP67 waterproof rating.
- 4X Zoomable Design for adjustable beam focus.
- Magnetic Mode Select Dial for easy mode switching.
- Smart Power Control and Smart Temperature Control for optimal performance.
- Integrated Power Bank functionality to charge other devices.

Components:

- NEBO Davinci 10000 Lumen Flashlight
- Rechargeable Lithium-Ion Battery (pre-installed)
- USB Charging Cable
- Lanyard



Figure 2.1: The NEBO Davinci 10000 Lumen Flashlight, showcasing its robust design and textured grip.



Figure 2.2: The NEBO Davinci Flashlight acting as a power bank, charging a smartphone via its USB port.



Figure 2.3: Close-up view of the USB charging ports on the NEBO Davinci flashlight, protected by a rubber flap.

3. Setup

3.1 Initial Battery Preparation:

Before first use, unscrew the tail cap of the flashlight. Locate and remove the small plastic disc that insulates the battery. Reinsert the battery with the positive (+) end facing towards the head of the flashlight and securely screw the tail cap back on.

3.2 Charging the Flashlight:

1. Locate the rubber flap on the side of the flashlight body, near the power button.
2. Carefully lift the flap to reveal the USB charging ports.
3. Connect the provided USB charging cable to the appropriate input port (USB-C or Micro-USB, depending on model) on the flashlight.
4. Plug the other end of the USB cable into a compatible USB power source (e.g., wall adapter, computer USB port).
5. The power button LED indicator will show charging status (e.g., red for charging, blue/green for fully charged).
6. Once fully charged, disconnect the cable and firmly close the rubber flap to maintain waterproof integrity.

4. Operating Instructions

4.1 Power On/Off:

Press the power button once to turn the flashlight ON. Press it again to cycle through the different light modes. To turn the flashlight OFF, press the power button after cycling through all modes, or press and hold the power button for approximately 2 seconds from any mode.

4.2 Light Modes:

The Davinci 10000L features 5 light modes:

- **Turbo (10,000 lumens):** Achieved by pressing and holding the power button while the flashlight is on. Provides maximum brightness for 30 seconds, reaching up to 200 meters.
- **High (7,000 lumens):** Approximately 2 hours runtime, 164 meters beam distance.
- **Medium (3,000 lumens):** Approximately 3 hours runtime, 114 meters beam distance.
- **Low (300 lumens):** Approximately 12 hours runtime, 36 meters beam distance.
- **Strobe (10,000 lumens):** Approximately 2 hours runtime, 200 meters beam distance. Activated by double-pressing the power button quickly.

4.3 Zoom Function:

Adjust the beam focus by twisting the head of the flashlight. Twist clockwise for a wider floodlight beam and counter-clockwise for a more focused spotlight beam (4X zoom).

4.4 Power Bank Functionality:

To use the flashlight as a power bank, lift the rubber flap to expose the USB-A output port. Connect your device's charging cable to this port. The flashlight's internal battery will then provide power to charge your external device.

5. Maintenance

5.1 Cleaning:

Wipe the flashlight body with a soft, damp cloth. Do not use abrasive cleaners or solvents. Ensure the charging port flap is clean and securely closed to prevent water or dust ingress.

5.2 Battery Care:

For optimal battery life, fully charge the flashlight before long periods of storage. Recharge the battery every 3-6 months if not in regular use to prevent deep discharge.

5.3 Storage:

Store the flashlight in a cool, dry place away from direct sunlight and extreme temperatures. Keep out of reach of children.

6. Troubleshooting

Problem	Possible Cause	Solution
Flashlight does not turn on.	Battery is dead or not properly inserted.	Charge the battery. Ensure the plastic disc is removed and the battery is inserted correctly.
Light is dim or flickers.	Low battery.	Recharge the flashlight battery.
Flashlight not charging.	Charging cable or adapter faulty; port not fully connected.	Try a different USB cable or power adapter. Ensure the cable is fully inserted into the charging port.
Power bank function not working.	Flashlight battery is too low; device not compatible.	Ensure flashlight battery is sufficiently charged. Check compatibility of the device being charged.

7. Specifications

Feature	Detail
Model Name	NEB-FLT-1029
Brightness	10000 Lumens (Turbo)
Light Source Type	LED
Power Source	Battery Powered (1 Lithium Ion battery included)
Runtime (Low Mode)	12 hours

Feature	Detail
Water Resistance Level	Waterproof (IP67)
Material	Aircraft-grade Aluminum
Color	Storm Gray
Product Dimensions	6"D x 4"W x 4"H

8. Warranty and Support

8.1 Warranty Information:

This NEBO Davinci Flashlight comes with a 2-year manufacturer's warranty. Please retain your proof of purchase for warranty claims.

8.2 Customer Support:

For further assistance, troubleshooting, or warranty inquiries, please visit the official NEBO website or contact their customer support directly. You can find more information and contact details at www.nebo.acgbrands.com.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BS7FSN8R

More documents and user manuals: **https://manuals.plus/**