Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

RED5 93442

RED5 Retro Light-Up Wireless Speaker User Manual

Model: Retro Light-Up Bluetooth Speaker (93442)

Brand: RED5

1. Introduction

Thank you for purchasing the RED5 Retro Light-Up Wireless Speaker. This portable speaker combines retro aesthetics with modern functionality, featuring vibrant RGB LED lighting and multiple audio input options. This manual provides essential information for setting up, operating, and maintaining your speaker to ensure optimal performance and longevity.

What's in the Box:

- RED5 Retro Light-Up Wireless Speaker
- Charging Cable
- User Manual (this document)



Figure 1.1: Packaging of the RED5 Retro Light-Up Wireless Speaker.

2. Key Features

- **Retro Design:** Classic retro styling with a modern twist.
- **Dynamic RGB LED Lighting:** Colour-changing lights enhance the listening experience.
- **Multiple Connectivity Options:** Supports Bluetooth, Aux-in, Micro SD Card, and USB MP3 playback.
- **FM Radio Functionality:** Built-in FM radio for listening to your favourite stations.
- **Portable and Wireless:** Integrated 1200 mAh rechargeable battery provides up to 5 hours of playback.
- **Hands-Free Calling:** Built-in microphone for hands-free phone calls.
- **Compact Size:** Measures approximately 20 cm x 8 cm x 12 cm, making it easy to transport.



Figure 2.1: The speaker displaying pink and red LED lighting on a surface.



Figure 2.2: Angled view of the speaker showcasing its vibrant multi-color LED illumination.

3. Setup Guide

3.1 Charging the Speaker

Before first use, fully charge the speaker. Locate the charging port on the speaker. Connect the provided charging cable to the speaker and the other end to a USB power adapter (e.g., phone charger, computer USB port). The charging indicator light will illuminate during charging and turn off or change colour when fully charged.

Note: A full charge typically takes 2-3 hours. Do not use the speaker while it is charging for optimal battery life.

3.2 Powering On/Off

To power on the speaker, press and hold the Power button. You will hear an audible prompt or see the LED lights activate. To power off, press and hold the Power button again until the speaker shuts down.

4. Operating Instructions

4.1 Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth pairing mode. The LED lights may flash to indicate pairing readiness.

2. On your mobile device (smartphone, tablet, computer), enable Bluetooth.
3. Search for available Bluetooth devices. The speaker will appear as "RED5 Retro Speaker" or similar.
4. Select the speaker from the list to pair. Once connected, you will hear a confirmation tone, and the LED lights may change their pattern.
5. You can now play audio from your device through the speaker.

Note: The speaker will automatically attempt to reconnect to the last paired device when powered on.

4.2 Using Other Input Modes

The speaker supports various input sources:

- **Aux-in:** Connect an audio device using a 3.5mm audio cable (not included) to the AUX port on the speaker. The speaker should automatically switch to Aux mode.
- **Micro SD Card:** Insert a Micro SD card (TF card) with MP3 audio files into the designated slot. The speaker will automatically begin playing music from the card.
- **USB MP3:** Insert a USB flash drive with MP3 audio files into the USB port. The speaker will automatically begin playing music from the drive.
- **FM Radio:** Press the Mode button (if available) to switch to FM Radio mode. Use the skip/volume buttons to scan for stations.

4.3 Controls and Functions

The speaker features intuitive controls, typically located on the top panel:

Button/Control	Function
Power Button	Press and hold to Power On/Off.
Mode Button (M)	Short press to switch between Bluetooth, Aux, Micro SD, USB, and FM Radio modes.
Play/Pause Button (▶)	Short press to Play/Pause music. In call mode, short press to Answer/End call. Long press to reject call.
Previous Track/Volume Down (-)	Short press for Previous Track. Long press to decrease Volume.
Next Track/Volume Up (+)	Short press for Next Track. Long press to increase Volume.



Figure 4.1: Front view of the speaker, highlighting the control buttons on top.



Figure 4.2: The speaker illuminated with blue and red LED lights, placed on a dark surface.



Figure 4.3: The speaker displaying green LED lighting, positioned on a dark surface.



Figure 4.4: Front view of the speaker with its LED lights illuminated in white.

5. Maintenance and Care

- **Cleaning:** Wipe the speaker with a soft, dry cloth. Do not use abrasive cleaners, solvents, or strong chemicals.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the speaker regularly, even if not in use for extended periods.
- **Water Resistance:** This speaker is not water-resistant. Avoid exposure to liquids.
- **Handling:** Handle the speaker with care. Avoid dropping it or subjecting it to strong impacts.

6. Troubleshooting

Problem	Possible Solution
Speaker does not power on.	Ensure the battery is charged. Connect the charging cable and try again.
Cannot pair via Bluetooth.	◦ Ensure the speaker is in Bluetooth pairing mode. ◦ Make sure Bluetooth is enabled on your device. ◦ Move your device closer to the speaker (within 10 meters). ◦ Forget the speaker from your device's Bluetooth list and try pairing again. ◦ Restart both the speaker and your device.
No sound or low volume.	◦ Increase the volume on both the speaker and your connected device. ◦ Ensure the correct input mode is selected (Bluetooth, Aux, SD, USB). ◦ Check audio cables if using Aux-in.

Problem	Possible Solution
FM Radio reception is poor.	◦ Extend the antenna (if applicable, not specified but common). ◦ Move the speaker to a location with better signal reception. ◦ Perform an auto-scan for stations again.

7. Specifications

Feature	Detail
Model Name	Retro Light-Up Bluetooth Speaker
Item Model Number	93442
Brand	RED5
Connectivity Technology	Bluetooth, Auxiliary
Audio Output Mode	Stereo
Special Feature	Built-in Microphone, RGB LED Lights, FM Radio, Micro SD/USB MP3 Playback
Battery Capacity	1200 mAh (estimated from 5 hours playback)
Playback Time	Up to 5 hours
Input Voltage	5 Volts
Product Dimensions (L x W x H)	19.6 x 6.7 x 10.3 cm
Weight	400 g
Material	Plastic, Fabric
Mounting Type	Tabletop

8. Warranty and Support

This product comes with a standard manufacturer's warranty. Please refer to the retailer's return policy for details on warranty claims and returns. For technical support or further inquiries, please contact the retailer or the manufacturer, RED5.
For more information, you may visit theRED5 Store on Amazon.

© 2025 RED5. All rights reserved.
This manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BSQYSK6J

More documents and user manuals: **https://manuals.plus/**