Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun MGK5440

Braun MGK5440 All-in-One 6-in-1 Grooming Kit User Manual

Model: MGK5440

1. Introduction

The Braun MGK5440 All-in-One 6-in-1 Grooming Kit is designed for comprehensive beard, face, and hair styling. This versatile kit includes tools for beard trimming, hair clipping, and precision grooming, offering a complete solution for personal care. Its ultra-sharp blade ensures efficient and comfortable styling.



Image 1.1: The Braun MGK5440 grooming kit with its various attachments.

2. Safety Information

Please read all instructions carefully before using this appliance. Keep this manual for future reference.

- Use the device with caution to avoid skin irritation or eye injuries.
- Ensure the device is kept away from water unless specifically designed for wet use. This model is waterproof and suitable for wet & dry use.
- Always check the trimmer head and combs for damage before use. Do not use if damaged.
- Keep out of reach of children.
- Only use the charger provided with the appliance.
- Adhere to recommended cleaning and maintenance procedures to ensure optimal performance and safety.

3. Package Contents

Your Braun MGK5440 All-in-One Grooming Kit includes the following items:

- 1 Trimmer unit with plastic trimmer attachment
- 1 Mini precision shaving head
- 1 Sliding beard comb (3-11 mm)
- 1 Sliding hair comb (13-21 mm)
- 1 Standard fixed comb (1 mm)
- 1 Standard fixed comb (3 mm)
- 1 Cleaning brush




Image 3.1: All components of the Braun MGK5440 kit.

4. Setup

4.1 Charging the Device

The device features a powerful NiMH battery. Before first use, fully charge the device. Connect the charger to the device and a power outlet. A full charge provides approximately 100 minutes of cordless operation. The charging indicator light will show the charging status.

4.2 Attaching Combs and Heads

To attach a comb or head, align it with the trimmer unit and press firmly until it clicks into place. To remove, gently pull the attachment away from the trimmer unit.

- **Sliding Combs:** For adjustable length settings (3-11mm for beard, 13-21mm for hair). Adjust the dial on the comb to select your desired length.
- **Fixed Combs:** For specific lengths (1mm, 3mm).
- **Mini Precision Shaving Head:** For detailed styling and sharp lines.

5. Operating Instructions

Ensure your skin and hair are clean and dry before trimming, or use with shaving foam/gel for wet shaving, as the device is waterproof.

5.1 Beard Trimming

Attach the sliding beard comb (3-11 mm) and select your desired length setting. Trim against the direction of hair growth for an even cut. For precise lines and edges, remove the comb and use the trimmer head directly.



Image 5.1: Trimming a beard with the Braun MGK5440.

5.2 Hair Clipping

For hair clipping, use the sliding hair comb (13-21 mm) or the fixed combs (1 mm, 3 mm) to achieve various hair lengths. Move the trimmer slowly against the direction of hair growth, ensuring an even cut.

5.3 Body Grooming

The kit can also be used for body grooming. Attach the appropriate head or comb for body hair removal. Use gentle,

even strokes.



Image 5.2: Using the Braun MGK5440 for body grooming.

5.4 Precision Trimming

Utilize the mini precision shaving head for detailed styling, creating sharp lines, or trimming small areas.



Image 5.3: Close-up of the ultra-sharp trimmer blade.

6. Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the life of your grooming kit.

- **After Each Use:** Remove the attachment and rinse the trimmer head and combs under running water.
- **Cleaning Brush:** Use the provided cleaning brush to remove any trapped hairs from the trimmer head and attachments.
- **Drying:** Ensure all parts are thoroughly dry before reattaching or storing the device.
- **Lubrication:** Periodically apply a drop of light machine oil (not included) to the trimmer blades for smooth operation.

7. Troubleshooting

If you encounter any issues with your Braun MGK5440, please refer to the following common solutions:

- **Device not turning on:** Ensure the device is fully charged. Check that the power button is pressed firmly.
- **Reduced trimming performance:** Clean the blades and combs thoroughly to remove any hair buildup. Ensure the blades are not damaged. Consider lubricating the blades.
- **Battery not charging:** Verify that the charger is correctly connected to both the device and the power outlet. Ensure the outlet is functional.
- **Skin irritation:** Ensure you are using the correct comb length for your desired style and trimming against the direction of hair growth. Do not press too hard against the skin.

For persistent issues not resolved by these steps, please contact Braun customer support.

8. Specifications

Feature	Specification
Brand	Braun
Model	MGK5440
Power Source	Battery-powered (NiMH)
Battery Life	Up to 100 minutes cordless operation
Special Features	Cordless, Waterproof (Wet & Dry use)
Recommended Use	Beard, Hair, Body
Blade Material	Metal
Dimensions (L x W x H)	13.7 x 5.7 x 28.2 cm
Weight	311 Grams
Washable Parts	Trimmer heads and combs

9. Warranty and Support

The Braun MGK5440 All-in-One 6-in-1 Grooming Kit comes with a 5-year warranty. For detailed terms and conditions, please refer to the official Braun website or contact Braun customer support.



Image 9.1: Product warranty information.

For further assistance, product registration, or to find replacement parts, please visit the official Braun website or consult your local Braun service center.

© 2023 Braun. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BT539YGS

More documents and user manuals: **https://manuals.plus/**