Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Honor NO

Honor X8a Smartphone User Manual

Model: NO | Brand: Honor

Introduction and Overview

The Honor X8a is a powerful 4G smartphone designed for everyday use, featuring a large display, advanced camera system, and efficient performance. This manual provides essential information on setting up, operating, maintaining, and troubleshooting your device.



Figure 1: Front view of the Honor X8a smartphone.

Setup Guide

1. Unboxing and Initial Inspection

Upon opening the package, ensure all components are present:

- Honor X8a Smartphone
- USB Cable
- Charger
- SIM Tray Ejector
- User Manual (this document)

2. Inserting SIM Cards

The Honor X8a supports Dual SIM functionality using nano SIM cards.

1. Locate the SIM card tray on the side of the device.
2. Insert the SIM tray ejector tool into the small hole next to the tray and press gently until the tray pops out.
3. Place your nano SIM card(s) into the designated slots on the tray. Ensure the gold contacts face downwards.
4. Carefully reinsert the SIM tray into the phone until it clicks into place.






Figure 2: Back view of the Honor X8a, showing the SIM tray location on the side.

3. Charging the Battery

Before first use, it is recommended to fully charge your device.

- Connect the USB cable to the charger and then to the USB-C port on the bottom of your phone.
- Plug the charger into a power outlet.
- The device supports 22.5W SuperCharge for fast charging. A full charge of the 4500mAh battery provides extended usage.




Figure 3: Illustration of the 22.5W SuperCharge capability.



Figure 4: Illustration of the 4500mAh battery capacity.

4. Powering On and Initial Setup

Press and hold the Power button until the Honor logo appears. Follow the on-screen prompts to complete the initial setup, including language selection, Wi-Fi connection, and Google account setup.

Operating Your Honor X8a

1. Basic Navigation and Interface

Your Honor X8a runs on Android 12 with Magic UI 6.1. Navigate using gestures or on-screen buttons. Swipe down from the top for notifications and quick settings. Swipe up from the bottom for the app drawer (if enabled).

2. Camera Features

The Honor X8a is equipped with a versatile camera system:

- **Main Camera:** 100 Megapixels, f/1.9 aperture for high-resolution photos.

- **Wide Angle & Depth Camera:** 5 Megapixels, f/2.2 aperture, for expansive shots and depth effects.
- **Macro Camera:** 2 Megapixels, f/2.4 aperture, for close-up photography.
- **Front Camera:** 16 Megapixels, f/2.45 aperture, for selfies and video calls.



Figure 5: Overview of the Honor X8a camera system.

3. Display and Visual Experience

Experience vibrant visuals on the 6.7-inch LCD FullView display with a resolution of 2388 x 1080 pixels and a smooth 90 Hz refresh rate. The display offers a 93.6% screen-to-body ratio for an immersive viewing experience.



Figure 6: Key display specifications of the Honor X8a.

4. Security Features

Your device offers multiple security options:

- **Face Recognition:** Unlock your phone using your face.
- **Fingerprint Reader:** The side-mounted fingerprint reader provides quick and secure access.
- Standard PIN, Pattern, and Password options are also available.

5. Connectivity

The Honor X8a supports Wi-Fi 5 and Bluetooth for wireless connectivity. USB-C is used for charging and data transfer.

Maintenance

1. Software Updates

Regularly check for and install software updates to ensure optimal performance, security, and access to new features. Go to **Settings > System & updates > Software update**

2. Cleaning Your Device

Use a soft, lint-free cloth to clean the screen and body of your phone. Avoid using harsh chemicals or abrasive materials. Do not expose the device to excessive moisture.

3. Battery Care

To prolong battery life:

- Avoid extreme temperatures.
- Do not let the battery drain completely frequently.
- Use the original charger and cable.

4. Storage Management

Your device comes with 128GB of internal storage. Regularly clear unnecessary files, cache, and uninstall unused apps to maintain performance. You can check storage usage in **Settings > Storage**.

Troubleshooting

This section addresses common issues you might encounter.

Device Not Powering On

- Ensure the battery is charged. Connect the charger and wait a few minutes before attempting to power on.
- Press and hold the Power button for at least 10-15 seconds to force a restart.

Network Connectivity Issues

- **No Signal/Poor Signal:** Check if your SIM card is properly inserted. Try restarting the device. Ensure you are in an area with network coverage.
- **Wi-Fi Connection Problems:** Restart your Wi-Fi router. Forget the network on your phone and reconnect.

Apps Crashing or Freezing

- Close and reopen the app.
- Clear the app's cache and data (Settings > Apps > [App Name] > Storage > Clear cache/Clear data).
- Ensure the app is updated to the latest version.

Slow Performance

- Close background apps.
- Clear cache and unnecessary files.
- Restart your device regularly.
- Consider a factory reset as a last resort (**Note:** This will erase all data on your phone. Back up important information first).

Specifications

Detailed technical specifications for the Honor X8a:

Feature	Specification
Model Number	NO
Display Size	6.7 Inches

Feature	Specification
Max Screen Resolution	2388 x 1080 Pixels
Refresh Rate	90 Hz
Processor	MediaTek Helio G88 (2 GHz, 8 cores)
RAM	6 GB
Internal Storage	128 GB
Operating System	Android 12.0 with Magic UI 6.1
Main Camera	100 Megapixels, f/1.9
Second Camera	5 Megapixels (Wide Angle/Depth), f/2.2
Third Camera	2 Megapixels (Macro), f/2.4
Front Camera	16 Megapixels, f/2.45
Battery Capacity	4500 mAh
Charging	22.5W SuperCharge
Security	Face recognition, Side-mounted fingerprint reader
Dimensions (WxDxH)	74.5 mm x 7.45 mm x 163 mm (2.93 x 0.29 x 6.42 inches)
Weight	179 g (6.3 ounces)
Color	Cyan Lake (Blue)
SIM Type	Dual nano SIM
Wireless Interface	Wi-Fi 5, Bluetooth




Figure 7: Physical dimensions and weight of the Honor X8a.

Warranty and Support

Warranty Information

The Honor X8a comes with a **2-year manufacturer's warranty**. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.
For detailed warranty terms and conditions, please refer to the warranty card included in your product packaging or visit the official Honor website for your region.

Customer Support

If you encounter issues not covered in the troubleshooting section or require further assistance, please contact Honor customer support through their official website or the contact information provided in your product documentation. When contacting support, please have your device model number (NO) and serial number ready.

© 2024 Honor. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BTHHL5L4

More documents and user manuals: **https://manuals.plus/**