Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Dpofirs Dpofirson30kwxzdi

Mini WiFi Camera User Manual

Model: Dpofirson30kwxzdi

Brand: Dpofirs

1. Introduction

Thank you for choosing the Dpofirs Mini WiFi Camera. This compact and versatile camera is designed for discreet surveillance, offering 1080p high-definition video, infrared night vision, and a wide 150-degree viewing angle. Its wireless connectivity and one-touch operation make it an ideal solution for monitoring your home, office, or outdoor spaces. Please read this manual carefully to ensure proper use and optimal performance of your device.



Image 1.1: Front view of the Dpofirs Mini WiFi Camera.

2. Product Features

- **1080p HD Video Quality:** Captures clear and detailed footage with 1080p resolution and a superior quality chip, ensuring a clearer image with digital noise reduction.
- **150° Wide-Angle View:** Provides a broad field of view, allowing for comprehensive monitoring of larger areas.
- **High-Definition Night Vision:** Equipped with infrared night vision, enabling clear recording even in low-light or complete darkness, up to 10 meters.
- **Wireless Connectivity:** Supports remote monitoring via wireless connection, allowing you to view live footage from anywhere.
- **Built-in WiFi Hotspot:** Features an integrated WiFi hotspot, enabling real-time recording and viewing even when no external network is available.
- **One-Touch Control:** Simple operation with a single button to power on the camera and initiate recording.
- **Compact and Portable Design:** Small form factor for easy placement and discreet surveillance.



Image 2.1: Illustration of the camera's 150-degree wide-angle view.



Image 2.2: Comparison showing the camera's day and night vision capabilities.

3. Package Contents

Please check the package carefully to ensure all items are present:

- 1 x Mini WiFi Camera
- 1 x User Manual
- 2 x Data Cables (USB)
- 1 x Stand (Magnetic Mount)



Image 3.1: Contents of the Dpofirs Mini WiFi Camera package.

4. Setup

4.1 Charging the Camera

Before first use, fully charge the camera. Connect one of the provided USB data cables to the camera's charging port (located on the side/bottom) and the other end to a USB power adapter (not included) or a computer's USB port. The charging indicator light will show the charging status.



Image 4.1: Bottom view of the camera with the charging port.

4.2 Inserting a Memory Card

The camera supports local storage via a memory card (not included). Locate the memory card slot on the camera and gently insert a compatible card (e.g., microSD) until it clicks into place. Ensure the camera is powered off before inserting or removing the card.

4.3 Connecting to Wi-Fi

The camera can connect to your home Wi-Fi network for remote monitoring or operate via its built-in Wi-Fi hotspot for direct connection. Refer to the detailed instructions in the included user manual for specific app download and connection procedures.

4.4 Mounting the Camera

Use the provided magnetic stand to position the camera. The magnetic base allows for easy attachment to metallic surfaces or stable placement on flat surfaces. Adjust the camera angle as needed for optimal viewing.



Image 4.2: The camera and its magnetic mount.

5. Operating Instructions

5.1 Power On/Off

To power on the camera, press and hold the 'ON/OFF' button until the indicator light illuminates. To power off, press and hold the 'ON/OFF' button again until the light turns off.

5.2 One-Touch Recording

Once a memory card is inserted and the camera is powered on, you can activate recording with a single touch. Refer to the specific instructions in the full user manual for details on recording modes and saving footage.

5.3 Remote Monitoring via App

Download the recommended mobile application (details in the included manual) to access live video feeds, review recorded footage, and adjust camera settings remotely. Ensure your camera is connected to a Wi-Fi network for remote access.

5.4 Night Vision

The camera's infrared night vision activates automatically in low-light conditions, providing clear black and white video. No manual intervention is typically required for this feature.



Image 5.1: Examples of how the mini camera can be used in different environments.

6. Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the camera lens and body. Avoid using liquid cleaners or abrasive materials.
- **Storage:** Store the camera in a cool, dry place away from direct sunlight and extreme temperatures when not in use.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the camera regularly, even if not in constant use.
- **Firmware Updates:** Check the manufacturer's website or app for any available firmware updates to ensure optimal performance and security.

7. Troubleshooting

7.1 Camera Not Turning On

- Ensure the camera is fully charged.
- Press and hold the 'ON/OFF' button for a few seconds.

7.2 Wi-Fi Connection Issues

- Ensure the camera is within range of your Wi-Fi router.
- Verify that the Wi-Fi password entered is correct.
- Restart both the camera and your Wi-Fi router.
- If using the hotspot, ensure your device is directly connected to the camera's Wi-Fi signal.

7.3 Recording Problems

- Check if a memory card is properly inserted and has sufficient free space.
- Ensure the memory card is formatted correctly (refer to manual for format type).

- The battery might be low; charge the camera.

7.4 Poor Image Quality

- Clean the camera lens with a soft cloth.
- Ensure there is adequate lighting in the environment, or that night vision is active if in darkness.
- Check the camera's resolution settings in the app.

8. Specifications

Feature	Specification
Item Type	Mini WiFi Camera
Material	ABS Plastic
Video Resolution	1080p
Video Format	ASF
Compression Format	H.264
Frame Rate	25 FPS
Wide Angle	150°
Night Vision Distance	Up to 10 m (32.8 feet)
Continuous Recording Time	Approx. 1 hour
Recording Range	5 m²
Power Consumption	240 mA, 3.7 V
Built-in Battery	300 mAh Lithium Polymer
Connectivity Protocol	Wi-Fi
Power Source	Battery Powered
Usage Environment	Indoor
Product Dimensions	10.5 x 10.5 x 4.2 cm
Product Weight	80 grams

9. Warranty and Support

This product comes with a standard manufacturer's warranty. For detailed warranty information, technical support, or any inquiries regarding your Dpofirs Mini WiFi Camera, please refer to the contact information provided in the original product packaging or visit the official Dpofirs website. Please retain your proof of purchase for warranty claims.

© 2024 Dpofirs. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BTYZFPTF

More documents and user manuals: **https://manuals.plus/**