Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun 51-R1000s

Braun Series 5 Electric Shaver Instruction Manual

Model: 51-R1000s

Introduction

Thank you for choosing the Braun Series 5 Electric Shaver. This manual provides essential information for the safe and effective use, maintenance, and care of your shaver. Please read these instructions thoroughly before first use and keep them for future reference.
The Braun Series 5 electric shaver is designed for a thorough and comfortable shave, featuring flexible blades that adapt to your facial contours and AutoSense technology for efficient hair capture.

Product Overview



Image 1: Braun Series 5 Electric Shaver (Model 51-R1000s) in its retail packaging. The packaging highlights key features such as "Easy, Close & Gentle Shave" and "Up to 5 Years Warranty".

The Braun Series 5 shaver is equipped with advanced features for an optimal shaving experience:

- **3 Flexible Blades:** Designed to adapt to your facial contours for a close and comfortable shave.

- **AutoSense Technology:** Detects beard density and adjusts motor performance to capture and cut more hair efficiently.
- **EasyClean System:** Allows for quick and easy cleaning of the shaver without needing to remove the shaving head.
- **Wet & Dry Use:** Fully waterproof design enables comfortable dry shaving or refreshing wet shaving with foam or gel.
- **Lithium-ion Battery:** Provides up to 50 minutes of cordless shaving on a full charge, with a 5-minute quick charge option for one shave.

Setup and Charging





Image 2: The Braun Series 5 shaver packaging, illustrating features like the EasyClean system, Li-ion battery, Wet & Dry use, and "Made in Germany" label. The model number 51-R1000s is also visible.

1. **Initial Charge:** Before using your shaver for the first time, fully charge it for approximately 1 hour. This provides up to 50 minutes of cordless shaving time.
2. **Connecting the Charger:** Use the provided charging cable. Plug the small end into the shaver's charging port and the larger end into a power outlet.
3. **Charging Indicator:** The battery indicator lights on the shaver will show the charging status. When fully charged, all lights will be illuminated or turn off, depending on the model.
4. **Quick Charge:** A 5-minute quick charge provides enough power for one shave.
5. **Important Note:** Ensure the shaver is dry before charging. Do not immerse the shaver completely in water during charging.

Operating Instructions





Image 3: A man using the Braun Series 5 electric shaver on his face, demonstrating its ergonomic design and flexible shaving head. The image highlights the shaver's ability for a clean and close shave.

1. **Turning On/Off:** Press the power button located on the front of the shaver to turn it on or off.
2. **Dry Shaving:** For a dry shave, ensure your face is clean and dry. Hold the shaver at a right angle (90°) to your skin and shave against the direction of hair growth. Stretch your skin with your free hand to ensure a smooth surface.

3. **Wet Shaving:** The shaver is 100% waterproof and can be used with shaving foam or gel for a refreshing wet shave. Apply foam or gel to your face, then proceed as with dry shaving. Rinse the shaver head under running water during and after use.
4. **Flexible Blades:** The shaver's flexible blades will adapt to your facial contours. Apply gentle, even pressure for optimal results.
5. **AutoSense Technology:** The shaver automatically adjusts its power to the density of your beard, ensuring efficient cutting even on dense areas.

Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the lifespan of your Braun Series 5 shaver.

1. **EasyClean System:** After each shave, activate the EasyClean system. Simply hold the shaver head under running warm water while the shaver is switched on. The water will flow through the shaving head, rinsing away stubble and debris without needing to remove the foil and cutter block.
2. **Deep Cleaning:** For a more thorough cleaning, switch off the shaver, remove the foil and cutter block, and rinse both parts under running warm water. You can use the included cleaning brush to remove stubborn hair particles, but do not use the brush on the foil as it may damage it.
3. **Drying:** After cleaning, shake off excess water and allow the shaver head to air dry completely before reattaching the foil and cutter block or storing.
4. **Lubrication:** Periodically, apply a drop of light machine oil (e.g., Braun Shaver Oil) to the foil and cutter block to maintain optimal cutting performance.
5. **Replacement Parts:** For best shaving performance, replace the shaver's foil and cutter block every 18 months, or when they show signs of wear.

Troubleshooting

If you encounter issues with your Braun Series 5 shaver, please refer to the following common solutions:

- **Shaver not turning on:** Ensure the shaver is fully charged. If the battery is completely depleted, it may take a few minutes of charging before the shaver can be switched on.
- **Reduced shaving performance:** Clean the shaver thoroughly using the EasyClean system or by removing the shaving head. Ensure the foil and cutter block are not damaged and are correctly seated. Consider replacing the foil and cutter block if they are older than 18 months.
- **Shaver not charging:** Check that the charging cable is securely connected to both the shaver and the power outlet. Ensure the outlet is functional.
- **Skin irritation:** Ensure your skin is clean before shaving. Shave against the direction of hair growth with gentle pressure. If using for wet shaving, ensure sufficient foam or gel is applied. Allow your skin to adapt to the new shaver over a few weeks.

If the problem persists, please contact Braun customer support.

Specifications

Brand	Braun
Model Name	Series 5

Item Model Number	51-R1000s
Power Source	Battery Powered
Special Features	AutoSense Technology, Cordless, Dry Shave, EasyClean system, Waterproof, Wet
Recommended Uses	Face
Battery Life	Up to 21 days (50 minutes shaving time)
Item Weight	275 Grams
Colour	Red
Blade Material	Stainless Steel
Product Dimensions	14 x 6.5 x 25 cm
Manufacturer	Procter & Gamble
Country of Origin	Germany

Warranty and Support

Your Braun Series 5 Electric Shaver comes with a**5-year warranty**. Please note that terms and conditions apply, which can be found on the official Braun website.
For further assistance, product registration, or to view the full warranty details, please visit the official Braun website or contact Braun customer service.
Manufacturer Contact: Frankfurter Str.145, 61476 Kronberg, Germany
For the most up-to-date support information, please refer towww.braun.com.

Safety Information

Please observe the following safety precautions:

- This appliance is suitable for cleaning under running water.
- Do not immerse the shaver completely in water for extended periods beyond normal wet shaving use.
- Use only the power supply provided with the appliance.
- Do not use the appliance if the foil or cord is damaged.
- Keep out of reach of children.

© 2025 Braun. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BVFV23L6

More documents and user manuals: **https://manuals.plus/**