Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

DUMOS EB38F

DUMOS Small Standing Desk EB38F User Manual

Model: EB38F

Brand: DUMOS

Introduction

Thank you for choosing the DUMOS Small Standing Desk, Model EB38F. This mobile and height-adjustable workstation is designed to provide a flexible and ergonomic solution for your home or office environment. This manual contains important information regarding the assembly, operation, and maintenance of your desk. Please read it thoroughly before use and retain it for future reference.

Safety Information

- Ensure all components are securely fastened before use.
- Do not exceed the maximum weight capacity of 33 lbs (15 kg).
- Keep hands and fingers clear of moving parts during height adjustment.
- Use on a level surface to prevent tipping.
- Do not allow children to play on or around the desk.
- Regularly inspect the desk for any signs of wear or damage. Discontinue use if damage is found.

Package Contents

Please verify that all parts are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- Desktop Panel (MDF)
- Main Support Column (with pneumatic lift mechanism)
- Base Frame (H-shaped metal)
- Casters (4, two with locking mechanism)
- Assembly Hardware (screws, wrench, Allen key)
- Instruction Manual



Image: Overview of desk components and included assembly tools.

Assembly Instructions

Assembly is straightforward and typically takes less than 10 minutes. All necessary tools are included.

1. **Attach Casters to Base Frame:** Insert the four casters into the designated holes on the H-shaped metal base frame. Ensure they are securely tightened. Two of the casters have locking mechanisms.
2. **Connect Main Support Column to Base Frame:** Align the main support column with the center of the H-shaped base frame. Secure it using the provided screws and wrench/Allen key.
3. **Attach Desktop Panel:** Place the desktop panel upside down on a soft, clean surface. Align the main support column with the pre-drilled holes on the underside of the desktop. Secure the desktop to the column using the remaining screws.
4. **Final Check:** Carefully turn the assembled desk upright. Ensure all connections are tight and the desk is stable.

Operating Instructions

Height Adjustment (Pneumatic System)

The DUMOS Standing Desk features a pneumatic adjustment system, allowing you to effortlessly switch between sitting

and standing positions. The height can be adjusted between 28.5 inches and 42.5 inches.

- **To Raise the Desk:** Lightly press the adjustment lever located under the desktop while gently lifting the desktop. The pneumatic cylinder will assist in raising the desk. Release the lever at your desired height.
- **To Lower the Desk:** Lightly press the adjustment lever located under the desktop while applying gentle downward pressure on the desktop. The desk will lower smoothly. Release the lever at your desired height.



Image: The desk shown in both sitting and standing configurations, demonstrating height adjustability.

Mobile Functionality (Lockable Casters)

The desk is equipped with four silent wheels for easy mobility. Two of these casters include a locking mechanism to secure the desk in place.

- **To Move the Desk:** Ensure the locking mechanisms on the two casters are disengaged (unlocked). Gently push the desk to your desired location.
- **To Lock the Desk in Place:** Once the desk is in position, step on the locking levers of the two lockable casters until they click into place. This will prevent the desk from rolling.



Image: The DUMOS Standing Desk with a laptop and coffee, highlighting its mobile design with casters.

Maintenance

Proper maintenance will ensure the longevity of your DUMOS Standing Desk.

- **Cleaning:** Wipe the desktop and metal frame with a damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.
- **Pneumatic System:** The pneumatic lift system is designed for maintenance-free operation. Do not attempt to disassemble or lubricate it.



Image: Details of the durable MDF desktop and the sturdy H-shaped metal base, emphasizing material quality.

Troubleshooting

Problem	Possible Cause	Solution
Desk is unstable or wobbly.	Loose screws; uneven surface.	Ensure all assembly screws are tightened. Move desk to a level surface.

Problem	Possible Cause	Solution
Desk does not adjust height smoothly.	Obstruction; pneumatic system issue.	Check for any obstructions around the column. If the issue persists, contact customer support.
Casters do not roll or lock properly.	Debris in casters; locking mechanism engaged/disengaged incorrectly.	Clean any debris from caster wheels. Ensure locking levers are fully engaged or disengaged.

Specifications

Feature	Detail
Model Number	EB38F
Brand	DUMOS
Product Dimensions (D x W x H)	19"D x 25.7"W x 42.5"H
Adjustable Height Range	28.5" to 42.5"
Maximum Weight Capacity	33 lbs (15 kg)
Desktop Material	Engineered Wood (MDF)
Base Material	Metal
Color	Black
Lifting Mechanism	Pneumatic
Assembly Required	Yes (Tools included)



Image: Detailed product dimensions and maximum weight capacity of the desk.

Warranty and Support

DUMOS products are manufactured to high-quality standards. For warranty information, technical support, or to report missing/damaged parts, please refer to the contact information provided at the point of purchase or visit the official DUMOS website. Please have your model number (EB38F) and purchase date available when contacting support.

© 2025 DUMOS. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BX8TQ4TZ

More documents and user manuals: **https://manuals.plus/**