Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

KMM LT-117C

KMM Handheld Car Vacuum Cleaner Instruction Manual

Model: LT-117C
Brand: KMM

Introduction

Welcome to the instruction manual for your new KMM Handheld Car Vacuum Cleaner. This versatile 2-in-1 device combines powerful vacuuming with efficient air dusting, designed for convenient cleaning in various environments including your car, home, and office. Please read this manual thoroughly before operating the device to ensure safe and optimal performance.

Product Overview

The KMM Handheld Car Vacuum Cleaner (Model LT-117C) is a compact and lightweight cleaning solution. It features a 9000Pa strong suction for effective debris removal and a powerful blowing function for dusting. Equipped with a built-in 4000mAh rechargeable battery, it offers cordless operation and fast charging. The device includes multiple detachable nozzles to cater to diverse cleaning needs, from tight crevices to broader surfaces, and an integrated LED light for improved visibility in dark areas.



Image: The KMM Handheld Car Vacuum Cleaner shown with its main unit, various suction and blowing nozzles, a USB charging cable, and a washable HEPA filter.

Features

- **Powerful Air Duster and Vacuum Cleaner 2 in 1:** This device offers dual functionality, allowing you to either suck up dirt and debris or blow away dust and particles.
- **Rechargeable Battery and Fast Charging:** Features a built-in 4000mAh battery that charges fully in approximately 3 hours, providing extended cordless operation.
- **Effortless Maintenance:** Designed for easy cleaning with a one-click dismantling system for the dust bin and a washable, reusable HEPA filter.
- **Simple and Lightweight Design:** Weighing only 0.72 lbs, its compact and portable design ensures comfortable handling and easy storage.
- **Integrated LED Light:** An LED light is incorporated to illuminate dark areas, making cleaning in low-light conditions more effective.
- **Wide Application:** Comes with various detachable brush head nozzle accessories suitable for cleaning computer keyboards, cameras, air conditioners, sofas, windows, pet areas, and more.

Setup

Charging the Device

Before first use, fully charge the vacuum cleaner. Connect the provided USB charging cable to the charging port located at the bottom of the device. Plug the other end into a compatible USB power source such as a car charger, mobile power bank, laptop, or adapter charger. The charging indicator light will provide feedback on the charging status. A full charge typically takes 2.5 to 3 hours.



Image: The vacuum cleaner connected to a USB charging cable, illustrating various compatible power sources like a car charger, power bank, computer, and wall adapter.

Attaching Nozzles

Select the appropriate nozzle for your cleaning task. Align the nozzle with the suction or blowing port and firmly push it into place until it clicks securely. Ensure the nozzle is properly seated to prevent loss of suction or blowing power during operation.

Operating Instructions

Power On/Off

To turn on the device, press the power switch located on the handle. Press it again to turn off. The device typically has two power levels; press the button to cycle through them.

Vacuum Function

Attach the desired suction nozzle to the front port. Guide the nozzle over the surface to be cleaned, allowing the powerful suction to pick up dust, crumbs, pet hair, and other small debris. For tight spaces, use the crevice tool. For larger areas or upholstery, use the brush attachments.



Image: The vacuum cleaner demonstrating its dual functionality, showing it being used to clean a keyboard (suction) and a car interior vent (blowing).

Air Duster Function

Attach the appropriate blowing nozzle to the rear air outlet. Use the powerful airflow to dislodge and clear dust from delicate electronics, keyboards, car vents, or hard-to-reach areas. This function is ideal for tasks where suction might not be suitable or where debris needs to be pushed away.



Image: A visual guide to the different nozzles and their applications, including the HEPA filter & waste bin, suction nozzle for windows/crevices, blow nozzle for fine dust, and floor brush for larger surfaces.

Using the LED Light

The integrated LED light can be activated by pressing the power switch. It provides illumination for cleaning in dimly lit environments, ensuring no dust or debris is missed.



Image: The vacuum cleaner's LED light illuminating dark areas during cleaning, such as under car seats and floor mats.

Official Product Video

Your browser does not support the video tag.

Video: An official product video demonstrating the features and usage of the KMM Handheld Car Vacuum, including its dual vacuum and duster functions, compact design, and various applications.

Maintenance

Emptying the Dust Bin

After each use or when the dust bin is full, it is recommended to empty it. The dust bin can be easily detached with a one-click dismantling mechanism. Simply twist or unclip the transparent dust bin from the main unit and dispose of the collected debris.

Cleaning the HEPA Filter

The HEPA filter is washable and reusable. After emptying the dust bin, remove the HEPA filter. Rinse it under running water until clean. Ensure the filter is completely dry before reinserting it into the dust bin and reattaching the bin to the vacuum cleaner. Regular cleaning of

the filter maintains optimal suction power and prevents blockages.



Image: An internal view of the vacuum cleaner highlighting the 9000Pa suction power, 4000mAh battery capacity, and the washable HEPA filter within the transparent dust bin.

Troubleshooting

- **Device not turning on:** Ensure the battery is fully charged. If the device was recently used, allow it to cool down for a few minutes before attempting to charge or operate again.
- **Weak suction/blowing power:** Check if the dust bin is full and needs emptying. Inspect the HEPA filter for clogs and clean it if necessary. Ensure all nozzles and attachments are securely fitted.
- **Unusual noise:** Turn off the device immediately. Check for any foreign objects lodged in the nozzles or the main unit's intake/outlet.

If you encounter persistent issues not covered here, please contact KMM customer support for assistance.

Specifications

Feature	Detail
Brand	KMM
Model Name	LT-117C
Special Feature	Portable, High Power, Cordless, Rechargeable, Washable Filter
Filter Type	HEPA Filter
Included Components	Brush, Various Nozzles, USB Charging Cable
Is Cordless?	Yes
Wattage	120 watts
Runtime	20-30 minutes (typical usage)
Charging Time	2.5 - 3 hours
Product Dimensions	7.68"L x 6.3"W x 2.68"H
Item Weight	12.3 ounces (0.72 lbs)
Battery Description	Lithium-Ion (4000mAh)
Noise Level	60 dB
Connectivity Technology	USB

Warranty and Support

For information regarding product warranty, returns, or technical support, please refer to the warranty card included in your product packaging or visit the official KMM website. You may also contact KMM customer service directly through the contact information provided on their website or your purchase platform.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BYD5XB67

More documents and user manuals: **https://manuals.plus/**