Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun Replacement Shaver Cord (Multi-model compatible)

Braun Replacement Shaver Cord User Manual

Official instructions for the Braun Replacement Shaver Cord, ensuring proper use and compatibility.

1. Introduction

This manual provides essential information for the safe and effective use of your Braun Replacement Shaver Cord. This cord is designed to provide power and charging capabilities for a wide range of compatible Braun electric shavers and trimmers. Please read these instructions carefully before use to ensure optimal performance and longevity of your device and the replacement cord.

2. Compatibility

The Braun Replacement Shaver Cord is compatible with numerous Braun shaver types and models. Verify your shaver's type or model number against the lists below to confirm compatibility.

2.1. Compatible Shaver Types

This cord is compatible with the following Braun shaver types:

- 5417
- 5418
- 5427
- 5429
- 5514
- 5515
- 5517
- 5683
- 5685
- 5751
- 5757
- 5758
- 5759

- 5760

2.2. Compatible Shaver Models

This cord is compatible with the following Braun shaver models:

- 130, 140, 150 (Series 1)
- 510, 530, 550cc, 560, 565, 565CC, 570CC, 590CC
- 815, 8385, 8374, 8377
- BT5090, Cruzer5 Beard and Head, Cruzer6 Beard and Head, BT5070
- HC3050, HC5010, HC5030, HC5050, HC5090
- WaterFlex models WF1s, WF2s

3. Setup

Follow these steps to properly set up and connect your Braun Replacement Shaver Cord:

1. **Inspect the Cord:** Before first use, carefully inspect the replacement cord for any signs of damage, such as cuts, frayed wires, or bent pins. Do not use the cord if any damage is observed.
2. **Connect to Shaver:** Locate the power input port on your Braun shaver. Gently insert the connector end of the replacement cord into the shaver's power port until it is firmly seated. Ensure the connection is secure.
3. **Connect to Power Outlet:** Plug the wall adapter end of the replacement cord into a standard electrical outlet. Ensure the outlet provides the correct voltage as specified by your shaver's original manual or the shaver itself.
4. **Verify Connection:** Once connected, your shaver should indicate that it is receiving power or charging (e.g., a charging indicator light may illuminate).



Image 1: The Braun Replacement Shaver Cord. This image displays the full length of the black power cord with its wall adapter plug on one end and the shaver connector on the other. The cord is coiled neatly.



Image 2: Close-up view of the shaver cord connector. This image provides a detailed look at the two-pin connector end of the cord, which plugs into the Braun shaver. The pins are clearly visible, along with polarity markings.

4. Operating

The replacement shaver cord functions identically to the original power cord provided with your Braun shaver. It is designed to supply the necessary electrical power for operating the shaver directly from an outlet or for recharging its internal battery.

- **Direct Operation:** For shavers that support corded operation, connect the cord as described in the Setup section. You can then use your shaver while it is plugged into the power outlet.
- **Charging:** For shavers with rechargeable batteries, connect the cord to the shaver and a power outlet. The shaver's charging indicator will typically show the charging status. Refer to your shaver's original manual for specific charging times and indicator behaviors.

Always ensure the cord is not strained or bent sharply during use or storage to prevent internal damage.

5. Maintenance

Proper care of your replacement shaver cord will extend its lifespan and ensure reliable performance.

- **Cleaning:** Disconnect the cord from both the shaver and the power outlet before cleaning. Wipe the cord and adapter with a dry, soft cloth. Do not use abrasive cleaners or immerse the cord in water.
- **Storage:** When not in use, store the cord in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly wrapping the cord around the adapter or shaver, as this can stress the wire and lead to damage. Gently coil the cord for storage.
- **Inspection:** Periodically inspect the cord for any signs of wear, such as cracks in the insulation, exposed wires, or loose connections at either end. Replace the cord immediately if any damage is found.

6. Troubleshooting

If you encounter issues with your Braun Replacement Shaver Cord, consider the following troubleshooting steps:

- **Shaver Not Powering On/Charging:**
  - Ensure the cord is fully inserted into both the shaver and the wall outlet.
  - Try plugging the cord into a different electrical outlet to rule out a faulty outlet.
  - Verify that your shaver model is listed as compatible in Section 2.
  - Inspect the cord for visible damage. If damaged, discontinue use and replace.
  - If the shaver has a battery, ensure it is not completely depleted or faulty.
- **Loose Connection:**
  - If the cord feels loose when plugged into the shaver, gently push it in firmly.
  - Avoid pulling the cord by the wire; always grasp the plug when disconnecting.

If the issue persists after following these steps, it may indicate a problem with the shaver itself or a need for a new replacement cord. Contact Braun customer support or an authorized service center for further assistance.

7. Specifications

Key specifications for the Braun Replacement Shaver Cord:

Manufacturer	Braun
Product Type	Replacement Shaver Power Cord
ASIN	B0BZG9VGNS
Compatibility	Refer to Section 2 for a comprehensive list of compatible Braun shaver types and models.

Note: Specific electrical ratings (voltage, amperage) are designed to match the requirements of the compatible Braun shavers. Always use the cord with compatible devices only.

8. Warranty and Support

For information regarding the warranty of your Braun Replacement Shaver Cord, please refer to the original product packaging or the official Braun website. Warranty terms may vary based on region and retailer.
For technical support, service, or to purchase additional accessories, please visit the official Braun support channels or their authorized service centers. You can find more information on the Braun Store on Amazon or their global website.

© 2023 Braun. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BZG9VGNS

More documents and user manuals: **https://manuals.plus/**