Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ENJBRICK 1028

ENJBRICK Typewriter Building Set Model 1028 Instruction Manual

Model: 1028 | Brand: ENJBRICK

1. Product Overview

This manual provides detailed instructions for the assembly, operation, and care of your ENJBRICK Typewriter Building Set, Model 1028. This set is inspired by classic typewriters and includes a platen roller, a printed paper element, and 26 letter keys, offering a detailed and engaging building experience.



Image 1.1: The fully assembled ENJBRICK Typewriter Building Set, showcasing its detailed design and functional elements.

2. Setup and Assembly

The ENJBRICK Typewriter Building Set comes with an easy-to-follow instruction booklet. All building bricks are made from durable, light, and safe ABS plastic with smooth edges, similar to classic building brands. The bricks are typically organized in numbered bags to simplify the assembly process.

2.1. Unboxing and Preparation

1. Carefully open the package and remove all contents.
2. Verify that all numbered bags of bricks and the instruction booklet are present.
3. Find a clean, well-lit, and spacious area for assembly.

2.2. Assembly Instructions

Follow the included instruction booklet step-by-step. Each step will guide you through connecting the pieces to form the complete typewriter model.



Image 2.1: A user assembling the ENJBRICK Typewriter Building Set, with the instruction manual visible in the background.

2.3. Assembly Video Guide

For a visual guide on the unboxing and initial assembly steps, please refer to the video below:

▶ **Watch video online**
ENJBRICK Typewriter Toy Building Set unboxing

Video 2.1: An unboxing and assembly overview of the ENJBRICK Typewriter Building Set, demonstrating the components and initial construction.

3. Operating the Model

While this is a building model and not a functional writing instrument, it incorporates several interactive features

designed to mimic a real typewriter.

3.1. Key Mechanism

- The model includes 26 letter keys. These keys are designed to provide a tactile experience, simulating the typing action of a classic typewriter.
- Pressing the keys will engage the internal mechanism, adding to the realistic feel of the model.

3.2. Platen Roller and Paper Insertion

- The platen roller is a key feature, allowing for the insertion of the included printed paper.
- Gently slide the printed paper into the slot above the platen roller. The roller can be turned to advance or retract the paper, simulating paper movement.



Image 3.1: A close-up of the assembled typewriter model, showing the paper inserted into the platen roller.

3.3. Feature Demonstration Video

Observe the interactive features and overall design of the typewriter model in the following video:

▶ **Watch video online**
ENJBRICK Typewriter Toy Building Set

Video 3.1: A demonstration of the ENJBRICK Typewriter Toy Building Set, highlighting its features and interactive elements.

4. Maintenance

Proper care will ensure the longevity and appearance of your building set.

4.1. Cleaning

- To clean the model, gently wipe it with a soft, dry cloth.
- For stubborn dust or dirt, a slightly damp cloth can be used, followed by immediate drying. Avoid harsh chemicals or abrasive cleaners.

4.2. Storage

- Store the assembled model in a cool, dry place away from direct sunlight to prevent discoloration or material degradation.
- If disassembling for storage, keep all pieces in a sealed container to prevent loss.

5. Troubleshooting

Should you encounter any issues during assembly or with the completed model, consider the following:

5.1. Missing Pieces

- Double-check all packaging and bags. Small pieces can sometimes be overlooked.
- Refer to the parts list in your instruction booklet to confirm if a piece is indeed missing.
- If a piece is genuinely missing, contact ENJBRICK customer support for assistance.

5.2. Assembly Difficulties

- Review the instruction booklet carefully, paying close attention to the images and step numbers.
- Ensure pieces are oriented correctly and fully pressed together.
- Sometimes, disassembling a small section and re-building it can resolve alignment issues.

6. Specifications

Key specifications for the ENJBRICK Typewriter Building Set Model 1028:



Image 6.1: Visual representation of the assembled typewriter model's dimensions.

Feature	Detail
Brand	ENJBRICK
Model Number	1028
Item Dimensions (L x W x H)	5.75 x 4.68 x 1.73 inches
Item Weight	9.92 ounces
Number of Pieces	26
Material Type	ABS Plastic (Note: 'Paper' is listed for included printed paper element)
Assembly Required	Yes
Recommended Age	8-14 Years (Manufacturer Minimum Age: 96 months)

Included Components	Building Set, Printed Paper

7. Warranty Information

Specific warranty details for the ENJBRICK Typewriter Building Set Model 1028 are not provided in the product information. For any warranty-related inquiries, please refer to the product packaging or contact the retailer or manufacturer directly.

8. Customer Support

For further assistance, questions, or to report missing parts, please contact ENJBRICK customer support through the retailer's platform or the official ENJBRICK website, if available. Always provide your model number (1028) and purchase details when seeking support.

© 2023 ENJBRICK. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BZRW93W4

More documents and user manuals: **https://manuals.plus/**