Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Soundcore A3947

Soundcore Liberty 4 NC Wireless Noise Cancelling Earbuds User Manual

Model: A3947 | Brand: Soundcore

Introduction

Welcome to the user manual for your Soundcore Liberty 4 NC Wireless Noise Cancelling Earbuds. These earbuds are designed to provide an immersive audio experience with advanced noise cancellation, high-resolution sound, and extended battery life. This manual will guide you through the setup, operation, and maintenance of your device to ensure optimal performance.



Image: Soundcore Liberty 4 NC earbuds in their light blue charging case, showcasing the product design.

What's in the Box

Upon unboxing your Soundcore Liberty 4 NC earbuds, verify that all components are present:

- Soundcore Liberty 4 NC Earbuds
- Charging Case (extends battery life to 50 hours)
- XS/S/M/L Ear Tips (Medium size pre-installed)
- USB-C Charging Cable



Image: Contents of the Soundcore Liberty 4 NC retail package, including earbuds, charging case, various ear tip sizes, and a USB-C charging cable.

Setup

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. Connect the provided USB-C cable to the charging case and a power source. The case also supports wireless charging.

- **Wired Charging:** Use the USB-C port on the charging case.
- **Wireless Charging:** Place the charging case on a compatible wireless charging pad.

A 10-minute fast charge provides approximately 4 hours of listening time.



Image: The Soundcore Liberty 4 NC charging case being wirelessly charged, highlighting its extended battery capabilities.

2. Selecting the Right Ear Tips

For optimal sound quality and noise cancellation, it is crucial to select the correct ear tip size. Experiment with the included XS, S, M, and L ear tips to find the best fit for your ears. A snug fit ensures effective passive noise isolation and secure placement.



Image: A detailed view of the Soundcore Liberty 4 NC earbud, emphasizing the ear tip for proper fit.

3. Bluetooth Pairing

1. Open the charging case. The earbuds will automatically enter pairing mode.
2. On your device (smartphone, tablet, laptop), enable Bluetooth.
3. Search for "Soundcore Liberty 4 NC" in the list of available devices and select it to connect.
4. For Android devices, Fast Pair enables quick and effortless connection.

The earbuds support Bluetooth 5.3 and multi-point connection, allowing simultaneous connection to two devices.



Image: Illustration of a user pairing the Soundcore Liberty 4 NC earbuds with a mobile device via Bluetooth.

4. Soundcore App Installation

For full customization and access to advanced features like HearID 2.0, adjustable EQ, and noise cancellation modes, download the Soundcore app from your device's app store. The app provides a comprehensive interface for personalizing your audio experience.

Operating Instructions

1. Controls

The Liberty 4 NC earbuds feature touch controls on each earbud and a 3-in-1 smart button on the charging case for various functions.

- **Earbud Touch Controls:** Customizable via the Soundcore app for playback, call management, and noise control.
- **Charging Case Smart Button:** Press to open the case, enter Bluetooth pairing mode, or reset your earbuds.



Image: The 3-in-1 smart button on the Soundcore Liberty 4 NC charging case, used for opening, pairing, and resetting.

2. Noise Cancellation and Transparency Modes

The Liberty 4 NC features Adaptive ANC 2.0, which automatically adjusts noise cancellation based on your ear canals and environment. You can also manually select from various modes:

- **Noise Cancellation:** Reduces up to 98.5% of external noise. Offers 5 levels of noise cancellation and 4 specialized modes for plane, train, bus, and taxi travel.
- **Transparency Modes:** Allows you to hear your surroundings without removing the earbuds. Two transparency modes are available.

These modes can be managed through the Soundcore app.



Image: A user experiencing Adaptive ANC 2.0 with Soundcore Liberty 4 NC earbuds in a travel setting.

3. Sound Customization

Personalize your listening experience using the Soundcore app:

- **HearID 2.0:** Creates a personalized sound profile tailored to your hearing.
- **Custom EQ:** Adjust the equalizer settings to your preference.
- **22 Presets:** Choose from a variety of pre-configured sound profiles.

The earbuds feature 11mm custom-tuned drivers and LDAC technology for Hi-Res wireless audio, delivering 3 times more data than standard Bluetooth.



Image: Visual representation of customizing sound profiles for the Soundcore Liberty 4 NC earbuds.

4. Making Calls

The Liberty 4 NC earbuds are equipped with 6 beamforming microphones and an AI algorithm to enhance your voice and reduce background noise during calls, ensuring clear communication.



Image: A user making a clear phone call with Soundcore Liberty 4 NC earbuds, highlighting the 6-mic AI technology.

5. Water Resistance

The earbuds are IPX4 water-resistant, protecting them from splashes and sweat. This makes them suitable for workouts and outdoor activities, but they are not designed for submersion in water.



Image: Soundcore Liberty 4 NC earbuds shown with water droplets, demonstrating their IPX4 water-resistant rating.

Maintenance

Proper maintenance ensures the longevity and optimal performance of your earbuds.

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Remove ear tips and clean them with mild soap and water, ensuring they are completely dry before reattaching. Clean the mesh and charging contacts carefully to prevent debris buildup.
- **Storage:** When not in use, store the earbuds in their charging case to protect them from dust and damage.
- **Avoid Extreme Conditions:** Do not expose the earbuds to extreme temperatures, humidity, or corrosive liquids.

Troubleshooting

If you encounter issues with your Soundcore Liberty 4 NC earbuds, refer to the following common solutions or consult the official troubleshooting guide.

- **No Sound/Poor Sound Quality:**
  - Ensure earbuds are charged and connected.
  - Check ear tip fit for proper seal.
  - Clean earbud mesh and charging contacts.
  - Adjust volume on both earbuds and connected device.
- **Pairing Issues:**
  - Ensure Bluetooth is enabled on your device.
  - Place earbuds back in the case, close, then reopen to re-enter pairing mode.
  - Forget the device from your Bluetooth list and try pairing again.
  - Reset the earbuds using the smart button on the charging case (refer to the Soundcore app or full manual for specific reset instructions).
- **Noise Cancellation Not Working:**
  - Ensure ear tips provide a good seal.
  - Check ANC settings in the Soundcore app.
- **Battery Not Charging:**
  - Verify USB-C cable and power adapter are working.
  - Ensure wireless charging pad is compatible and properly aligned.
  - Clean charging contacts on earbuds and case.

For more detailed troubleshooting, please refer to the official Troubleshooting Guide (PDF) or the comprehensive User Manual (PDF).

Specifications

Feature	Detail
Model Name	Liberty 4 NC (A3947)
Noise Control	Active Noise Cancellation (Adaptive ANC 2.0)
Audio Driver Size	11 Millimeters
Connectivity Technology	Wireless (Bluetooth 5.3)
Bluetooth Range	10 Meters
Battery Life (Earbuds)	10 Hours (Normal Mode), 8 Hours (ANC On)
Battery Life (with Case)	50 Hours (Normal Mode), 40 Hours (ANC On)
Charging	USB-C, Wireless Charging, Fast Charging (10 mins for 4 hrs)
Water Resistance Level	IPX4
Microphones	6 (with AI Clear Calls)
Control Type	Touch
Item Weight	1.76 ounces (50 Grams)
Product Dimensions	4.25 x 4.25 x 2.17 inches
Color	Light Blue
UPC	194644132262

Warranty and Support

Soundcore products typically come with a limited warranty. Please refer to the warranty information included with your purchase or visit the official Soundcore website for details regarding warranty coverage and terms.
For further assistance, technical support, or to explore additional Soundcore products, please visit the Soundcore Store on Amazon or the official Soundcore support channels.
You may also find the Troubleshooting Guide (PDF) and the full User Manual (PDF) helpful.

© 2023 Soundcore. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BZV6SYXQ

More documents and user manuals: **https://manuals.plus/**