Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Langsdom BE09

Langsdom Open Ear Sport Headphones User Manual

Model: BE09

1. Introduction

Thank you for choosing Langsdom Open Ear Sport Headphones. This manual provides essential information for the proper use, maintenance, and troubleshooting of your new headphones. Please read it thoroughly before using the product to ensure optimal performance and longevity.

2. Product Overview

The Langsdom Open Ear Sport Headphones (Model: BE09) are designed for comfort and safety during various activities, including music listening, sports, running, cycling, and hiking. They feature an open-ear design that allows you to remain aware of your surroundings while enjoying high-quality audio.

2.1 Key Features

- **Open Audio Design:** Utilizes updated air conduction technology for sound delivery without bone conduction vibration, reducing ear canal discomfort.
- **Enhanced Bass:** Equipped with a special power amplifier chip and 14.2mm large unit for pure and full bass.
- **Directional Sound Transmission:** Innovative snail-shaped sound chamber design minimizes sound dispersion and enhances privacy.
- **Dual Device Connection:** Allows simultaneous connection to a laptop and mobile phone, with easy switching.
- **Long Battery Life:** Up to 15 hours of playtime.
- **Durability:** IPX4 waterproof rating.
- **Control:** Combined touch and button controls for ease of use.

2.2 Package Contents

Upon opening the package, please verify that all items are present and in good condition.

- Langsdom Open Ear Sport Headphones (Model: BE09)
- USB-C Charging Cable
- User Manual




Image: The Langsdom Open Ear Sport Headphones, a USB-C charging cable, and the user manual, all neatly arranged next to the product packaging.

2.3 Comfort and Safety



Image: A person wearing the Langsdom Open Ear Sport Headphones, highlighting the open-ear comfort design that does not require insertion into the ear canal.



Image: A cyclist wearing the Langsdom Open Ear Sport Headphones, emphasizing the benefit of maintaining awareness of surroundings for outdoor safety.

3. Setup

3.1 Charging the Headphones

Before first use, fully charge your headphones. Use the provided USB-C cable to connect the headphones to a USB power source (e.g., computer USB port, wall adapter). The charging indicator light will provide status feedback (refer to LED indicator section for details).




Image: A diagram showing the dimensions of the Langsdom Open Ear Sport Headphones, indicating a length of 135mm (5.31 inches) and a height of 110mm (4.33 inches).

3.2 Pairing with a Bluetooth Device

1. Ensure the headphones are powered off.
2. Press and hold the power button until the LED indicator flashes rapidly (usually blue and red), indicating pairing mode.
3. On your device (smartphone, tablet, computer), enable Bluetooth and search for available devices.
4. Select "Langsdom BE09" (or similar name) from the list of found devices.
5. Once connected, the LED indicator will change to a steady blue light or turn off, depending on the model.

For dual device connection, pair with the first device, then disable Bluetooth on the first device. Put the headphones back into pairing mode and connect to the second device. Re-enable Bluetooth on the first device; the headphones should automatically connect to both.



Image: The Langsdom Open Ear Sport Headphones positioned between an open laptop and a smartphone, illustrating the dual device connection capability.

4. Operating Instructions

4.1 Power On/Off

- **Power On:** Press and hold the power button for approximately 3 seconds until the LED indicator lights up.
- **Power Off:** Press and hold the power button for approximately 5 seconds until the LED indicator turns off.

4.2 Music Playback

- **Play/Pause:** Single press the multi-function button.
- **Next Track:** Double press the multi-function button.
- **Previous Track:** Triple press the multi-function button.
- **Volume Up:** Single press the Volume + button.

- **Volume Down:** Single press the Volume - button.

4.3 Call Management

- **Answer/End Call:** Single press the multi-function button during an incoming call.
- **Reject Call:** Press and hold the multi-function button for 2 seconds during an incoming call.
- **Activate Voice Assistant:** Press and hold the multi-function button for 2 seconds when not on a call.



Image: A person wearing the Langsdom Open Ear Sport Headphones while running outdoors, demonstrating their use during physical activity.

5. Maintenance

Proper maintenance ensures the longevity and performance of your headphones.

- **Cleaning:** Wipe the headphones with a soft, dry, lint-free cloth. Do not use abrasive cleaners, alcohol, or chemical solvents.

- **Storage:** Store the headphones in a cool, dry place away from direct sunlight and extreme temperatures.
- **Water Resistance:** The headphones have an IPX4 waterproof rating, meaning they are resistant to splashing water from any direction. Do not submerge them in water or expose them to heavy rain. Dry them thoroughly if they get wet.
- **Charging:** Always use the provided USB-C cable for charging. Avoid using damaged cables or chargers.

6. Troubleshooting

If you encounter issues with your headphones, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Headphones do not power on.	Low battery.	Charge the headphones fully.
Cannot pair with device.	Headphones not in pairing mode; Bluetooth off on device; device too far.	Ensure headphones are in pairing mode (flashing LED). Turn on Bluetooth on your device. Move device closer to headphones.
No sound or low volume.	Volume too low on headphones or device; not connected properly.	Increase volume on both headphones and device. Reconnect headphones to device.
Sound quality is poor.	Interference; low battery.	Move away from sources of interference (e.g., Wi-Fi routers). Charge headphones.

If the problem persists, please contact customer support.

7. Specifications

Feature	Detail
Model Number	BE09
Brand	Langsdom
Ear Placement	Open Ear
Impedance	32 Ohm
Playtime	Up to 15 hours
Waterproof Rating	IPX4
Connectivity	Wireless Bluetooth
Charging Port	USB-C
Color	Gray/Orange

8. Warranty and Support

Langsdom provides a one-year quality guarantee for this product. For warranty claims, technical support, or any inquiries, please contact Langsdom customer service through the retailer where you purchased the product or visit the official Langsdom website.

Please retain your proof of purchase for warranty purposes.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BZYQC6SL

More documents and user manuals: **https://manuals.plus/**