ELYKEN B0C1B2MNKT

ELYKEN Narrow Console Sofa Table User Manual

Model: B0C1B2MNKT

1. Introduction

Thank you for purchasing the ELYKEN Narrow Console Sofa Table. This manual provides essential information for the safe assembly, operation, maintenance, and troubleshooting of your new table. Please read these instructions carefully before use and retain them for future reference.

2. Safety Information

- Always assemble the table on a stable, flat surface.
- Use the anti-tipping strap and expansion screw to secure the table to the wall, especially if heavy items are placed on it.
- Tighten all screws and adjust the feet pegs to ensure stability.
- Do not place heavy items on the table that could cause it to tip over.
- Ensure the power cord is routed safely to prevent tripping hazards.
- Do not overload the electrical outlets or USB ports.
- Keep liquids away from electrical components.

3. Package Contents

Please verify that all components are present before beginning assembly:

- Tabletop (Engineered Wood)
- Metal Frame Components
- LED Light Strip (pre-attached or separate, refer to specific packaging)
- Power Strip with 2 AC Outlets and 2 USB Ports
- 6.5-foot Extension Cord

- Hexagonal Wrench
- Screws and Fasteners
- Anti-tipping Strap and Expansion Screw
- Adjustable Feet Pegs

4. Setup and Assembly

Assembly is required. All necessary tools (hexagonal wrench, screws) are included. Follow these steps for proper assembly:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Assemble the Metal Frame:** Connect the metal support rods to the table legs using the provided screws and hexagonal wrench. Ensure all connections are secure but do not overtighten initially.
3. **Attach the Tabletop:** Place the engineered wood tabletop onto the assembled metal frame. Align the screw holes and secure the tabletop to the frame using the remaining screws. Tighten all screws firmly.
4. **Install Adjustable Feet Pegs:** Screw the adjustable feet pegs into the bottom of each table leg. Adjust them as needed to ensure the table is level and stable on your floor.
5. **Secure with Anti-Tipping Strap:** For enhanced stability, attach the anti-tipping strap to the back of the table and secure it to the wall using the expansion screw. This is highly recommended to prevent accidental tipping.
6. **Connect Power Strip:** The power strip with outlets and USB ports is integrated into the tabletop. Ensure its connection is secure.

Figure 4.1: Product dimensions and integrated power features.

Description for Figure 4.1: This image displays the overall dimensions of the ELYKEN console table, which is 5.9"D x 39.4"W x 31.1"H. It highlights the metal frame structure and the integrated power strip with its 6.5-foot extension cord. The diagram also shows the placement of the power outlets and USB ports on the tabletop.

Figure 4.2: Adjusting the feet pegs for stability.

Description for Figure 4.2: A close-up image illustrating a hand adjusting one of the table's adjustable feet pegs. These pegs can be rotated 360 degrees and adjusted in height to ensure the table remains stable and level on uneven surfaces.

5. Operating Instructions

5.1. LED Light Strip Operation

The console table features an integrated LED light strip with multiple color options and dynamic modes. The LED strip is controlled by a single button, typically located near the power strip.

- **Power On/Off:** Press the control button once to turn the LED lights on or off.
- **Change Colors:** With the lights on, press the control button repeatedly to cycle through the 7 available color options.
- **Change Modes:** Continue pressing the button to cycle through the 3 dynamic modes (Flash, Smooth, Fade).

Figure 5.1: LED light strip displaying various colors behind a sofa.

Description for Figure 5.1: This image shows the ELYKEN console table positioned behind a sofa, with its integrated LED light strip illuminating the wall in a vibrant display of colors. The lighting creates an ambient atmosphere in the living space.

Figure 5.2: Control button for LED light strip.

Description for Figure 5.2: A close-up view of a hand pressing the single control button for the LED light strip, demonstrating how to cycle through colors and modes.

5.2. Charging Station Usage

The integrated charging station provides convenient access to power for your electronic devices.

- **AC Outlets:** Plug in standard 120VAC devices into the two AC outlets.
- **USB Ports:** Connect your USB-powered devices (e.g., smartphones, tablets) to the two USB ports for charging.
- Ensure the table's main power cord is plugged into a wall outlet for the charging station and LED lights to function.

Figure 5.3: Smartphone charging via the integrated USB port.

Description for Figure 5.3: This image shows a smartphone connected to and charging from one of the integrated USB ports on the console table's surface. The power strip also includes two standard AC outlets.

5.3. Official Product Video

Your browser does not support the video tag.

Video 5.1: ELYKEN Console Table with LED features demonstration.

Description for Video 5.1: This official product video from ELYKEN demonstrates the key features of the console table, including the functionality of the LED light strip with its various colors and dynamic modes, as well as the convenience of the integrated charging station with AC outlets and USB ports. It provides a visual guide to operating these features.

6. Maintenance

- **Cleaning:** Wipe the table surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Dusting:** Regularly dust the table and LED strip to maintain optimal light output and appearance.
- **Electrical Components:** Ensure the power strip and LED connections remain dry and free from dust. Do not attempt to disassemble or repair electrical components yourself.
- **Tighten Fasteners:** Periodically check and retighten all screws and fasteners to ensure the table remains stable.

7. Troubleshooting

Problem	Possible Cause	Solution
LED lights not turning on.	Power cord not plugged in; loose connection; faulty LED strip.	Ensure the main power cord is securely plugged into a wall outlet. Check the connection of the LED strip to the power source. If issues persist, contact customer support.
Charging station (outlets/USB) not working.	Main power cord unplugged; device not properly connected; power strip malfunction.	Verify the table's main power cord is plugged in. Ensure devices are correctly inserted into outlets/USB ports. Test with different devices. If still not working, contact customer support.
Table is wobbly.	Loose screws; uneven floor; feet pegs not adjusted.	Tighten all assembly screws. Adjust the individual feet pegs to compensate for uneven flooring. Ensure the anti-tipping strap is securely installed if applicable.

8. Specifications

Brand: ELYKEN

Model: B0C1B2MNKT

Product Dimensions: 5.9"D x 39.4"W x 31.1"H

Frame Material: Metal

Top Material Type: Engineered Wood

Color: Black

Special Features: LED Light Strip (7 colors, 3 dynamic modes), Integrated Charging Station (2 AC Outlets, 2 USB Ports, 6.5 ft Power Cord)

Assembly Required: Yes (Hexagonal wrench and screws included)

9. Warranty and Support

For warranty information or technical support, please refer to the contact details provided with your purchase documentation or visit the official ELYKEN website. Our customer service team is available to assist you with any questions or concerns regarding your product.
ELYKEN Customer Support: Visit the ELYKEN Store on Amazon