ChomChom Roller ChomChom Roller

ChomChom Roller Pet Hair Remover Instruction Manual

Model: ChomChom Roller

1. Introduction

The ChomChom Roller is a reusable tool designed for effective removal of pet hair from various surfaces. It operates without the need for adhesives or sticky tape, providing a sustainable solution for maintaining a hair-free environment. This manual provides instructions for its proper use, maintenance, and general information.

Image 1.1: The ChomChom Roller, demonstrating its hair collection capability.

This image displays the black ChomChom Roller, highlighting its design and how it effectively captures pet hair within its internal chamber after use.

2. Setup

The ChomChom Roller requires no assembly or batteries. It is ready for immediate use upon removal from its packaging.

1. **Unpack:** Carefully remove the ChomChom Roller from its packaging.
2. **Inspect:** Check the roller for any visible damage. If damaged, do not use and contact customer support.

3. Operating Instructions

Follow these steps for effective pet hair removal:

Image 3.1: Step-by-step guide for using the ChomChom Roller.

This image visually guides the user through the three primary steps of operating the ChomChom Roller: rolling it across a surface to collect hair, pressing the release button to open the hair collection chamber, and then manually removing the collected hair for disposal.

1. **Position:** Place the roller on the surface you wish to clean (e.g., couch, carpet, clothing).
2. **Roll Back and Forth:** Apply light to moderate pressure and roll the ChomChom Roller back and forth in short, quick strokes. The specialized brush material will capture pet hair and lint, depositing it into the internal chamber.
3. **Repeat:** Continue rolling until the desired area is free of pet hair.

The ChomChom Roller is effective on various surfaces, including:

- Couches and upholstery
- Carpets and rugs
- Clothing and bedding
- Pet beds and cat towers
- Car seats and mats

Image 3.2: Versatile application of the ChomChom Roller.

This image demonstrates the ChomChom Roller's effectiveness across multiple surfaces, including a blue couch, a red pet bed, a beige cat tower, and a black car seat, all shown with significant pet hair before cleaning.

4. Maintenance

Regular cleaning of the ChomChom Roller ensures optimal performance.

1. **Emptying the Hair Receptacle:**
   - After use, locate the release button on the handle.
   - Press the button to open the hair collection chamber.
   - Manually remove the collected pet hair from the chamber and dispose of it.
   - Close the chamber securely until it clicks.
2. **Cleaning the Roller Surface:**
   - If the roller surface appears dirty or less effective, gently wipe it with a damp cloth.

- Allow the roller to air dry completely before next use. Do not submerge in water.



Image 4.1: Opening and emptying the hair chamber.

These images illustrate the process of opening the ChomChom Roller's hair collection chamber by pressing the release button and then manually removing the accumulated pet hair.

5. Troubleshooting

Problem	Possible Cause	Solution
Roller not picking up hair effectively.	Hair chamber is full. Roller surface is dirty. Incorrect rolling technique.	Empty the hair chamber (see Section 4). Wipe the roller surface with a damp cloth (see Section 4). Ensure you are rolling back and forth with moderate pressure.
Chamber not closing properly.	Hair obstructing the closing mechanism.	Clear any hair or debris from the edges of the chamber and the closing mechanism.

6. Specifications

Brand: ChomChom Roller

Model: ChomChom Roller

Material: Plastic

Color: Black

Product Dimensions: 7.5"D x 7.5"W x 2.16"H (19cm x 19cm x 5.5cm)

Item Weight: 6.7 ounces (190 grams)

Operation Mode: Manual

Batteries Required: No

UPC: 856957004154

ASIN: B0C2FMZMHP

Image 6.1: ChomChom Roller features and dimensions.

This diagram illustrates the key features of the ChomChom Roller, including its overall dimensions (7.5 inches in length and width), the fur-grabbing brush mechanism, and the large internal waste compartment for collected hair.

7. Warranty and Support

For information regarding product warranty, returns, or customer support, please refer to the retailer's return policy or contact the manufacturer directly.

Return Policy: This product is typically eligible for returns within 30 days of receipt, subject to the retailer's specific terms and conditions. Please check your purchase details for exact information.

Manufacturer: ChomChom Roller

Online Support: Visit the official ChomChom Roller Store on Amazon for additional product information and support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question