Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Sweetcrispy SF-5021-AMBK

Sweetcrispy Recliner Chair (Model SF-5021-AMBK) - User Manual

Brand: Sweetcrispy | Model: SF-5021-AMBK

Introduction Safety Information Package Contents Setup Operation Features Maintenance Specifications Support

1. Introduction

Thank you for choosing the Sweetcrispy Recliner Chair. This manual provides essential information for the safe assembly, operation, and maintenance of your new recliner. Please read it thoroughly before use and retain it for future reference.
This model (SF-5021-AMBK) is designed for comfort and relaxation, featuring adjustable push-back reclining and high-density sponge cushioning. **Please note: This specific model does NOT include a massage function.**

2. Important Safety Information

- **Read All Instructions:** Familiarize yourself with all assembly and operating instructions before using the chair.
- **Weight Limit:** Do not exceed the maximum weight capacity of 300 lbs (136 kg).
- **Proper Assembly:** Ensure all parts are correctly assembled and tightened before use. Regularly check for loose connections.
- **Avoid Pinch Points:** Keep hands, feet, and pets clear of the reclining mechanism when adjusting the chair to prevent injury.
- **Stable Surface:** Place the recliner on a flat, stable surface to prevent tipping.
- **Children and Pets:** Do not allow children or pets to play on or around the recliner unsupervised.
- **Moving the Chair:** When moving the chair, ensure it is in the upright, non-reclined position. Lift, do not drag, to prevent damage to the chair or floor.

3. Package Contents

Verify that all components are present before beginning assembly. The package typically includes:

- Chair Base (1)
- Chair Backrest (1)
- Legs (4)
- Instruction Manual (1)
- Necessary Tools (e.g., Allen wrench)

Note: Some smaller components like legs and tools may be stored within zippered compartments under the chair base or in small boxes within the main packaging.

4. Setup and Assembly

Assembly is quick and typically takes about 5 minutes. Follow these steps:

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a soft, clean surface to prevent scratches.



Image: All components of the Sweetcrispy Recliner Chair unpacked and ready for assembly.

2. **Attach Legs:** Locate the four legs. Gently tilt the chair base to access the underside. Screw each leg into the designated threaded holes on the bottom of the chair base. Ensure they are tightened securely.



Image: Attaching a leg to the underside of the chair base.

3. **Attach Backrest:** Align the metal brackets on the backrest with the corresponding slots on the chair base. Slide the backrest down firmly until it clicks securely into place.



Image: Sliding the backrest onto the chair base until it locks.

4. **Final Check:** Once assembled, gently test the stability of the chair and ensure all connections are firm.

5. Operating Instructions

Reclining the Chair:

This recliner features an adjustable push-back mechanism. To recline:

1. Sit comfortably in the chair.
2. Lean back gently against the backrest while applying slight pressure with your body.
3. The footrest will extend, and the backrest will recline to your desired position (between 90° and 160°).
4. To return to the upright position, lean forward and push down on the footrest with your legs until it locks into place.



Image: Visual representation of the adjustable reclining angles (90° to 160°).

Important Note: This model (SF-5021-AMBK) does not include a massage function. If your product came with a remote control for massage, it is likely a different variant. Please refer to the product description for your specific model.

6. Key Features

- **Adjustable Reclining:** Effortlessly switch between 90° and 160° reclining positions for various activities like reading, napping, or watching TV.
- **Premium Comfort:** Crafted with high-quality fabrics and filled with a high-resilience sponge for superior comfort and breathability.
- **Durable Construction:** Features a sturdy hardwood frame for long-lasting durability and reliable stability.
- **Enhanced Footrest:** The upgraded footrest provides optimal relaxation.
- **Ergonomic Design:** Provides fatigue-free sitting even for extended periods with lumbar support.



Image: Detailed view of key product characteristics including thicker cushioning, wider armrests, retractable footrest, and metal support structure.

7. Maintenance

- **Cleaning:** Wipe clean with a damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the PU leather.
- **Regular Inspection:** Periodically check all bolts and screws to ensure they are tight. Re-tighten if necessary.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause the material to fade or crack.
- **Spills:** Blot spills immediately with a clean, dry cloth.

8. Troubleshooting

- **Chair Not Reclining Smoothly:**
  - Check for any obstructions around the reclining mechanism.
  - Ensure all assembly bolts are securely tightened.
- **Squeaking Noises:**
  - Inspect the reclining mechanism for any loose parts or areas that may require lubrication (use a silicone-based lubricant sparingly).
- **Stability Issues:**
  - Verify that the chair is placed on a flat, even surface.
  - Re-tighten all leg and backrest connections.

If you encounter issues not covered here, please contact customer support.

9. Specifications

Brand	Sweetcrispy
Model Name	Sweetcrispy Recliner Chair PU Leather Recliner Sofa No Massage
Item Model Number	SF-5021-AMBK
Color	Black
Product Dimensions	34.25"D x 26.77"W x 38.37"H
Weight Capacity	300 lbs
Item Weight	47.4 pounds
Material	PU Leather, High-Density Sponge
Reclining Position Count	2 (90° to 160°)
Assembly Required	Yes
Product Care Instructions	Wipe Clean



Image: Detailed product dimensions and weight capacity information.

10. Warranty and Customer Support

For any issues, concerns, or questions regarding your Sweetcrispy Recliner Chair, please contact our dedicated customer service team. Our team is ready to provide prompt assistance.
Please refer to your purchase documentation for specific warranty details and contact information.
You may also visit the official Sweetcrispy store for more information:Sweetcrispy Store

© 2025 Sweetcrispy. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C2Z1X3N4

More documents and user manuals: **https://manuals.plus/**