**Manuals+**
Q & A | Deep Search | Upload

**CPT37**

# Generic CPT37 Wallet Case for INOVALLEY Smartphone 5.7 POUCES 4G User Manual

Model: CPT37 | Brand: Generic

## Introduction

This manual provides instructions for the Generic CPT37 Wallet Case, designed specifically for the INOVALLEY Smartphone 5.7 POUCES 4G. This case offers protection, convenience, and functionality with its integrated kickstand, magnetic closure, and card storage features. Please read this manual carefully to ensure proper use and maintenance of your product.

## Setup

1. **Unpacking:** Carefully remove the wallet case from its packaging.
2. **Inserting Your Smartphone:**
   - Open the wallet case.
   - Align your INOVALLEY Smartphone 5.7 POUCES 4G with the silicone frame inside the case.
   - Gently press the phone into the silicone frame, ensuring all edges are securely seated and all ports and buttons are accessible.
3. **Securing the Case:** Close the front flap. The integrated magnetic closure will automatically secure the case, keeping your phone protected.

*Image: The INOVALLEY Smartphone 5.7 POUCES 4G securely placed in the CPT37 wallet case, demonstrating the kickstand functionality and the magnetic closure.*

## Operating Instructions

### Using the Kickstand Feature

1. Open the front flap of the wallet case.
2. Fold the front flap backward and position it to create a triangular stand.
3. Adjust the angle for comfortable viewing of videos or e-books.

### Utilizing Card Storage

1. Open the front flap of the wallet case.
2. Locate the card slots on the inner side of the front flap.
3. Insert up to two standard-sized cards (e.g., ID, credit cards) into the designated slots.
4. Ensure cards are fully seated to prevent them from falling out.

*Image: The CPT37 wallet case open, displaying the integrated card storage slots with example cards inserted.*

## Maintenance

- **Cleaning:** To clean the PU leather surface, gently wipe with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or solvents, as these can damage the material.
- **Drying:** Allow the case to air dry completely after cleaning. Do not expose it to direct sunlight or high heat.
- **Storage:** When not in use, store the case in a cool, dry place away from direct sunlight to prevent material degradation.
- **Avoid Overstuffing:** Do not overfill the card slots, as this can stretch the material and compromise the magnetic closure.

## Troubleshooting

**Issue: Phone does not fit securely in the case.**

**Solution:** Ensure your smartphone is an INOVALLEY Smartphone 5.7 POUCES 4G. This case is specifically designed for this model. Verify the phone is correctly aligned and pressed firmly into the silicone frame.

**Issue: Magnetic closure is not holding the flap closed.**

**Solution:** Check if the card slots are overfilled. Excessive cards or bulky items can prevent the magnetic closure from engaging properly. Remove some items if necessary.

**Issue: Case appears dirty or stained.**

**Solution:** Refer to the "Maintenance" section for proper cleaning instructions. For stubborn stains, a mild soap solution on a damp cloth may be used, followed by wiping with a clean, damp cloth and air drying.

## Specifications

| | |
|---|---|
| **Model** | CPT37 |
| **Compatible Phone Models** | INOVALLEY Smartphone 5.7 POUCES 4G |

| | |
|---|---|
| **Material** | Polyurethane (PU) Leather, Silicone |
| **Special Features** | Kickstand, Magnetic Closure, Card Slots |
| **Item Weight** | 2.46 ounces |
| **Product Dimensions (L x W x H)** | 0.39 x 0.39 x 0.39 inches |

## Warranty and Support

This product is manufactured by Generic. For any inquiries regarding warranty, product support, or technical assistance, please refer to the retailer where the product was purchased or visit the manufacturer's official website for contact information.
Please retain your proof of purchase for warranty claims.

© 2023 Generic. All rights reserved.