Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LUE BONA 500*2

LUE BONA Outdoor Chaise Lounge Chairs Instruction Manual

Model: 500*2

1. Introduction

Thank you for choosing the LUE BONA Outdoor Chaise Lounge Chairs. This manual provides essential information for the safe assembly, operation, and maintenance of your new chaise lounge chairs. Please read these instructions thoroughly before use and retain them for future reference.



Image 1: LUE BONA Outdoor Chaise Lounge Chairs in a poolside setting.

2. Safety Information

WARNING: Failure to follow these safety instructions may result in injury or product damage.

- Always use the chaise lounge chairs responsibly and within their specified weight capacity.
- Exercise caution when moving the chairs, especially on slippery or uneven surfaces, to prevent tipping or loss of control.
- Ensure all bolts and fasteners are securely tightened before each use. Periodically check and re-tighten as necessary.
- Keep children and pets away from the assembly area.
- Do not stand on the chaise lounge chairs.
- Avoid placing hot items directly on the chair surface to prevent damage.

3. Package Contents

Verify that all components are present before beginning assembly. If any parts are missing or damaged, contact LUE BONA customer support.

- Chaise Lounge Chair Components (for 2 chairs)
- Hardware Kit (bolts, washers, nuts, Allen wrench)
- Instruction Manual

4. Assembly Instructions

Assembly typically takes approximately 25 minutes per chair. It is recommended to have a second person assist with assembly for easier handling of components. All necessary hardware and tools are included.

1. Unpack all components and lay them out on a clean, flat, non-abrasive surface.
2. Identify the main frame sections, backrest, seat, armrests, and wheels.
3. Attach the backrest to the main frame using the provided bolts and washers. Do not fully tighten yet.
4. Connect the seat section to the main frame, ensuring proper alignment. Secure with bolts and washers.
5. Attach the armrests to both sides of the chair frame.
6. Install the wheels onto the designated axle points at the rear of the chair.
7. Once all components are loosely assembled, gradually tighten all bolts using the included Allen wrench. Ensure the chair is stable and all connections are secure.



Image 2: Product dimensions and backrest adjustment levels.

5. Operating Instructions

5.1 Backrest Adjustment

The chaise lounge features a 5-position adjustable backrest, allowing you to customize your comfort for various activities such as napping, reading, or relaxing. To adjust the backrest:

1. Slightly lift the backrest to disengage it from its current position.
2. Move the backrest to the desired angle.
3. Lower the backrest until it securely locks into one of the five available notches. Ensure it is stable before applying full weight.



Image 3: Detail of the 5-level backrest adjustment.

5.2 Moving the Chaise Lounge

Equipped with movable wheels and a portable handle, these chaise lounge chairs are designed for easy relocation. To move the chair:

1. Locate the portable handle at the head of the chair.
2. Slightly lift the handle end of the chair, allowing the wheels at the opposite end to engage with the ground.
3. Roll the chair to your desired location, such as poolside, backyard, or garden.



Image 4: Portable handle and movable wheels for effortless movement.

6. Maintenance

The LUE BONA chaise lounge chairs are constructed from HDPS (High-Density Polystyrene) material, known for its durability and low maintenance requirements. This material resists fading, cracking, and peeling, and does not require regular sealing.

6.1 Cleaning

To clean your chaise lounge chairs:

- Wipe down the surfaces with a soft cloth and mild soap and water solution.
- Rinse thoroughly with clean water to remove any soap residue.
- For stubborn dirt, a soft brush can be used. Avoid abrasive cleaners or harsh chemicals, as these may damage the HDPS material.
- Allow the chairs to air dry completely before use.



Image 5: HDPS material benefits and cleaning illustration.

6.2 Storage

While designed for outdoor environments, storing the chairs indoors or covering them during prolonged periods of harsh weather (e.g., heavy snow, extreme temperatures) can extend their lifespan and maintain their appearance.

7. Troubleshooting

If you encounter any issues with your LUE BONA chaise lounge chairs, please refer to the following common solutions:

- **Chair feels wobbly:** Ensure all assembly bolts are fully tightened. Check for any uneven ground surfaces.
- **Backrest not adjusting smoothly:** Inspect the adjustment mechanism for any obstructions. Ensure the backrest is lifted sufficiently before attempting to change positions.
- **Difficulty moving with wheels:** Check if the wheels are clear of debris. Ensure the chair is lifted correctly to engage the wheels.

For issues not resolved by the above, please contact LUE BONA customer support.

8. Specifications

Brand	LUE BONA
Model Number	500*2
Product Dimensions	78.9"D x 27.9"W x 18"H
Material	HDPS (High-Density Polystyrene)
Backrest Positions	5
Features	Adjustable Backrest, Movable Wheels, Foldable
Indoor/Outdoor Usage	Outdoor
Unit Count	2.0 Count

9. Warranty and Support

LUE BONA provides a 3-year warranty for these outdoor chaise lounge chairs, covering manufacturing defects under normal use. For warranty claims, technical support, or any inquiries, please contact LUE BONA customer service through your purchase platform or the official LUE BONA website.
Please retain your proof of purchase for warranty validation.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C4Z498G3

More documents and user manuals: **https://manuals.plus/**