Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

MINISO XS66

MINISO Hello Kitty Classic Series TWS Earphones Model XS66 User Manual

Wireless Earbud Headphones

1. Introduction

Thank you for choosing the MINISO Hello Kitty Classic Series TWS Earphones Model XS66. These wireless earbuds are designed to provide a high-fidelity audio experience with the convenience of Bluetooth connectivity. This manual will guide you through the setup, operation, and maintenance of your new earphones to ensure optimal performance and longevity.

2. Package Contents

- MINISO Hello Kitty Classic Series TWS Earphones (Left and Right)
- Charging Case
- USB Charging Cable
- User Manual

3. Product Overview

The MINISO Hello Kitty Classic Series TWS Earphones feature a compact and ergonomic design, housed in a distinctive Hello Kitty-themed charging case. The case not only protects your earphones but also charges them on the go.



Figure 1: The pink, circular charging case for the Hello Kitty TWS earphones. The case features a charming graphic of Hello Kitty holding a teddy bear, with the 'Hello Kitty' logo elegantly scripted above. This design highlights the product's aesthetic appeal and brand identity.

3.1 Earphone Components

- **Touch Control Area:** For managing music playback, calls, and voice assistant.
- **LED Indicator:** Displays pairing status, battery level, and charging status.
- **Microphone:** For hands-free calls.
- **Charging Contacts:** For charging within the case.

3.2 Charging Case Components

- **Charging Port:** USB port for charging the case.
- **LED Indicator:** Shows the charging status of the case.
- **Earphone Charging Slots:** Securely holds and charges the earphones.

4. Setup

4.1 Charging the Earphones and Case

1. **Initial Charge:** Before first use, fully charge both the earphones and the charging case.
2. **Charging the Earphones:** Place the earphones into their respective slots in the charging case. The earphone LED

indicators will illuminate to show charging.

3. **Charging the Case:** Connect the USB charging cable to the charging port on the case and the other end to a USB power adapter (not included) or a computer USB port. The case's LED indicator will show charging progress.
4. **Full Charge:** Once fully charged, the LED indicators will change or turn off, depending on the model.

4.2 Bluetooth Pairing

1. **Power On:** Open the charging case. The earphones will automatically power on and enter pairing mode. The LED indicator on one earphone will flash, indicating it is ready to pair.
2. **Activate Bluetooth:** On your smartphone or Bluetooth-enabled device, go to the Bluetooth settings and turn on Bluetooth.
3. **Select Device:** In the list of available devices, locate and select "MINISO XS66" (or similar name).
4. **Confirm Pairing:** Once connected, the earphone LED indicator will stop flashing or turn off, and you will hear an audible confirmation.
5. **Reconnect:** After initial pairing, the earphones will automatically connect to the last paired device when taken out of the case, provided Bluetooth is active on the device.

5. Operating Instructions

5.1 Power On/Off

- **Power On:** Open the charging case, and the earphones will power on automatically. Alternatively, press and hold the touch control area on both earphones for approximately 3 seconds.
- **Power Off:** Place the earphones back into the charging case and close the lid. They will power off automatically. Alternatively, press and hold the touch control area on both earphones for approximately 5 seconds.

5.2 Music Playback

- **Play/Pause:** Tap the touch control area on either earphone once.
- **Next Track:** Double-tap the touch control area on the right earphone.
- **Previous Track:** Double-tap the touch control area on the left earphone.
- **Volume Up:** Triple-tap the touch control area on the right earphone.
- **Volume Down:** Triple-tap the touch control area on the left earphone.

5.3 Call Management

- **Answer/End Call:** Tap the touch control area on either earphone once.
- **Reject Call:** Press and hold the touch control area on either earphone for approximately 2 seconds.

5.4 Voice Assistant

- **Activate Voice Assistant:** Press and hold the touch control area on either earphone for approximately 2 seconds (when not on a call).

6. Maintenance

- **Cleaning:** Use a soft, dry, lint-free cloth to clean the earphones and charging case. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use, store the earphones in their charging case to protect them from dust and damage.
- **Avoid Water:** The earphones are not waterproof. Avoid exposure to water, moisture, or extreme temperatures.
- **Charging:** Charge the earphones regularly, even if not in frequent use, to maintain battery health.

7. Troubleshooting

Problem	Possible Cause	Solution
Earphones not pairing	Bluetooth is off on device; earphones not in pairing mode; interference.	Ensure Bluetooth is on. Place earphones in case, close, then reopen to re-enter pairing mode. Move away from other wireless devices.
No sound from earphones	Volume too low; earphones not connected; media paused.	Increase device volume. Check Bluetooth connection. Ensure media is playing.
Earphones not charging	Charging cable faulty; charging contacts dirty; case battery low.	Try a different USB cable/charger. Clean charging contacts on earphones and case. Charge the charging case.
One earphone not working	Low battery; not paired correctly.	Ensure both earphones are charged. Try re-pairing both earphones.

8. Specifications

- **Model Name:** Hello Kitty Classic Series TWS Earphones Model XS66
- **Item Model Number:** 2013164010103
- **Brand:** MINISO
- **Connectivity:** Bluetooth
- **Battery Life (Earphones):** Up to 4 hours (continuous use)
- **Standby Time:** Up to 200 hours
- **Product Dimensions:** 5 x 5 x 5 cm (Charging Case); 6 g (Total Weight)
- **Manufacturer:** MINISO

9. Warranty and Support

MINISO products are manufactured to high-quality standards. For information regarding warranty coverage, technical support, or service inquiries, please refer to the warranty card included with your purchase or visit the official MINISO website. Please retain your proof of purchase for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C58GS3BB

More documents and user manuals: **https://manuals.plus/**