Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun 9577cc

Braun Series 9 PRO+ 9577cc Electric Shaver User Manual

Model: 9577cc | Brand: Braun

1. Important Safety Information

Please read all safety instructions carefully before using your Braun Series 9 PRO+ shaver. Failure to follow these instructions may result in injury or damage to the device.

- Always unplug the shaver and allow it to dry completely before charging.
- Do not use the shaver while it is charging.
- Keep the shaver clean and dry for optimal performance and to prevent bacterial growth.
- Always hold the shaver firmly and carefully during use to avoid accidental cuts.
- Do not use the shaver near water when it is plugged in or charging.

2. Product Overview and What's in the Box

The Braun Series 9 PRO+ 9577cc is designed for an efficient and comfortable shave, even on 1, 3, or 7-day beards. It features advanced shaving elements and a precision trimmer.



Image: Braun Series 9 PRO+ 9577cc Electric Shaver, SmartCare Center, and PowerCase.

Box Contents:



Image: All components included in the Braun Series 9 PRO+ 9577cc package.

- 1x Braun Series 9 PRO+ Electric Shaver
- 1x SmartCare Center 6-in-1 (Cleaning and Charging Station)
- 1x Cleaning Cartridge for SmartCare Center
- 1x PowerCase (Portable Charging Case)
- 1x Charger
- 1x Cleaning Brush

3. Setup

3.1 Initial Charging

Before first use, fully charge your shaver. The shaver has a powerful Li-Ion battery providing up to 60 minutes of shaving time on a full charge.

1. Connect the charger to the shaver or the SmartCare Center.
2. Plug the charger into a power outlet.
3. The battery indicator lights on the shaver will show the charging progress. A full charge typically takes about

1 hour.

3.2 SmartCare Center Setup

The SmartCare Center automatically cleans, lubricates, dries, and charges your shaver.

1. Open the SmartCare Center by pressing the release button.
2. Insert a cleaning cartridge into the base until it clicks into place.
3. Close the SmartCare Center.
4. Place the shaver head-down into the SmartCare Center. Ensure it is securely seated.

4. Operating Instructions

4.1 Shaving

The Series 9 PRO+ is designed for both wet and dry shaving. For best results, shave before washing your face.



Image: Demonstrating effective and gentle shaving with the Braun Series 9 PRO+.

1. Press the On/Off button to start the shaver.

2. Stretch your skin and shave against the direction of hair growth.
3. Hold the shaver at a right angle (90°) to your skin.
4. Apply gentle, even pressure.



Image: The shaver is effective on various beard lengths, from 1 to 7 days.

4.2 Using the ProTrimmer

The integrated ProTrimmer is ideal for precise shaping of sideburns, mustaches, and for trimming longer hairs before shaving.



Image: Using the ProTrimmer for precise grooming.

1. Slide the ProTrimmer release button upwards to extend the trimmer.
2. Use the trimmer to define beard lines, sideburns, or to pre-trim longer hair.
3. After use, push the trimmer back down until it locks into place.



Image: The 5 synchronized shaving elements and the ProTrimmer for superior performance.

5. Maintenance

5.1 Cleaning the Shaver

Regular cleaning ensures optimal performance and hygiene.

Manual Cleaning:

1. Switch off the shaver and remove the foil and cutter block cassette.
2. Rinse the shaver head and the cassette under hot running water until all residues are removed.
3. Use the cleaning brush to remove any stubborn hair from the shaver head. Do not use the brush on the foil.
4. Allow the shaver and cassette to air dry completely before reassembling or storing.

SmartCare Center Cleaning:

For thorough cleaning, lubrication, and drying, use the SmartCare Center.



Image: The SmartCare Center for automatic cleaning and maintenance.

1. Place the shaver head-down into the SmartCare Center.
2. Press the start button on the SmartCare Center to initiate the cleaning cycle.

3. The center will automatically clean, lubricate, dry, and charge the shaver.

5.2 Replacing Shaver Parts

To maintain 100% shaving performance, replace the foil and cutter cassette every 18 months, or when worn.

1. Press the release buttons on the side of the shaver head to remove the old cassette.
2. Snap the new foil and cutter cassette into place until it clicks.

6. Troubleshooting

Problem	Possible Cause	Solution
Shaver does not turn on.	Battery is empty.	Charge the shaver.
Reduced shaving performance.	Foil and cutter cassette is worn or dirty.	Clean the shaver or replace the foil and cutter cassette.
Shaver makes unusual noise.	Hair trapped or damaged part.	Clean the shaver thoroughly. If noise persists, contact customer support.
SmartCare Center not cleaning.	Cleaning cartridge is empty or not inserted correctly.	Replace the cleaning cartridge or ensure it is properly seated.

7. Specifications

Model Number: 9577cc

Power Source: Battery Powered (Li-Ion)

Battery Life: Up to 60 minutes

Charging Time: Approx. 1 hour for full charge

Special Features: Waterproof, ProLift Blade, ProTrimmer, SmartCare Center compatible, PowerCase included

Blade Material: Surgical Steel

Color: Silver

Weight: 1.45 Kilograms

Dimensions (Package): 25.2 x 17.9 x 16 cm

Recommended Use: Beard, Moustache

Manufactured: Germany

8. Warranty and Support

Braun offers a comprehensive warranty for the Series 9 PRO+ 9577cc electric shaver.



Image: Braun offers up to 5 years of warranty.

8.1 Warranty Information

This product is covered by a manufacturer's warranty of up to 5 years. Please register your purchase on the official Braun website to activate and verify your warranty details. The warranty covers defects in materials and workmanship under normal use.

8.2 Customer Support

For further assistance, product information, or to inquire about warranty claims, please visit the official Braun website or contact their customer service department. Refer to the packaging or Braun's official website for specific contact details in your region.

© 2024 Braun. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C5JT8ZQG

More documents and user manuals: **https://manuals.plus/**