Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JOYROOM JR-FC2

JOYROOM JR-FC2 Smart Watch User Manual

Model: **JR-FC2** | Brand: **JOYROOM**

1. Introduction

Thank you for choosing the JOYROOM JR-FC2 Smart Watch. This manual will guide you through the features, setup, and operation of your new device. Please read this manual carefully before using the watch to ensure proper function and safety.

Safety Information

- Do not attempt to disassemble or modify the watch.
- Keep the watch away from extreme temperatures and direct sunlight.
- Avoid exposing the watch to strong impacts or drops.
- Use only the provided charging cable and adapter.
- Consult a medical professional before starting any new exercise regimen, especially if you have pre-existing health conditions.

2. Product Overview

The JOYROOM JR-FC2 Smart Watch is designed to enhance your daily life with its smart features and robust design. Key features include:

- **High-Resolution IPS Display:** 1.32-inch, 360x360 HD resolution for clear and detailed visuals.
- **Rotatable Metal Crown Button:** Easily switch dial styles with a single press, offering convenient navigation.
- **One-Button Wireless Calling:** Smart calling function for high-definition calls in various environments.
- **IP68 Water Resistance:** Designed to withstand water immersion up to 1 meter for 30 minutes without damage.
- **Extensive Sports Modes:** Over 107 sports modes to track and record your workouts in real-time.



Figure 2.1: Front view of the JOYROOM JR-FC2 Smart Watch, showcasing its round display and classic design.



Figure 2.2: Rear view of the watch, highlighting the charging contacts and health sensors.



Figure 2.3: Side view showing the rotatable crown button and microphone/speaker openings.

3. Setup

3.1 Charging the Watch

Before first use, fully charge your smart watch. Connect the magnetic charging cable to the charging contacts on the back of the watch and plug the USB end into a power adapter (5V/1A recommended) or a computer USB port. The watch display will indicate charging status.

3.2 Powering On/Off

- **Power On:** Press and hold the crown button for a few seconds until the screen lights up.
- **Power Off:** Press and hold the crown button, then select 'Power Off' on the screen.

3.3 App Installation and Bluetooth Pairing

1. Scan the QR code in the watch's settings or search for the official JOYROOM app (e.g., 'Joyroom Fit' or similar, refer to packaging for exact name) on your smartphone's app store (Google Play Store for Android, Apple App Store for iOS).
2. Download and install the app.
3. Open the app and follow the on-screen instructions to create an account or log in.
4. Enable Bluetooth on your smartphone.
5. In the app, navigate to 'Device' or 'Add Device' and select your JR-FC2 Smart Watch from the list of available devices.
6. Confirm the pairing request on both your watch and smartphone.

4. Operating Instructions

4.1 Screen Navigation

- **Swipe Down:** Access quick settings (e.g., brightness, DND, battery).
- **Swipe Up:** View notifications.
- **Swipe Left/Right:** Cycle through widgets (e.g., heart rate, activity, weather).
- **Tap:** Select an item or open an application.
- **Press Crown Button:** Return to the watch face or open the app menu.
- **Rotate Crown Button:** Scroll through lists or change watch faces.

4.2 Making and Receiving Calls

Once paired via Bluetooth, you can make and receive calls directly from your watch:

- **Making a Call:** Access the 'Dialer' or 'Contacts' app on your watch, then dial a number or select a contact.
- **Receiving a Call:** When a call comes in, tap the green answer icon on your watch screen.

4.3 Notifications

Ensure notification permissions are enabled in your smartphone's settings and within the JOYROOM app. Notifications from selected apps will appear on your watch screen.

4.4 Sports Modes

The watch supports over 107 sports modes. To start a workout:

1. Open the 'Workout' or 'Sports' app on your watch.
2. Select your desired activity (e.g., running, cycling).
3. Tap 'Start' to begin tracking.
4. During the workout, you can view real-time data such as duration, distance, and heart rate.
5. To end the workout, swipe right or press the crown button, then select 'End' or 'Pause'.

4.5 Water Resistance (IP68)

The JR-FC2 Smart Watch has an IP68 water resistance rating, meaning it is protected against immersion in water

up to 1 meter for 30 minutes. It is suitable for daily use, such as hand washing or light rain. *It is not recommended for swimming, diving, or showering with hot water.*

5. Maintenance

5.1 Cleaning

- Wipe the watch and strap regularly with a soft, dry cloth.
- For stubborn dirt, use a slightly damp cloth and then dry thoroughly.
- Avoid using harsh chemicals or abrasive materials.

5.2 Battery Care

- Charge the watch regularly, even if not in use, to maintain battery health.
- Avoid completely draining the battery frequently.
- Do not expose the watch to extreme temperatures during charging or storage.

5.3 Storage

When not in use for extended periods, store the watch in a cool, dry place away from direct sunlight and moisture.

6. Troubleshooting

If you encounter issues with your JOYROOM JR-FC2 Smart Watch, please refer to the following common solutions:

Problem	Possible Solution
Watch not turning on	Ensure the watch is fully charged. Press and hold the crown button for at least 10 seconds to force a restart.
Bluetooth connection issues	Ensure Bluetooth is enabled on both devices. Restart both the watch and your smartphone. Forget the device in your phone's Bluetooth settings and re-pair. Ensure the watch app is running in the background.
Inaccurate sensor readings (Heart Rate, Pedometer)	Ensure the watch is worn snugly on your wrist, not too tight or too loose. Clean the sensor area on the back of the watch. Note that smart watch sensors are not medical devices and may have slight variations.
Notifications not appearing	Check notification permissions in your smartphone's settings for the JOYROOM app. Ensure notifications are enabled within the JOYROOM app itself for specific applications.
Short battery life	Reduce screen brightness. Disable unnecessary features like 'Always-On Display'. Limit frequent heart rate monitoring. Ensure no background apps are excessively draining power.

If the problem persists, please contact JOYROOM customer support for further assistance.

7. Specifications

Feature	Detail
Model Name	JR-FC2
Brand Name	JOYROOM
Screen Size	1.32 inches
Item Shape	Round
GPS	No
Wireless Communication Standard	Bluetooth
Connectivity Technology	Bluetooth
Special Features	Smart, Wireless, Bluetooth, Display Screen
Memory Storage Capacity	128 MB
Operating System	Android
ASIN	B0C5MMNXW6
Product Dimensions	16.8 x 9.6 x 7.6 cm; 280 grams
First Available Date	May 18, 2023

8. Warranty and Support

For warranty information, please refer to the warranty card included with your product packaging or visit the official JOYROOM website. Keep your purchase receipt as proof of purchase.
For technical support or further inquiries, please contact JOYROOM customer service through their official website or the contact information provided in your product documentation.

© 2024 JOYROOM. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C5MMNXW6

More documents and user manuals: **https://manuals.plus/**