Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Edifier edifier-g1500-black

Edifier G1500 Hecate Gaming Speakers User Manual

Model: edifier-g1500-black

1. Introduction

Thank you for purchasing the Edifier G1500 Hecate Gaming Speakers. These speakers are designed to provide a high-quality audio experience for your computer, gaming console, and other multimedia devices. Featuring versatile connectivity options, dynamic RGB lighting, and optimized sound modes, the G1500 speakers are engineered for immersive sound performance.



Front view of the Edifier G1500 Hecate Gaming Speakers, showcasing their sleek design and illuminated RGB light strips.

2. Product Overview

2.1 Key Features

- **High-Quality Sound:** Dual 2.5-inch full-range drivers with 10 Watts peak power for live stereo sound.
- **RGB Lighting:** 5 various RGB lighting effects to customize your gaming atmosphere.
- **Auto EQ:** Smooth switch to Game/Music/Movie mode for an immersive experience tailored to specific content.
- **Multiple Input:** Connect via Bluetooth 5.3, 3.5mm AUX, and USB input. USB powered for seamless plug-and-play installation.
- **Easy Control:** Intuitive button controls on the speaker for power, volume adjustments, and lighting effect switching. Indicator light colors change with the active connection.


2.2 What's in the Box

- 2 x Edifier G1500 Speakers
- User Manual (this document)


2.3 Component Identification

Familiarize yourself with the various parts and controls of your Edifier G1500 speakers.

Diagram illustrating the various components and connection points of the Edifier G1500 speakers, including indicator light, power/volume buttons, multi-function 'G' button, and input ports.



An internal view highlighting the dual 2.5-inch full-range drivers, capable of 10W peak power for clear and full sound.



Detailed view of speaker features including the fine metal net for robust sound and heat dissipation, simple and comfortable control buttons, anti-slip silicone pads, and an elevation angle design to reduce sound refraction.

3. Setup

Follow these steps to set up your Edifier G1500 speakers.

3.1 Speaker Placement

Place the speakers on a stable, flat surface. For optimal stereo imaging, position them equidistant from your listening position and at ear level.

3.2 Connecting the Speakers

Connect the passive speaker to the active speaker using the provided cable. Ensure a secure connection.

3.3 Power Connection

Connect the USB power cable from the active speaker to a USB power source (e.g., computer USB port, USB wall adapter). The speakers are USB powered.

3.4 Input Connections

The Edifier G1500 speakers support multiple input methods:

- **USB Audio Streaming Input:** Ideal for direct digital audio from your computer.
- **3.5mm AUX Input:** For connecting devices with a standard audio jack.
- **Bluetooth Input:** For wireless audio streaming from Bluetooth-enabled devices.

To switch between input modes, press the Power/Mode button (labeled with a circle and vertical line) once. The

indicator light color will change to reflect the active input:

- Red LED: USB Audio Streaming Input
- Green LED: AUX Input
- Blue LED: Bluetooth Input (solid when connected)

USB Audio Streaming Connection

Illustration of connecting the speakers via USB for audio streaming, indicated by a red LED.

3.5mm AUX Connection

Illustration of connecting the speakers via 3.5mm AUX cable, indicated by a green LED.

Bluetooth Connection

Illustration of pairing the speakers via Bluetooth, indicated by a solid blue LED once connected. Search for "HECATE G1500" on your device.

4. Operating Instructions

Learn how to use the controls and features of your Edifier G1500 speakers.

4.1 Button Functions

Detailed diagram of the speaker's control panel, outlining the functions of each button for power, volume, input mode, sound mode, and lighting effects.


- **Power On/Off (① button):** Press once to switch input mode (USB/AUX/Bluetooth). Press and hold for 2 seconds to power on/off.
- **Volume Up (+ button):** Press once for volume up. Press and hold for 2 seconds for gradual volume increase.
- **Volume Down (- button):** Press once for volume down. Press and hold for 2 seconds for gradual volume decrease.
- **Multi-function 'G' button:**
  - Press once: Switch Sound Mode (Music/Game/Movie).
  - Press and hold for 2 seconds: Turn Light Effects On/Off (retains memory without power cut off).
  - Press twice: Switch Light Effects.

4.2 Sound Modes

The G1500 speakers feature three optimized sound modes:

- **Game Mode:** Effectively enhances gunfire and footsteps for an immersive battlefield experience.
- **Movie Mode:** Provides a broad soundstage and space stereo for cinematic audio.
- **Music Mode:** Offers balanced high, middle, and low frequencies for high-quality listening.

Switch between these modes by pressing the 'G' button once.



Visual representation of the Game Mode, enhancing audio cues for gaming.



Visual representation of the Movie Mode, optimizing audio for cinematic experiences.



Visual representation of the Music Mode, providing balanced audio for music playback.

4.3 RGB Lighting

The speakers feature dynamic RGB lighting with 5 different effects. Use the 'G' button to control the lighting:

- Press and hold 'G' for 2 seconds to turn lighting On/Off.
- Press 'G' twice to cycle through the different lighting effects.

5. Maintenance

To ensure the longevity and optimal performance of your Edifier G1500 speakers, please follow these maintenance guidelines:

- **Cleaning:** Gently wipe the speaker surfaces with a soft, dry cloth. Do not use abrasive cleaners, waxes, or solvents as they may damage the finish.
- **Placement:** Avoid placing speakers in direct sunlight, near heat sources, or in areas with high humidity or dust. Ensure adequate ventilation around the speakers.
- **Handling:** Handle the speakers with care. Avoid dropping them or subjecting them to strong impacts.
- **Power Off:** When not in use for extended periods, it is recommended to power off the speakers.

6. Troubleshooting

If you encounter any issues with your Edifier G1500 speakers, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No sound	Speakers not powered on; Incorrect input mode selected; Volume too low; Loose cable connection.	Ensure speakers are powered on. Press the Power/Mode button to cycle through inputs. Increase volume. Check all cable connections.
Distorted sound	Volume too high; Audio source issue; Speaker placement.	Lower the volume. Test with a different audio source. Adjust speaker placement to avoid obstructions.
Bluetooth pairing issues	Speakers not in pairing mode; Device out of range; Interference.	Ensure speakers are in Bluetooth mode (blue LED). Move device closer to speakers. Avoid strong electromagnetic interference.
RGB lights not working	Lights turned off; Malfunction.	Press and hold the 'G' button for 2 seconds to toggle lights. If issue persists, contact support.

If the problem persists after trying these solutions, please contact Edifier customer support for further assistance.

7. Specifications

Feature	Specification
Model Name	edifier-g1500-black
Speaker Type	Multimedia
Compatible Devices	Desktop, Laptop, Smartphone, Tablet, MP3 Player
Unit Count	1.0 Count (2 speakers)
Surround Sound Channel Configuration	2.0
Included Components	2 x Speaker

Feature	Specification
Item Weight	1.33 Kilograms (2.92 pounds)
Is Waterproof	False
Warranty Type	Limited
Control Method	Touch
Wireless Communication Technology	Bluetooth
Speaker Size	2.5 Inches
Power Source	DC power supply (USB powered)
Signal-to-Noise Ratio	60 dB
Woofer Diameter	2.5 Inches
Audio Driver Type	Dynamic Driver
Bluetooth Range	100 Meters (approx. 30m barrier-free transmission)
Number of Microphones	1
Subwoofer Connectivity Technology	Wireless (N/A for G1500, likely for G1500 MAX)
Connectivity Protocol	Bluetooth
Includes MP3 player?	No
Series Number	1500
UPC	875674007347
Indoor/Outdoor Usage	Indoor
Manufacturer	Edifier
Product Dimensions	4.8 x 4.1 x 6.5 inches
Date First Available	July 9, 2023
Speaker Maximum Output Power	10 Watts
Connectivity Technology	Bluetooth
Audio Output Mode	Stereo
Mounting Type	Tabletop Mount

8. Warranty and Support

8.1 Warranty Information

The Edifier G1500 speakers come with a Limited Warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions. Keep your purchase receipt as proof of purchase for warranty claims.

8.2 Customer Support

For technical support, troubleshooting assistance, or warranty inquiries, please contact Edifier customer service. You can find contact information on the official Edifier website or through the retailer where you purchased the product.

Manufacturer: Edifier

Online Store: Visit the Edifier Store on Amazon

© 2025 Edifier. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C61L1JW8

More documents and user manuals: **https://manuals.plus/**