**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## Braun IS1514VI

# Braun CareStyle 1 Pro IS1514 VI Steam Iron

Instruction Manual

Model: IS1514VI | Brand: Braun

## 1. Introduction

Thank you for choosing the Braun CareStyle 1 Pro IS1514 VI Steam Iron. This manual provides essential information for the safe and efficient use of your appliance. Please read these instructions carefully before first use and keep them for future reference.



Figure 1.1: The Braun CareStyle 1 Pro Steam Iron with its base unit and 1.7L water tank.

## 2. Safety Instructions

Always observe the following basic safety precautions when using your steam iron:

- Ensure the voltage indicated on the appliance corresponds to your mains voltage.
- Do not immerse the iron or base unit in water or other liquids.
- Do not leave the iron unattended while it is connected to the mains supply.
- Keep the appliance out of reach of children.
- Always unplug the iron from the electrical outlet when filling with water, emptying, or when not in use.
- Do not operate the iron with a damaged cord or plug, or if the iron has been dropped or damaged.
- Use the iron only for its intended household use.
- The hot soleplate and steam can cause burns. Handle with care.

## 3. Product Overview

The Braun CareStyle 1 Pro IS1514 VI is a powerful steam iron designed for efficient and effortless ironing. Key components include:

- **Iron Unit:** Features the FreeGlide 3D soleplate and precision heat dial.
- **Base Unit:** Houses the 1.7L water tank and steam generator.
- **Water Tank:** Removable for easy refilling.
- **Steam Hose:** Connects the iron to the base unit.




Figure 3.1: The steam iron and its base unit set up on an ironing board, ready for use.




Figure 3.2: Close-up view of the FreeGlide 3D SuperCeramic soleplate with precision tip.

## 4. Setup

1. **Unpacking:** Carefully remove the appliance from its packaging. Retain the packaging for storage or future transport.
2. **Positioning:** Place the base unit on a stable, heat-resistant surface, such as an ironing board designed for steam generators.
3. **Filling the Water Tank:**
    - Remove the removable 1.7L water tank from the base unit.
    - Fill the tank with tap water up to the 'max' indicator. For areas with very hard water, consider using a mix of tap water and distilled water (50/50).
    - Replace the water tank securely into the base unit.




Figure 4.1: Removing the 1.7L water tank for refilling.

4. **Connecting to Power:** Plug the power cord into a suitable electrical outlet.

## 5. Operating Instructions

Once set up, your Braun CareStyle 1 Pro is ready for use. Allow a few moments for the iron to heat up and generate steam after switching on.

### 5.1. Precision Heat Dial

The iron features a precision heat dial with 4 setting options to simplify ironing for various fabric types:

- **Level 1:** Synthetics
- **Level 2:** Wool, Silk, and Polyester
- **Level 3:** Cotton and Linen
- **Level 4:** Max (for stubborn creases and heavy fabrics)

Select the appropriate temperature setting based on the fabric care label.

### 5.2. FreeGlide 3D Technology

The unique FreeGlide 3D soleplate, inspired by a snowboard, ensures 360° glideability. This allows the iron to effortlessly glide backward over obstacles such as buttons, pockets, and zippers, preventing snagging and making ironing faster and smoother.




Figure 5.1: The FreeGlide 3D soleplate effortlessly glides over buttons.

## 5.3. Doublesteam Technology

This technology provides more than double the steam output compared to traditional steam irons, significantly reducing ironing time by up to half. Press the steam trigger on the iron handle to activate continuous steam.

## 5.4. Vertical Steam

The powerful continuous steam system enables effortless vertical steaming of hanging garments, curtains, and drapes. Hold the iron vertically a few centimeters away from the fabric and press the steam trigger.



Figure 5.2: Demonstrating vertical steam for refreshing hanging clothes.

### 5.5. Auto-Off Function

For safety and energy saving, the Auto-Off function automatically switches off the appliance after 10 minutes of inactivity.

## 6. Maintenance and Cleaning

Regular maintenance ensures optimal performance and extends the lifespan of your iron.

### 6.1. Descaling System

The iron features a quick and efficient descaling system for long-lasting performance. Refer to the specific instructions in your full user manual for detailed descaling procedures. Regular descaling prevents mineral buildup and ensures consistent steam output.

### 6.2. Cleaning the Soleplate

To clean the SuperCeramic soleplate, ensure the iron is unplugged and cool. Wipe the soleplate with a damp cloth and a non-abrasive liquid cleaner if necessary. Do not use abrasive pads or harsh chemicals.

### 6.3. Storing the Iron

After use, unplug the iron and allow it to cool completely. Empty any remaining water from the tank. Store the iron and base unit in a dry, safe place.

## 7. Troubleshooting

If you encounter issues with your Braun CareStyle 1 Pro, refer to the table below for common problems and solutions.

| Problem | Possible Cause | Solution |
|---|---|---|
| No steam output | Water tank empty; Iron not hot enough; Descaling needed. | Refill water tank; Wait for iron to heat up; Perform descaling procedure. |

| Problem | Possible Cause | Solution |
|---|---|---|
| Water leaking from soleplate | Temperature too low for steam; Overfilling water tank. | Increase temperature setting; Do not overfill water tank. |
| Iron not heating up | Not plugged in; Power outlet fault; Auto-Off activated. | Check power connection; Test outlet with another appliance; Reset by unplugging and replugging. |
| Poor glide on fabrics | Soleplate is dirty. | Clean the soleplate as per maintenance instructions. |

If the problem persists after trying these solutions, please contact customer support.

## 8. Specifications

| Feature | Specification |
|---|---|
| Brand | Braun |
| Model Number | IS1514VI |
| Color | Purple/White |
| Product Dimensions (L x W x H) | 36 x 18 x 0.1 cm |
| Item Weight | 2.8 Kilograms |
| Power | 2200 Watts |
| Voltage | 240 Volts |
| Water Tank Capacity | 1.7 Liters |
| Steam Pressure | 6 bar |
| Continuous Steam Output | 120 g/min |
| Soleplate Type | SuperCeramic with FreeGlide 3D Technology |
| Auto-Off Function | Yes (after 10 minutes of inactivity) |
| Special Features | Doublesteam Technology, Vertical Steam, Easy Lock System for transport, Digital Anti-drip System, Silent Technology |

## 9. Warranty and Support

Information regarding the specific warranty period and detailed support contacts for the Braun CareStyle 1 Pro IS1514 VI is not available in the provided product data. Please refer to the warranty card included with your product or visit the official Braun website for the most up-to-date warranty terms and customer service information in your region.

For spare parts availability, please consult the official Braun service centers or authorized retailers.

© 2023 Braun. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.


## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question


---


**Open the live page**

**https://manuals.plus/asin/B0C61VJMP8**

More documents and user manuals: **https://manuals.plus/**