Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Skullcandy 2SKSK1846B0L2

Skullcandy Terrain Mini Wireless Bluetooth Speaker User Manual

Model: 2SKSK1846B0L2

Introduction

Welcome to the Skullcandy Terrain Mini Wireless Bluetooth Speaker user manual. This compact and powerful speaker is designed for adventure, featuring IPX7 waterproofing, robust bass, and a long-lasting 14-hour battery. With its Multi-Link technology, you can connect up to 99 Skullcandy speakers for an expansive audio experience. This guide will walk you through setting up, operating, maintaining, and troubleshooting your new speaker.



The Skullcandy Terrain Mini Wireless Bluetooth Speaker in black, showcasing its compact design and integrated wrist strap.

What's in the Box

Your Skullcandy Terrain Mini package includes the following items:

- SKDY Terrain™ Mini Wireless Speaker
- 1 x 3FT C-to-A Charging Cable
- 1 x Wrist Strap
- 1 x User Manual (this document)



The Skullcandy Terrain Mini speaker alongside its included 3ft C-to-A charging cable and nylon wrist strap.

Setup

Initial Charge

Before first use, fully charge your Terrain Mini speaker. Connect the included 3ft C-to-A charging cable to the USB-C port on the speaker and a compatible USB power source. The LED indicator will show charging status. A full charge

provides up to 14 hours of continuous playtime.

Power On/Off

- **To Power On:** Press and hold the Power button (usually marked with a circle or power symbol) for a few seconds until you hear an audible cue and the LED indicator lights up.
- **To Power Off:** Press and hold the Power button again for a few seconds until you hear an audible cue and the LED indicator turns off.

Bluetooth Pairing

To connect your Terrain Mini speaker to a Bluetooth device:

1. Ensure the speaker is powered on.
2. The speaker will automatically enter pairing mode if it's not connected to a device. If it is connected, press and hold the Bluetooth button (usually marked with a Bluetooth symbol) to enter pairing mode. The LED indicator will flash to show it's ready to pair.
3. On your device (smartphone, tablet, etc.), go to Bluetooth settings and select "Skullcandy Terrain Mini" from the list of available devices.
4. Once connected, the speaker will provide an audible confirmation, and the LED indicator will change to a solid light.



A close-up view of the Skullcandy Terrain Mini speaker's top and side, showing the power button, Bluetooth pairing button, volume controls, and USB-C charging port.

Operating Your Speaker

Basic Controls

The Skullcandy Terrain Mini features intuitive controls for easy operation:

Button/Action	Function
Power Button (Press & Hold)	Power On/Off
Bluetooth Button (Press & Hold)	Enter Bluetooth Pairing Mode

Button/Action	Function
Volume + Button (Short Press)	Increase Volume
Volume - Button (Short Press)	Decrease Volume
Play/Pause Button (Single Press)	Play/Pause Audio
Play/Pause Button (Double Press)	Next Track
Play/Pause Button (Triple Press)	Previous Track

Multi-Link Pairing (Party Mode)

The Terrain Mini supports Skullcandy's Multi-Link technology, allowing you to connect up to 99 compatible Skullcandy speakers for a synchronized audio experience. This is ideal for larger spaces or gatherings.

1. Ensure all speakers you wish to link are powered on and not currently paired to a device.
2. Pair your primary Terrain Mini speaker to your audio source via Bluetooth as described in the 'Bluetooth Pairing' section.
3. On the primary speaker, press the Multi-Link button (refer to your speaker's specific button layout, often indicated by a chain link icon). The speaker will enter Multi-Link pairing mode.
4. On each additional Skullcandy speaker you wish to link, press its Multi-Link button. They will search for the primary speaker.
5. Once connected, all linked speakers will play audio from your primary source simultaneously.



Multiple Skullcandy Terrain speakers (Mini, standard, and XL) connected via Multi-Link technology, demonstrating the ability to synchronize audio across up to 99 devices.

Maintenance

Waterproofing (IPX7)

The Skullcandy Terrain Mini is IPX7 waterproof, meaning it can be submerged in up to 1 meter of water for 30 minutes. This makes it suitable for use near pools, beaches, or in the shower. Ensure the charging port cover is securely closed before exposing the speaker to water.



The Skullcandy Terrain Mini speaker highlighting its IPX7 waterproof rating, submerged in water.

Cleaning

To clean your speaker, use a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the speaker's finish or components. Ensure the speaker is dry before charging.

Storage

When not in use for extended periods, store the speaker in a cool, dry place away from direct sunlight and extreme temperatures. It is recommended to charge the battery periodically to maintain its health.

Troubleshooting

If you encounter issues with your Skullcandy Terrain Mini speaker, please refer to the following common problems and solutions:

- **Speaker Not Turning On:**
  Ensure the battery is charged. Connect the speaker to a power source using the provided USB-C cable and allow it to charge for at least 30 minutes before attempting to power on again.
- **Cannot Pair Bluetooth:**
  Make sure the speaker is in pairing mode (LED flashing). Turn off Bluetooth on your device and turn it back on. Try forgetting the speaker from your device's Bluetooth list and re-pairing. Ensure no other devices are currently connected to the speaker.
- **No Sound or Low Volume:**
  Check the volume levels on both the speaker and your connected device. Ensure the speaker is properly paired. Try playing audio from a different application or device to rule out source issues.
- **Sound Distortion:**
  Reduce the volume on both the speaker and your device. Move the speaker closer to your Bluetooth device to improve signal strength. Ensure there are no obstructions between the speaker and the device.
- **Multi-Link Not Working:**
  Ensure all speakers are Skullcandy Multi-Link compatible. Make sure only the primary speaker is paired to your audio source. All other speakers should be in Multi-Link pairing mode (not Bluetooth pairing mode). Try resetting all speakers and attempting the Multi-Link process again.
- **Speaker Not Charging:**
  Verify the charging cable is securely connected to both the speaker and the power source. Try a different USB port or power adapter. Ensure the charging port is clean and free of debris.

Specifications

Key technical specifications for the Skullcandy Terrain Mini Wireless Bluetooth Speaker:

Feature	Detail
Model Name	Terrain Mini
Model Number	2SKSK1846B0L2
Brand	Skullcandy
Dimensions (D x W x H)	3.5"D x 3.5"W x 4.1"H
Item Weight	1.37 Pounds
Battery Life	Up to 14 Hours
Waterproof Rating	IPX7 (Submersible up to 1 meter for 30 minutes)
Wireless Communication	Bluetooth
Bluetooth Range	10 Meters
Speaker Maximum Output Power	3 Watts
Frequency Response	30 Hz
Included Components	Speaker, USB-C Charging Cable, Wrist Strap, User Manual

Warranty and Support

The Skullcandy Terrain Mini Wireless Bluetooth Speaker comes with a Limited Warranty. For detailed warranty information, product registration, and technical support, please visit the official Skullcandy website or contact their customer service.

You can find more information and support resources by visiting theSkullcandy Store on Amazon.

© 2024 Skullcandy. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C633H5C4

More documents and user manuals: **https://manuals.plus/**