Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun 51-W1200S-V

Braun Series 5 Men's Shaver 51-W1200S-V User Manual

Model: 51-W1200S-V

1. Important Safety Information

Please read these instructions completely before using the appliance. Keep them for future reference.

- This appliance is suitable for cleaning under running tap water. Do not immerse the appliance in water.
- The appliance is equipped with a special cord set with an integrated Safety Extra Low Voltage power supply. Do not exchange or manipulate any part of it. Otherwise, there is a risk of electric shock.
- Only use the special cord set provided with your appliance.
- Do not use the appliance with a damaged foil or cord.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children unless they are older than 8 and supervised.
- For hygienic reasons, do not share this appliance with other persons.

2. Product Overview

The Braun Series 5 shaver is designed for a close and comfortable shave, featuring advanced technology for optimal performance.

2.1 Components



Figure 1: Braun Series 5 Shaver, stubble trimmer attachment, and travel pouch.

- **Shaver Unit:** The main body of the shaver, featuring the EasyClean system and power button.
- **3-Blade Floating System:** Three independent cutting elements that adapt to facial contours for a deep shave.
- **AI Technology:** Automatically adjusts power based on beard density, reading it 13 times per second.
- **S-shaped Trimmer Blade:** Designed for precise trimming of longer hairs.
- **DeepCatch Foil:** Features 900 mesh patterns for thorough shaving of various beard types.
- **Comfort Inner Blades:** Sharp-angled blades cut 2 microns inward to minimize skin contact and prevent irritation.

2.2 Included Accessories

- Main Shaver Unit
- Stubble Trimmer Attachment
- Foil Protection Cap
- Cleaning Brush
- Travel Pouch
- Dedicated Charging Cord

3. Setup

3.1 Charging the Shaver

Before first use, or when the battery indicator shows low charge, fully charge your shaver.

1. Ensure the shaver is dry before connecting it to the power outlet.
2. Connect the dedicated charging cord to the shaver and then plug it into an AC 100-240V power outlet.
3. The charging indicator lights will illuminate, indicating that the shaver is charging.
4. A full charge takes approximately 1 hour and provides up to 50 minutes of cordless shaving time.
5. Once fully charged, disconnect the shaver from the power outlet.

Note: The shaver can be used cordlessly. Do not use the shaver while it is plugged into the power outlet in a wet environment (e.g., shower or bath).

4. Operating Instructions

4.1 Shaving

The Braun Series 5 shaver can be used for both dry and wet shaving, including in the shower or bath.

1. Press the power button to turn on the shaver.
2. For dry shaving, ensure your skin is clean and dry.
3. For wet shaving, apply shaving foam or gel to your face. The shaver is 100% waterproof.
4. Hold the shaver at a right angle (90°) to your skin and shave against the direction of beard growth.
5. Apply gentle, even pressure. The 3-blade floating system and AI technology will adapt to your facial contours and beard density for an efficient shave.
6. Use the S-shaped trimmer attachment for precise trimming of sideburns or longer hairs as needed.

4.2 Using the Stubble Trimmer Attachment

The stubble trimmer attachment allows for precise styling and trimming of longer hairs.

1. Ensure the shaver is turned off.
2. Remove the shaver foil head by pressing the release buttons on the sides.
3. Attach the stubble trimmer attachment until it clicks into place.
4. Turn on the shaver and use the trimmer to shape your beard or trim longer hairs.
5. After use, turn off the shaver, remove the attachment, and reattach the foil head.

5. Maintenance and Cleaning

Regular cleaning ensures optimal shaving performance and extends the life of your shaver.

5.1 EasyClean System

The EasyClean system allows for quick and easy cleaning without removing the shaver head.

1. Turn on the shaver.
2. Rinse the shaver head under hot running tap water until all residue is removed. You can also use liquid soap.
3. After rinsing, turn off the shaver and shake off excess water.
4. Allow the shaver to air dry completely before storing or re-using.

5.2 Deep Cleaning

For a more thorough cleaning, especially after using shaving foam/gel:

1. Turn off the shaver.

2. Remove the shaver foil head by pressing the release buttons.
3. Tap out any loose hair clippings.
4. Rinse both the shaver head and the shaver body under hot running tap water.
5. Use the provided cleaning brush to remove stubborn hair particles from the cutting elements. Do not use the brush on the foil itself, as this may damage it.
6. Allow all parts to air dry completely before reassembling.

5.3 Replacing Shaver Parts

To maintain 100% shaving performance, replace the shaver foil and cutter cassette when the replacement indicator lights up (if applicable) or approximately every 18 months.

- Replacement parts can be purchased from authorized Braun retailers or online.
- To replace, simply remove the old foil head and snap on the new one.

6. Troubleshooting

If you encounter any issues with your Braun Series 5 shaver, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Shaver does not turn on.	Battery is depleted.	Charge the shaver for at least 1 hour.
Shaver does not provide a close shave.	Foil or cutter cassette is worn out or dirty.	Clean the shaver thoroughly. If performance does not improve, replace the foil and cutter cassette.
Shaver pulls hair or causes irritation.	Foil or cutter cassette is damaged or worn.	Inspect the foil for damage. Replace the foil and cutter cassette if damaged or if it has been used for over 18 months.
Charging indicator lights are not working.	Charging cord is not properly connected or is damaged.	Ensure the charging cord is securely connected to both the shaver and the power outlet. Try a different outlet. If the issue persists, the cord may be damaged and require replacement.

If the problem persists after trying these solutions, please contact Braun customer service for further assistance.

7. Specifications

Feature	Detail
Model Number	51-W1200S-V
Power Source	Rechargeable Battery (Cordless operation)
Rated Voltage	AC 100-240V
Charging Time	Approx. 1 hour for full charge
Battery Life	Approx. 50 minutes of cordless use

Feature	Detail
Waterproof	100% Waterproof (Wet & Dry use)
Blade Material	Stainless Steel
Head Type	Foil
Color	White
Item Weight	173 g
Package Dimensions	25.4 x 13.8 x 6.7 cm

8. Warranty and Support

Braun products are manufactured to the highest standards of quality, safety, and reliability. This product is covered by a Braun warranty.

- For detailed warranty information, please refer to the warranty card included with your product or visit the official Braun website.
- For customer support, service, or to purchase replacement parts, please visit the Braun official website or contact their authorized service centers.
- You can find more information and support at the Braun Store on Amazon.

© 2023 Braun. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C7GG37QV

More documents and user manuals: **https://manuals.plus/**