Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

sandoo SC1070

Sandoo SC1070 Spin Steam Mop Instruction Manual

Model: SC1070 | Brand: Sandoo

Introduction

Thank you for choosing the Sandoo SC1070 Spin Steam Mop. This all-in-one steam and scrub mop is designed to provide powerful, chemical-free cleaning for various sealed hard floor surfaces, including hardwood, laminate, marble, and tile. It also converts into a versatile handheld steam cleaner for tackling different cleaning tasks around your home. Please read this manual thoroughly before use to ensure safe and optimal operation.



Figure 1: Sandoo SC1070 Spin Steam Mop and included accessories.

Safety Information

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, or injury. This appliance is for household use only.

- Do not leave the steam mop unattended while powered on.
- Use only distilled or demineralized water in the water tank to prevent mineral buildup and ensure optimal performance.
- Do not add cleaning solutions, perfumes, or other chemicals to the water tank, as this may damage the appliance or create hazardous fumes.
- Ensure the power cord is not damaged and is kept away from hot surfaces.
- Always unplug the appliance before filling or emptying the water tank, attaching or removing accessories, or when not in use.
- Do not direct steam at people, pets, or electrical appliances.

- Allow the appliance to cool down completely before storing.
- Keep out of reach of children.

Package Contents

Verify that all items are present in your package:

- Spin Steam Mop Main Unit
- Handheld Steam Cleaner with Multiple Nozzles
- Detachable 330mL Water Tank
- 4 Dirt Grip Soft Scrub Washable Pads

Product Overview

Familiarize yourself with the main components of your Sandoo SC1070 Steam Mop.



Figure 2: Key features including 3 Steam Modes, Motor Switch, Detachable Water Tank, and Rotatable Wire Hook.

The unit features a control panel with buttons for selecting steam modes and activating the motor for the rotating pads. The water tank is conveniently detachable for easy refilling. The mop head is equipped with two rotating pads for enhanced cleaning.



Figure 3: The steam mop can be converted into a handheld unit for versatile cleaning with various nozzles.

Setup

Assembly

Assemble the steam mop by connecting the main components. Ensure all connections are secure for proper operation.

▶ **Watch video online**
SC1070 Spin Scrubber Steam Mop

Video 1: Assembly and basic operation of the Sandoo SC1070 Spin Steam Mop. This video demonstrates how to connect the mop head, handle, and fill the water tank.

Filling the Water Tank

The detachable water tank has a capacity of 330mL. For best results and to prolong the life of your appliance, use distilled or demineralized water.

1. Remove the water tank from the main unit by pressing the release button and pulling it out.
2. Unscrew the cap at the bottom of the water tank.
3. Fill the tank with distilled or demineralized water. Do not overfill.
4. Securely replace the cap.
5. Reinsert the water tank into the main unit until it clicks into place.

Attaching Cleaning Pads

The Sandoo SC1070 comes with 4 Dirt Grip Soft Scrub Washable Pads. These pads attach easily to the rotating discs on the mop head.

1. Ensure the mop head is clean and free of debris.
2. Align the cleaning pads with the hook-and-loop fasteners on the bottom of the rotating discs.
3. Press firmly to secure the pads in place.



Figure 4: The mop head with easily attachable and detachable cleaning pads.

Operating Instructions

Powering On and Steam Modes

Once assembled and filled, plug the steam mop into a standard electrical outlet. The unit will begin to heat up, typically reaching operating temperature in 20 seconds.

- **3 Steam Modes:** The Sandoo SC1070 offers three steam modes for different cleaning needs:
  - **Light:** For quick cleanups and delicate surfaces.
  - **Normal:** For everyday use on most hard floors.
  - **Deep:** For stubborn messes and tough stains.
- Press the 'Select' button on the control panel to cycle through the steam modes. The indicator light will change color to show the selected mode.
- **Independent Motor Switch:** Press the 'Motor Button' to activate the rotating pads for enhanced scrubbing action. This can be used independently of the steam function.

▶ **Watch video online**
Steaming Test in Factory

Video 2: Demonstration of steam output during factory testing, highlighting the rapid heat-up time.

Cleaning Hard Floors

The spinning action of the pads combined with powerful steam provides effective cleaning. Move the mop slowly over the surface to allow the steam to penetrate and the pads to scrub.



Figure 5: The steam mop is safe and effective for sealed hardwood, laminate, marble, and tile floors.

Using as a Handheld Steam Cleaner

The main unit detaches from the mop handle to become a portable handheld steam cleaner. Attach the desired accessory for specific cleaning tasks.

▶ **Watch video online**
SC1070 Multipurpose Steam Cleaner

Video 3: Demonstration of the Sandoo SC1070's versatility as a handheld steam cleaner, showcasing various attachments for different cleaning applications.

The handheld unit is ideal for cleaning grout, kitchen surfaces, bathroom fixtures, and more. Select the appropriate nozzle for the task.



Figure 6: Examples of handheld steam cleaning applications using different accessories.

Maintenance

Cleaning Pads

The Dirt Grip Soft Scrub Washable Pads are reusable and machine washable. After each use, remove the pads from the mop head.

- Machine wash the pads with warm water and liquid detergent.
- Do not use bleach or fabric softeners, as these can damage the pads.
- Tumble dry on low heat or air dry.

Water Tank Care

To prevent mineral buildup, especially if using tap water (though distilled is recommended):

- Empty any remaining water from the tank after each use.
- Periodically, clean the water tank by rinsing it with a mixture of water and white vinegar.
- Rinse thoroughly with clean water before refilling.

General Cleaning

Wipe down the exterior of the steam mop with a damp cloth. Do not immerse the unit in water.

Troubleshooting

Problem	Possible Cause	Solution
No steam output	Water tank empty; Unit not heated; Mineral buildup.	Refill water tank; Wait 20 seconds for heating; Descale unit.
Pads not rotating	Motor switch off; Improper assembly of mop head.	Press motor button; Ensure mop head is securely connected.
Water leaking from unit	Water tank cap not secure; Tank not properly seated.	Tighten water tank cap; Reinsert tank until it clicks.
Floors remain wet/streaky	Too much steam; Dirty pads; Using cleaning solutions.	Use lower steam mode; Clean or replace pads; Use only water.

Specifications

- **Model Name:** SC1070
- **Power Source:** AC
- **Voltage:** 120 Volts (AC)
- **Wattage:** 1300 watts
- **Tank Volume:** 330 Milliliters
- **Maximum Temperature:** 130 Degrees Celsius (266°F)
- **Heat Up Time:** 20 Seconds
- **Steam Duration:** 12-18 Minutes
- **Item Weight:** 3.2 Kilograms (7.04 pounds)
- **Product Dimensions:** 12.48 x 6.3 x 49.61 inches
- **Special Features:** Over 150 Scrubs Per Minute, Chemical-Free clean, 3 Steam Modes, Independent Motor Switch
- **Surface Recommendation:** Floor, Upholstery, Carpet (with appropriate accessories)

Warranty and Support

Your Sandoo SC1070 Spin Steam Mop comes with a one-year warranty. For any questions, concerns, or after-sales service, please contact Sandoo customer support through the email address or phone number provided on the product packaging or original purchase documentation. We are committed to maximizing your interests and ensuring your satisfaction.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C9BQJ37W

More documents and user manuals: **https://manuals.plus/**