Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

onerbl TASVAC S8 Series Adapter

onerbl AC/DC Adapter Instruction Manual

For TASVAC S8 Series Cordless Stick Vacuum Cleaners (Models S8, S8P, S800, S810, S820, S850, S860, S870, S880, S890)

1. Introduction

Thank you for choosing the onerbl AC/DC Adapter. This adapter is designed as a high-quality replacement power supply for your TASVAC S8 Series cordless stick vacuum cleaner. Please read this manual carefully before use to ensure proper operation and safety.

2. Product Overview and Features

The onerbl AC/DC Adapter provides reliable power for charging your TASVAC S8 Series vacuum cleaner. Key features include:

- **High-Quality Replacement:** Engineered to meet or exceed original specifications.
- **Universal Input:** Supports AC 100-240V, 50/60Hz, making it suitable for worldwide use.
- **Advanced Safety Features:** Equipped with a smart chip for multiple protections.
- **Durable Construction:** Features a robust design with copper wire and a PVC jacket for longevity.
- **Extended Cable Length:** Provides a convenient 76-inch (approximately 6.33 feet) cable for flexible placement.



Image 2.1: The onerbl AC/DC Adapter, showing its compact design with approximate dimensions of 3.1 inches (length), 2.1 inches (width), and 1.2 inches (thickness).



Image 2.2: Illustration of the adapter's smart chip technology, providing short-circuit, over-voltage, and over-current protection for enhanced safety.




Image 2.3: Detail showing the durable construction of the adapter's cable, featuring internal copper wires and a protective PVC jacket.

3. Specifications

Attribute	Value

Brand	onerbl
Input Voltage	AC 100-240V, 50/60Hz
Output Voltage/Current	35V, 550mA
Compatibility	TASVAC S8 Series (S8, S8P, S800, S810, S820, S850, S860, S870, S880, S890)
Item Weight	8 Ounces
Cable Length	76 inches (approx. 6.33 feet)
Manufacturer	Shenzhen Waweis Technology Co., Ltd

4. Setup

1. **Unpack the Adapter:** Carefully remove the onerbl AC/DC adapter from its packaging.
2. **Inspect for Damage:** Before use, visually inspect the adapter and its cable for any signs of damage. Do not use if damaged.
3. **Connect to Vacuum:** Locate the charging port on your TASVAC S8 Series vacuum cleaner. Insert the adapter's DC output plug firmly into the vacuum's charging port.
4. **Plug into Power Outlet:** Insert the AC input plug of the adapter into a standard wall power outlet (AC 100-240V). Ensure the outlet is easily accessible.



Image 4.1: The onerbl AC/DC adapter correctly plugged into a wall power outlet, ready for use.

5. Operating Instructions

Once the adapter is properly connected to both the vacuum cleaner and a power outlet, your TASVAC S8 Series vacuum cleaner will begin charging. Refer to your vacuum cleaner's manual for specific charging indicators (e.g., LED lights) and expected charging times.

- Ensure the adapter is securely connected during the entire charging process.
- Do not interrupt the charging cycle unnecessarily.
- Always disconnect the adapter from the power outlet when not in use or when charging is complete.

6. Safety Information

To prevent injury or damage to the product, please observe the following safety precautions:

- **Indoor Use Only:** This adapter is designed for indoor use in dry locations. Do not expose to water, rain, or

excessive humidity.

- **Proper Voltage:** Only connect the adapter to power outlets within the specified input voltage range (AC 100-240V).
- **Avoid Overloading:** Do not overload power outlets or extension cords.
- **Handle with Care:** Do not drop, disassemble, or attempt to repair the adapter. Refer servicing to qualified personnel.
- **Keep Away from Children:** Store the adapter out of reach of children.
- **Ventilation:** Ensure adequate ventilation around the adapter during use to prevent overheating. Do not cover the adapter.
- **Disconnect Safely:** Always grasp the plug, not the cord, when disconnecting from a power outlet.



Image 6.1: The product label on the adapter, indicating input specifications and the crucial safety warning: "CAUTION INDOOR USE ONLY."

7. Maintenance

The onerbl AC/DC Adapter requires minimal maintenance:

- **Cleaning:** Disconnect the adapter from the power outlet and the vacuum cleaner before cleaning. Use a soft, dry cloth to wipe the surface. Do not use liquid cleaners or solvents.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly winding the cable to prevent damage.
- **Cable Inspection:** Periodically check the power cord and plug for any signs of wear, cuts, or damage. Replace the adapter if any damage is found.

8. Troubleshooting

If you encounter issues with your onerbl AC/DC Adapter, try the following steps:

- **No Power/Charging:**
  - Ensure the adapter is securely plugged into both the wall outlet and the vacuum cleaner.
  - Check if the wall outlet is functional by plugging in another device.
  - Inspect the adapter cable and connectors for any visible damage.
- **Overheating:**
  - Ensure the adapter is not covered and has adequate ventilation.
  - Disconnect the adapter and allow it to cool down. If overheating persists, discontinue use.
- **Loose Connection:**
  - Verify that the DC output plug fits snugly into the vacuum's charging port.
  - Avoid pulling or tugging on the cable during use.

If these steps do not resolve the issue, please contact customer support.

9. Warranty and Support

This onerbl AC/DC Adapter is manufactured by Shenzhen Waweis Technology Co., Ltd. For warranty information or technical support, please refer to the documentation provided with your purchase or contact your retailer. Keep your purchase receipt as proof of purchase.

© 2023 onerbl. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C9HG2PKK

More documents and user manuals: **https://manuals.plus/**