Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

iROCKER Pop Up Cooler

iROCKER Collapsible Pop-Up Cooler Instruction Manual

Model: Pop Up Cooler
Brand: iROCKER

Product Overview

The iROCKER Collapsible Pop-Up Cooler is designed for portability and convenience, keeping your food and drinks cold during various outdoor adventures. Its lightweight, insulated design and versatile attachment options make it ideal for paddleboarding, beach days, camping, and more.

Key Features:

- **Easy Storage & Portability:** Folds flat for compact storage and effortless transport.
- **Soft Padded Handles:** Ensures a comfortable grip for easy carrying.
- **Paddleboard Compatible:** Securely clips onto your paddleboard's D-rings.
- **Insulated & Lightweight:** Keeps contents cold for hours without adding significant weight.
- **Durable & Versatile:** Built to withstand outdoor conditions for various activities.

What's in the Box

- Collapsible Cooler (1)
- Soft Padded Handles (2)
- Functional Mini Grip (1)

Setup Instructions

1. Unfolding the Cooler

To prepare your iROCKER cooler for use, simply release the elastic band that holds it in its collapsed state. The cooler will naturally spring into its upright, cylindrical shape. Ensure the base is fully extended and stable.



Image: The iROCKER cooler in its collapsed, flat state, secured by an elastic band.

2. Adjusting Internal Dividers

The cooler features adjustable internal dividers to help organize your items. Position these dividers as needed to separate drinks from food or other accessories. The dividers attach via hook-and-loop fasteners inside the main compartment.




iROCKER

Image: The iROCKER cooler with its main lid unzipped, revealing the insulated interior and adjustable dividers.

3. Attaching the Shoulder Strap

For easy transport, attach the included padded shoulder strap to the D-rings located on the sides of the cooler. Adjust the strap length for comfortable carrying, whether over your shoulder or across your body.



Image: A person walking, carrying the iROCKER cooler over their shoulder using the attached strap.

Operating Instructions

1. Filling the Cooler

Open the main zippered lid to fill the cooler with your desired food and beverages. For best insulation, use ice packs or frozen water bottles instead of loose ice, especially if you want to keep items dry. The 28-liter capacity allows for ample

storage.

2. Accessing Contents with Quick-Access Flap

The cooler features a convenient flap-style lid with hook-and-loop closure on the top. This allows for quick and easy access to items without needing to fully unzip the main compartment, helping to retain cold air.



Image: The iROCKER cooler with its small, square quick-access flap open on the main lid.

3. Attaching to a Paddleboard

Utilize the bungee cords and clips on the bottom of the cooler to securely attach it to the D-rings or existing bungee system on your paddleboard. Ensure the cooler is firmly fastened to prevent movement during your water activities.



Image: A close-up view of the iROCKER cooler securely attached to the deck of a paddleboard using its integrated bungee system.

4. Using the Bottle Opener

A functional mini grip with an integrated bottle opener is included. Attach it to one of the cooler's loops for convenient access to open bottled beverages during your outings.



Image: The back of the iROCKER cooler, highlighting the various attachment points and the included bottle opener hanging from a loop.

Maintenance and Care

Cleaning Instructions

To clean your iROCKER cooler, use mild soap and water. Wipe down both the interior and exterior surfaces. After cleaning, ensure the cooler is thoroughly air-dried before storing to prevent mold or mildew buildup.

Collapsing for Storage

Once empty and dry, gently push down on the top of the cooler to collapse it flat. Secure it with the elastic band to maintain its compact form for easy storage in small spaces.



Image: The iROCKER cooler in its collapsed, flat state, secured by an elastic band, ready for compact storage.

Troubleshooting

- **Issue: Cooler not staying cold enough.**
  Solution: Ensure the main zipper is fully closed and the quick-access flap is sealed. Use sufficient ice packs or frozen items. Pre-chill the cooler before adding contents.
- **Issue: Difficulty attaching to paddleboard.**
  Solution: Verify that the bungee cords are properly hooked to the D-rings or existing deck bungees. Adjust tension as needed. If your board lacks D-rings, consider adding compatible attachment points.
- **Issue: Cooler not collapsing easily.**
  Solution: Ensure the cooler is empty and dry. Gently apply even pressure to the top while pushing inwards on the sides to help it fold flat.

Product Specifications

Feature	Detail
Brand	iROCKER
Model Name	Pop Up Cooler
Color	Blue
Material	nylon-mesh
Item Weight	0.5 Pounds
Special Feature	Portable
Water Resistance Level	Water Resistant
Item Package Dimensions L x W x H	12 x 12 x 2.5 inches
UPC	791689994833

Warranty and Support

For specific warranty information or product support, please refer to the documentation included with your purchase or visit the official iROCKER website. Keep your proof of purchase for any warranty claims.

If you require further assistance, please contact iROCKER customer service through their official channels.

© 2026 iROCKER. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CC3Q9RS1

More documents and user manuals: **https://manuals.plus/**