Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Dpofirs Dpofirsz36b17xodp

Portable WiFi Router User Manual

Model: Dpofirsz36b17xodp | Brand: Dpofirs

Product Overview

The Dpofirs Portable WiFi Router is a versatile 4G LTE USB modem designed for travel and mobile internet access. It features a built-in 3200 mAh battery and a SIM card slot, allowing you to create a personal WiFi hotspot on the go. This device supports high-speed internet access up to 300 Mbps and can connect up to 10 devices simultaneously.



Image: Front view of the Dpofirs Portable WiFi Router, showing its compact white design with a black circular display area indicating signal, WiFi, and battery status, and a '4G/5G' logo.

Setup Guide

1. SIM Card and Battery Installation

To begin, insert your SIM card into the designated slot and install the battery. Ensure the SIM card is correctly oriented as per the diagram inside the device's compartment.



Image: Close-up view of the Dpofirs Portable WiFi Router showing the open back cover, revealing the SIM card slot and the battery compartment. A SIM card is shown next to the device, indicating its placement.

2. APN Configuration (If Needed)

Even if your SIM card is compatible with the WiFi hotspot device, it may not be plug-and-play. You might need to disable the SIM card's PIN code and modify the Access Point Name (APN) settings. Refer to your mobile network provider for the correct APN settings.



Image: The Dpofirs Portable WiFi Router displayed with overlay text explaining the initial setup steps, including inserting the SIM card and the potential need to disable the PIN and modify APN settings for proper functionality.

Operating Instructions

Connecting Devices

The Dpofirs Portable WiFi Router can connect up to 10 devices simultaneously, including smartphones, tablets, and laptops. The effective WiFi range is approximately 10 meters (32.8 feet).



Image: The Dpofirs Portable WiFi Router shown with text highlighting its ability to connect up to 10 devices simultaneously, such as smartphones, tablets, and laptops.

Powering the Device

The router is equipped with a 3200 mAh battery for portable use. It can also operate with an external power supply, allowing for continuous use without time limits. Charging can be done via a computer's USB port, a car USB charger, or a standard power adapter.

SPECIFICATIONS

This portable WiFi router supports the LTE CAT4 standard, providing high-speed internet access of up to 300 Mbps. Performance may vary based on signal strength. It supports various network bands for broad compatibility.



Image: The Dpofirs Portable WiFi Router against a blue background with abstract network lines, emphasizing its support for LTE CAT4 standard and 300 Mbps high-speed internet access.

Physical Characteristics

The device is designed to be compact and lightweight, making it ideal for travel and various mobile applications.



Image: The Dpofirs Portable WiFi Router in a setting suggesting portability, with text highlighting its compact and lightweight design, suitable for various uses like travel, business trips, and outdoor streaming.



Image: The Dpofirs Portable WiFi Router shown with approximate dimensions (10cm length, 6cm width, 1.5cm thickness), illustrating its compact size.

Detailed Specifications

Feature	Detail
Brand	Dpofirs
Model Number	Dpofirsz36b17xodp
Connectivity Technology	Wi-Fi
Wireless Communication Standard	802.11ac
Frequency Band Class	Dual Band
Supported Network Bands	B1/2/3/5/7/8/20/40
Max Speed	300 Mbps (LTE CAT4)
Battery Capacity	3200 mAh
SIM Card Slot	Yes
Max Connected Devices	10
Effective WiFi Distance	Up to 10 meters
Compatible Devices	Smartphones, Tablets, Laptops
Operating System (Tentative)	Linux
Color	White
Included Components	USB WiFi Modem, USB Cable

Maintenance

To ensure the longevity and optimal performance of your Dpofirs Portable WiFi Router, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the device. Avoid using liquid cleaners or abrasive materials.
- **Storage:** Store the device in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** For optimal battery life, avoid fully discharging the battery frequently. If storing for extended periods, charge the battery to about 50% and recharge every few months.
- **Avoid Drops:** Protect the device from physical shocks and drops, which can damage internal components.

Troubleshooting

If you encounter issues with your Dpofirs Portable WiFi Router, refer to the following common troubleshooting steps:

- **No Internet Connection:**
  - Ensure the SIM card is correctly inserted and activated with a data plan.
  - Check if the SIM card's PIN code needs to be disabled.
  - Verify and modify the APN settings according to your mobile network provider's specifications.
  - Restart the device.
  - Check signal strength. Poor signal can lead to no or intermittent connection.
- **Device Not Powering On:**
  - Ensure the battery is properly installed and charged.
  - Connect the device to a power source using the provided USB cable and a compatible charger.
- **Cannot Connect Devices to WiFi:**
  - Ensure the WiFi hotspot is enabled on the router.
  - Verify the WiFi password.
  - Check if the maximum number of connected devices (10) has been reached.
  - Move closer to the router to ensure you are within the effective WiFi range (10m).
- **Slow Internet Speed:**
  - Signal strength is a primary factor for speed; try moving to an area with better signal.
  - Reduce the number of connected devices.
  - Check your data plan for any speed limitations or data caps.

Warranty and Support

Specific warranty information for this product is not provided in the available data. For detailed warranty terms, technical support, or service inquiries, please refer to the documentation included with your purchase or contact Dpofirs customer support directly through their official channels.
You may also visit the Dpofirs Brand Store on Amazon for more information.

© 2025 Dpofirs. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CC9PP1TH

More documents and user manuals: **https://manuals.plus/**