1MORE EF906-Grey-AU

1MORE S50 Fit Open Earbuds User Manual

MODEL: EF906-GREY-AU | BRAND: 1MORE

Introduction

The 1MORE S50 Fit Open Earbuds are designed to provide a high-quality audio experience while maintaining awareness of your surroundings. Featuring an innovative open-ear design, PurePower Driver technology, and IPX7 sweat-resistance, these earbuds are ideal for sports, fitness, and daily use. This manual provides essential information for setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your earbuds.

Image: The 1MORE S50 Fit Open Earbuds resting in their charging case, showcasing their sleek design and compact form factor.

EXTENDED 38-HOUR BATTERY LIFE

Keep consistency with your other wirelessly charge-enabled devices, charging your 1MORE earbuds has never been easier.

11 Hrs
PER CHARGE

38 Hrs
OF TOTAL PLAYBACK WITH CASE

5 mins = **2** Hrs
FAST CHARGE

* Playtime is tested in the laboratory under AAC format at 50% volume, which may vary according to device settings, use habits and other factors.

Image: The 1MORE S50 Fit Open Earbuds highlighting their open-ear design for enhanced real-time awareness.

Image: A detailed diagram illustrating the PurePower Driver technology, designed to boost surging sound.

Image: A close-up view of the Diamond-Like Carbon (DLC) diaphragm, responsible for revealing the finest notes in audio.

What's in the Box

- 1MORE S50 Open Earbuds (2 units)
- Charging case (1 unit)
- Type-C Cable (1 unit)
- Ear Caps (3 pairs: XS/S/M)
- User Manual (this document)

Setup

1. Initial Charging

Before first use, fully charge the earbuds and the charging case. Place the earbuds into the charging case and connect the Type-C cable to the case and a power source. The LED indicator on the case will show charging status. A full charge provides up to 11 hours of listening time for the earbuds and up to 38 hours total with the charging case. A quick 5-minute charge can provide 2 hours of listening.

Image: The 1MORE S50 charging case with an illuminated LED, indicating battery status and charging capability.

2. Pairing with Your Device

1. Ensure the earbuds are in the charging case and the case lid is open.
2. On your device (smartphone, tablet, laptop), enable Bluetooth.
3. Search for "1MORE S50 Fit" in the list of available Bluetooth devices and select it to pair.
4. Once paired, the earbuds will automatically connect to your device when taken out of the case.

The earbuds utilize advanced Bluetooth 5.3 technology for stable and efficient wireless communication.

Image: A visual representation of the advanced Bluetooth 5.3 technology integrated into the earbuds, ensuring stable connectivity.

3. Wearing the Earbuds

The 1MORE S50 Fit Open Earbuds feature an open-ear design with ear hooks for secure and comfortable fit, allowing you to stay aware of your surroundings. Choose the appropriate ear caps (XS/S/M) for optimal comfort and sound delivery. Gently place the earbud over your ear, ensuring the ear hook wraps securely around the back of your ear.

REVEAL THE FINEST NOTES
## Diamond-Like Carbon Diaphragm

Image: A person wearing the 1MORE S50 Fit Open Earbuds, demonstrating their secure and comfortable fit during physical activity.


Image: A diagram illustrating the correct method for wearing the 1MORE S50 Fit Open Earbuds, highlighting the ear hook placement.

Operating Instructions

Touch Controls

The 1MORE S50 Fit Open Earbuds feature intuitive touch controls for easy management of calls and music playback.

Double-tap: Answer/End Call, Play/Pause Music.

Press and hold: Decline Call.

Tap 3 times (when Bluetooth is on and not on a phone call): Activate Voice Control on cellphone.

Image: A visual guide to the touch control functions on the 1MORE S50 Fit Open Earbuds.

Image: An expanded diagram detailing the touch control gestures for calls and music playback on the earbuds.

Sound Customization

The 1MORE S50 earbuds offer various equalizer options to tailor your listening experience. These can typically be adjusted via the companion app, if available, allowing you to select presets like Hip-Hop, Acoustic, Podcast, Electronic, Studio, Classical, Pop, Vocal Booster, Deep, Bass Booster, Lounge, and Bass Reducer.


Image: A graphic displaying the diverse range of equalizer presets available for sound customization on the 1MORE S50 earbuds.

Call Quality

Equipped with 4 high-performance MEMS microphones and an AI-powered deep neural network (DNN) algorithm, the earbuds accurately pick up human voice and eliminate background noise by up to 30 dB, ensuring clear two-way calls even in bustling environments.

CRYSTALLINE TWO-WAY COMMUNICATION

ENVIRONMENT NOISE CANCELLING FOR CALLS

4 high-performance MEMS microphones and an AI-powered deep neural network (DNN) algorithm accurately pick up the human voice and eliminate background noise by up to 30 dB, even in bustling crowds, the two-way calls are still clear.

Before   After

Image: A man using the 1MORE S50 earbuds for a call, highlighting the clear communication provided by the noise-cancelling technology.

Maintenance

Cleaning and Care

The 1MORE S50 Fit Open Earbuds boast an IPX7 waterproof rating, providing excellent protection against sweat, rain, and splashes. After intense workouts or exposure to moisture, it is recommended to gently wipe the earbuds with a soft, dry cloth. Ensure the charging contacts on both the earbuds and the case are clean and dry before placing them back in the case to charge.

ENHANCE REAL-TIME AWARENESS
Open-Air Tech Shields Your Back

Image: The 1MORE S50 Fit Open Earbuds covered in water droplets, visually confirming their IPX7 sweat-resistant design.

Storage

Always store the earbuds in their charging case when not in use to protect them and ensure they remain charged. Store the case in a cool, dry place away from extreme temperatures and direct sunlight.

Troubleshooting

Problem	Possible Cause	Solution
Earbuds not pairing/connecting.	Earbuds not in pairing mode; device Bluetooth off; interference.	Ensure earbuds are in case with lid open. Turn device Bluetooth off and on. Move closer to device. Try resetting earbuds.
No sound from earbuds.	Low battery; volume too low; incorrect audio output selected.	Charge earbuds. Increase device volume. Check device's audio output settings.

Problem	Possible Cause	Solution
Earbuds not charging.	Dirty charging contacts; faulty cable/power source.	Clean charging contacts with a dry cotton swab. Try a different USB-C cable or power adapter.
Poor call quality.	Environmental noise; weak signal.	Move to a quieter environment. Ensure earbuds are within Bluetooth range of your device.

Resetting the Earbuds

If you experience persistent issues, a factory reset may resolve them. Refer to the official 1MORE S50 user manual PDF for specific reset instructions, as procedures can vary.

Specifications

| Feature	Detail
Model Name	EF906
Connectivity Technology	Wireless (Bluetooth 5.3)
Ear Placement	Open Ear
Water Resistance Level	IPX7 (Waterproof)
Battery Life (Earbuds)	11 Hours
Battery Life (with Case)	38 Hours
Charging Case Battery Capacity	500 Milliamp Hours
Control Type	Touch
Microphones	4 MEMS Mics with AI-enabled ENC
Audio Driver Type	Dynamic Driver (PurePower Driver with DLC diaphragm)
Item Weight	18 Grams (earbuds)
Material	Plastic, Silicone
Color	Gray (Earbuds), Black Grey (Case)
UPC	190280000866

Warranty and Support

1MORE products typically come with a limited warranty. Please refer to the official 1MORE website or your purchase documentation for specific warranty terms and conditions.

For further assistance, technical support, or to view the complete user manual, please visit the official 1MORE website or refer to the provided PDF manual:

[Download User Manual (PDF)](#)

Related Documents - EF906-Grey-AU

[1MORE Fit Open Earbuds S50 User Guide](#)
User guide for the 1MORE Fit Open Earbuds S50, detailing features, functions, safety information, and warranty.

[1MORE Fit SE S30 Open Ear Wireless Bluetooth Headphones User Manual](#)
User manual and specifications for the 1MORE Fit SE S30 Open Ear Wireless Bluetooth Headphones (Model EF606). Features include Bluetooth 5.3, 30-hour battery life, clear calls, and detailed operational instructions.

[1MORE EF906 Wireless Earphones: User Manual, Features, and Specifications](#)
Get detailed information on the 1MORE EF906 wireless earphones, including setup, touch controls, smart playback, pairing, specifications, troubleshooting, and warranty. Enhance your audio experience.

[1MORE Fit SE Open Earbuds S30 User Guide](#)
User guide for the 1MORE Fit SE Open Earbuds S30, covering features, controls, safety information, specifications, and troubleshooting.

[1MORE Stylish True Wireless In-Ear Headphones E1026BT User Manual](#)
Comprehensive user manual for the 1MORE Stylish True Wireless In-Ear Headphones (E1026BT). Learn about product features, pairing, charging, key functions, tips, safety information, and FAQs.

[1MORE iBFree Sport Bluetooth In-Ear Headphones - E1018BT User Manual & Guide](#)
Comprehensive user manual and guide for the 1MORE iBFree Sport E1018BT Bluetooth in-ear headphones. Learn about pairing, controls, safety, warranty, and troubleshooting.