Manuals+
Q & A | Deep Search | Upload

hsiy-01

P9 Pro Max Bluetooth Over-Ear Headset Instruction Manual

Model: P9 Pro Max (hsiy-01)

Introduction

This manual provides detailed instructions for the safe and efficient use of your P9 Pro Max Bluetooth Over-Ear Headset. Please read this manual thoroughly before using the product and retain it for future reference.

Product Overview

The P9 Pro Max headset offers versatile audio connectivity with Bluetooth V5.1, wired AUX, and TF card playback. It features a comfortable over-ear design with soft earcups and a flexible headband.

Headset Components

- **Thick Soft Headband:** Designed for comfort during extended wear.
- **Soft Breathable Memory Foam Earmuffs:** Provides comfort and passive noise isolation.
- **Adjustable Earcups:** Ergonomic design allows for free adjustment to fit various head sizes.
- **Control Buttons:** For power, volume, track control, and call management.
- **Type-C Charging Port:** For charging the internal battery.
- **3.5mm AUX Port:** For wired audio connection.
- **TF Card Slot:** For direct audio playback from a memory card.
- **40mm Speaker Drivers:** Delivers clear stereo sound.

Image: Overview of the P9 Pro Max headset highlighting the thick soft headband and soft breathable memory foam earmuffs for comfort.

Image: A person wearing the P9 Pro Max headset, demonstrating its ergonomic and freely adjustable design for a comfortable fit.

Setup

1. Charging the Headset

Before first use, fully charge the headset. Use the provided Type-C charging cable to connect the headset's charging port to a USB power source (e.g., computer, wall adapter). The charging indicator light will typically show red during charging and turn off or blue when fully charged.

Charging Time: Approximately 2 hours.

Input Voltage: 3.7-5 V DC.

Image: Detailed view of the headset's side, indicating the Type-C charging port, 3.5mm AUX cable input, and TF card slot.

2. Power On/Off

- **Power On:** Press and hold the On/Off button for approximately 3 seconds until the indicator light flashes.
- **Power Off:** Press and hold the On/Off button for approximately 3 seconds until the indicator light turns off.

3. Bluetooth Pairing

After powering on, the headset will automatically enter pairing mode (indicator light will flash blue and red alternately).

1. Ensure Bluetooth is enabled on your device (smartphone, tablet, computer).
2. Search for available Bluetooth devices.
3. Select "P9 Pro Max" from the list of devices.
4. Once paired, the indicator light will flash blue slowly, and you will hear a confirmation tone.
5. Transmission Distance: Up to 10 meters (unobstructed).

Operating Instructions

Control Functions

Image: Illustration of the headset's control panel, detailing button functions for volume, track selection, power, play/pause, call management, and mode switching.

Headset Control Functions

Button/Action	Function
Volume + (Press once)	Increase Volume
Volume + (Long Press)	Next Song
Volume - (Press once)	Decrease Volume
Volume - (Long Press)	Previous Song
On/Off Button (Long Press 3rd)	Power On/Off

Button/Action	Function
On/Off Button (Press once)	Play/Pause Music
On/Off Button (Press once)	Receive/Hang Up Calls
BT/Radio Mode Button (Press once)	Switch between Bluetooth, Wired, and TF Card modes.

Wired Connection (AUX Mode)

To use the headset with a wired connection, plug one end of a 3.5mm AUX cable into the headset's AUX port and the other end into your audio device. The headset will automatically switch to wired mode. Note that some control functions may be limited in wired mode.

TF Card Playback

Insert a TF (microSD) card loaded with audio files into the TF card slot on the headset. The headset will automatically detect the card and begin playing music. Use the control buttons to manage playback.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the headset. Do not use abrasive cleaners or solvents.
- **Storage:** Store the headset in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the headset regularly, even if not in use for extended periods.
- **Avoid Water:** This headset is not waterproof. Avoid exposure to water or excessive moisture.

Troubleshooting

Common Issues and Solutions

Problem	Solution
Headset does not power on.	Ensure the headset is fully charged. Connect it to a power source using the Type-C cable.
Cannot pair via Bluetooth.	◦ Ensure the headset is in pairing mode (indicator light flashing blue/red). ◦ Make sure Bluetooth is enabled on your device. ◦ Move the headset closer to your device (within 10m). ◦ Forget the device from your Bluetooth list and try pairing again. ◦ Restart both the headset and your device.
No sound or low volume.	◦ Increase the volume on both the headset and your connected device. ◦ Ensure the headset is properly connected (Bluetooth or AUX). ◦ If using TF card, ensure audio files are compatible and the card is inserted correctly.
Headset disconnects frequently.	◦ Ensure there are no obstructions between the headset and your device. ◦ Move closer to your device. ◦ Avoid environments with strong Wi-Fi or other wireless interference.

Specifications

Technical Specifications

Feature	Detail
Bluetooth Version	V5.1
Connection Methods	Bluetooth, Wired (3.5mm AUX), TF Card
Transmission Distance	Up to 10 meters
Battery Capacity	Approximately 400mAh
Charging Time	Approximately 2 hours
Talk Time	Approximately 10 hours
Standby Time	Approximately 120 hours
Input Voltage	3.7-5 V DC
Charging Port	Type-C
Speaker Driver Size	40mm
Model Number	hsiy-01

Image: Diagram illustrating the internal structure of the 40mm speaker unit, emphasizing its design for high-fidelity and panoramic sound.

Warranty and Support

This product is covered by a standard manufacturer's warranty. For specific warranty terms and conditions, please refer to the packaging or contact your retailer. For technical support or further assistance, please contact the seller through the platform where the product was purchased.