Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Radio Flyer 3985Z

Radio Flyer Voya XT Quad Stroller Wagon User Manual

Model: 3985Z

Introduction

The Radio Flyer Voya XT Quad Stroller Wagon is designed for families on the go, combining the convenience of a stroller with the versatility of a wagon. It features seating for up to four children, extra tall sides for security, and dual UPF 50+ canopies for sun protection. This manual provides essential information for the safe assembly, operation, and maintenance of your Voya XT Quad Stroller Wagon.



The Voya XT Quad Stroller Wagon offers comfortable transport for up to four children.

Key Features:

- **Push or Pull Functionality:** Equipped with a Never Fall pull handle and a height-adjustable push handlebar.
- **Compact Fold:** Steel-reinforced aluminum frame folds quickly without removing accessories.
- **Spacious Seating:** Four padded seats with roomy footwells and 5-point harnesses.
- **Sun Protection:** Dual UPF 50+ extendable canopies with mesh peekaboo windows.
- **Ample Storage:** Includes an XL rear storage bag, parent caddy, mesh interior pockets, and a removable snack tray with cupholders.
- **Easy Access:** Tall side walls with zippered doors for children to enter and exit independently.

Important Safety Information

Always read and follow all safety instructions provided in the included safety manual before using the Radio Flyer Voya XT Quad Stroller Wagon. Failure to do so may result in serious injury.

- Ensure all children are properly secured with the 5-point harnesses at all times.

- Do not exceed the maximum weight capacity of 300 lbs.
- Suitable for children aged 6 months and older.
- Always engage the parking brake when the wagon is stationary.
- Never leave children unattended in the wagon.

Setup and Assembly

The Voya XT Quad Stroller Wagon is designed for straightforward assembly. Most users report setup taking approximately 10-45 minutes. A screwdriver may be required for some steps.

Unfolding the Wagon:

1. Place the folded wagon on a flat, stable surface.
2. Release any locking mechanisms that secure the wagon in its folded position.
3. Gently pull the frame outwards until it fully extends and locks into place.
4. Ensure all frame components are securely latched before use.



The wagon features a compact, travel-ready fold for easy storage and transport.

Attaching Accessories:

- **Canopies:** Slide the canopy poles into the designated slots on the wagon frame until they click securely.
- **Snack Tray:** Position the snack tray over the central divider and press down until it locks into place.
- **Storage Bag/Parent Caddy:** Attach these to the designated hooks or straps on the wagon.



Seat panels can be removed or installed as needed for cleaning or configuration.

Video Guide:

▶ **Watch video online**
Radio Flyer Voya XT Quad Stroller Wagon - Seats 4 Kids

Watch this official video from Radio Flyer for a visual guide on the Voya XT Quad Stroller Wagon's features and operation, including folding and unfolding.

Operating Instructions

Pushing and Pulling:

The Voya XT Quad Stroller Wagon offers dual functionality. You can push it like a traditional stroller using the height-adjustable handlebar or pull it like a wagon using the Never Fall pull handle. Adjust the handlebar to a comfortable height for optimal control.



Easily switch between pushing and pulling modes for versatile maneuvering.



The handlebar adjusts to accommodate users of various heights.

Securing Children:

Each of the four seats is equipped with a 5-point safety harness. Ensure each child is securely fastened before moving the wagon. The extra tall sides provide a secure environment.



Always use the 5-point harnesses to secure children.

Canopy Use:

Extend the dual UPF 50+ canopies to provide shade and protection from the sun. The mesh peekaboo windows allow for visibility and airflow. The canopies can be retracted when not needed.



Peekaboo windows offer visibility and ventilation.

Braking:

Engage the parking brake by pressing down on the foot pedal located near the rear wheels. Ensure the brake is fully engaged before releasing the handle. Disengage by lifting the pedal.



The foot-activated parking brake ensures the wagon remains stationary.

Storage and Accessibility:

Utilize the XL rear storage bag, parent caddy, and mesh interior pockets for personal items and essentials. The removable child snack tray with four cupholders provides convenience for children. Children can easily enter and exit through the zippered side doors.



Zippered doors allow for easy entry and exit.

The removable snack tray includes four cupholders.



The parent caddy provides convenient storage for adult essentials.

Maintenance

Cleaning:

The polyester fabric of the wagon can be easily wiped clean with a damp cloth and mild soap. Avoid harsh chemicals or abrasive cleaners. Allow to air dry completely before folding or storing.

Wheel Care:

Periodically check the wheels for debris and clear any obstructions. If wheels begin to squeak, apply a silicone-based lubricant to the axle points. Wheels can be removed for more compact storage or cleaning.



Durable wheels are designed for a smooth ride across various terrains.

Storage:

When not in use, fold the wagon into its compact form and store it in a dry, protected area. The wagon can stand upright when folded. Ensure all accessories are securely attached or stored separately to prevent loss.



The wagon is designed to be easily transported even when folded.

Troubleshooting

Problem	Possible Cause	Solution
Wheels squeak during use.	Lack of lubrication or debris in the wheel mechanism.	Clean wheels and apply a silicone-based lubricant to the axle points.
Push bar feels wobbly.	Normal flex in the adjustable mechanism.	Ensure the handlebar is securely locked at the desired height. This is a known characteristic of the design.
Brake is difficult to engage/disengage.	Mechanism may require firm pressure or adjustment.	Apply firm, deliberate pressure to the brake pedal. If issues persist, contact customer support.
Wagon does not roll easily when folded.	Front wheels do not lock for rolling in folded position.	The wagon is designed to be pulled on its larger rear wheels when folded. It can be angled for easier movement.

Specifications



Detailed dimensions of the Voya XT Quad Stroller Wagon.

Feature	Detail
Model Number	3985Z
Item Weight	54.2 pounds
Item Dimensions (L x W x H)	42.64"L x 30.79"W x 45.28"H
Maximum Weight Recommendation	300 pounds
Age Range Description	6+ months
Seating Capacity	4
Harness Type	5 Point

Feature	Detail
Number of Cup Holders	6
Material Type	Alloy Steel, Plastic, Polyester
Frame Material	Aluminum
Color	Gray
Included Components	Stroller Wagon

Warranty and Support

Radio Flyer is committed to producing durable and high-quality products. For detailed warranty information, product registration, or to contact customer support for assistance with your Voya XT Quad Stroller Wagon, please visit the official Radio Flyer website or refer to the documentation included with your purchase.
You can find more information and contact details on the Radio Flyer Brand Store.

© 2026 Radio Flyer. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CDMH7T78

More documents and user manuals: **https://manuals.plus/**