## Braun 8517s

# Braun Series 8 Electric Razor User Manual

Model: 8517s Galvano Silver

## 1. Product Overview

The Braun Series 8 Electric Shaver is designed to provide a close and gentle shave, even on dense beards. It features a 40-degree swiveling head and floating blades that adapt to facial contours for optimal skin comfort. Equipped with Braun's unique Sonic Technology, it utilizes 10,000 micro-vibrations to capture more hair. AutoSense technology adjusts power based on beard density. An integrated ProTrimmer allows for precise shaping. This shaver is 100% waterproof, suitable for wet and dry use, and powered by a Li-Ion battery offering 60 minutes of runtime with a quick charge option.




Image: The Braun Series 8 Electric Razor, showcasing its sleek Galvano Silver design, alongside its charging stand and a protective travel case.

## 2. What's Included

Your Braun Series 8 Electric Razor package includes the following components:

- Braun Series 8 8517s Men's Electric Shaver with built-in Precision Trimmer
- Fabric Razor Travel Case
- Charging stand
- Cleaning Brush
- Charging cable




Image: A clear layout of all items included in the Braun Series 8 product box, detailing each component.

## 3. Key Features

### 3.1. Sonic Technology & Shaving Elements

The shaver features 4 sonic-powered compact shaving elements and 10,000 micro-vibrations per minute. This technology helps to gently capture more hair in every stroke, ensuring a close and comfortable shave, even on dense beards.




Image: Detailed view of the shaver head highlighting the sonic technology and the 40-degree swiveling head for adapting to facial contours.

### 3.2. ProTrimmer for Precision

An integrated ProTrimmer slides out from the back of the shaver, providing ultimate precision for shaping sideburns and capturing tricky, fine hairs.




Image: The shaver demonstrating its 2-in-1 grooming capability with the ProTrimmer extended for detailed work.

### 3.3. Wet & Dry Use

The Braun Series 8 is 100% waterproof, allowing for versatile wet and dry shaving. It can be used with shaving foam, gel, or even under the shower for a comfortable experience.




Image: The shaver emphasizing its waterproof design and long battery life, suitable for both wet and dry use.

### 3.4. Long-lasting Battery

Powered by a powerful Li-Ion battery, the shaver provides up to 60 minutes of cordless shaving time. It also includes a 5-minute quick charge option for a single shave when time is short.

## 4. Setup

1. Remove the shaver from its packaging.
2. Clean all removable parts with warm, soapy water if necessary.
3. Ensure the shaver is fully charged before first use. Connect the charging cable to the shaver and the charging stand, then plug into a power outlet. The battery indicator lights will show charging progress.

## 5. Operating Instructions

The Braun Series 8 can be used for both wet and dry shaving. For optimal results, follow these steps:

1. **Prepare your skin:** For a dry shave, ensure your face is clean and dry. For a wet shave, wet your face or apply your preferred shaving foam or gel.
2. **Shaving technique:** Move the 40-degree swiveling head and floating blades gently over your face. The shaver adapts to facial contours, ensuring closeness and skin comfort. Use light pressure and shave against the direction of hair growth.
3. **Using the ProTrimmer:** For precise shaping of sideburns or trimming longer hairs, slide out the integrated ProTrimmer located at the back of the shaver. Use short, controlled strokes.

*Note: Video content demonstrating shaving techniques is not available for embedding due to source restrictions.*

## 6. Maintenance

Proper maintenance ensures the longevity and performance of your Braun Series 8 shaver.

- **Daily Cleaning:** Rinse the shaver head under running water after each use. Since it's 100% waterproof, this is quick and easy.
- **Deep Cleaning:** For a more thorough clean, use the included cleaning brush to remove any trapped hairs from the shaving elements.
- **Replacement Parts:**
  - Replace the shaving head (Braun 83M replacement head) approximately every 18 months to maintain optimal cutting performance.
  - If using a cleaning station (not included in this specific 5-piece set), change the cleaning cartridge refill every 2 months.
- **Battery Care:** To preserve battery life, avoid fully discharging the shaver frequently. Recharge it when the battery indicator shows low power.




Image: Visual guide for maintaining the shaver, including replacement schedules for the shaving head and cleaning cartridge.

## 7. Troubleshooting

Specific troubleshooting steps are not detailed in the provided product information. For any operational issues, please refer to the full product manual or contact Braun customer support.

## 8. Specifications

| Feature | Detail |
|---|---|
| Product Dimensions | 5.39 x 2.64 x 9.92 inches; 1.26 Pounds |
| Item Model Number | 8517s |
| Batteries | 1 Lithium Ion batteries required (included) |

| | |
|---|---|
| Date First Available | August 10, 2023 |
| Manufacturer | Procter & Gamble |
| ASIN | B0CFC8NRZL |
| Brand | Braun |
| Recommended Uses For Product | Beard |
| Special Feature | Waterproof |
| Power Source | Battery Powered |
| Model Name | Series 8 |
| Wattage | 5 watts |

## 9. Warranty & Support

The Braun Series 8 Electric Razor comes with a manufacturer's warranty of up to 2 years. This product is 100% Made in Germany, ensuring premium craftsmanship.
For further support, product registration, or warranty claims, please visit the officialBraun Store or contact their customer service directly.

© 2025 Braun. All rights reserved.


### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question