ANJANK AC199-Black

ANJANK 4-in-1 Wireless Charging Station with Alarm Clock User Manual

Model: AC199-Black

1. INTRODUCTION

Thank you for purchasing the ANJANK 4-in-1 Wireless Charging Station with Alarm Clock. This device is designed to simplify your charging experience by providing a centralized solution for your iPhone, Apple Watch, and AirPods, along with an integrated digital alarm clock. Please read this manual carefully to ensure proper setup and operation.

2. PACKAGE CONTENTS

Please check the package for the following items:

- 1 x ANJANK 4-in-1 Wireless Charging Station with Alarm Clock
- 1 x 18W Power Adapter
- 1 x Type-C Cable
- 1 x User Manual

3. PRODUCT OVERVIEW

The ANJANK 4-in-1 Wireless Charging Station integrates multiple functions into a compact design, featuring dedicated charging areas for your smartphone, Apple Watch, and AirPods, alongside a digital alarm clock display.

Figure 3.1: Front view of the ANJANK 4-in-1 Wireless Charging Station, showing a smartphone, Apple Watch, and AirPods charging, with the digital clock displaying 12:30 AM.

Figure 3.2: Diagram illustrating the four main functions: Phone charging, Headphone (AirPods) charging, Apple Watch charging, and Alarm Clock.

4. SETUP INSTRUCTIONS

1. **Connect Power:** Insert the Type-C cable into the charging port on the back of the station. Connect the other end of the cable to the provided 18W power adapter, then plug the adapter into a wall outlet.

2. **Power On:** The digital clock display will illuminate, indicating the device is powered on and ready for use.

3. **Initial Placement:** Place the charging station on a stable, flat surface, such as a nightstand or desk.

5. OPERATING INSTRUCTIONS

5.1. Wireless Phone Charging

Place your compatible smartphone on the vertical charging pad. Ensure the phone is centered on the pad for optimal charging. The charging indicator light on the station will illuminate to confirm charging is active.

- The station supports both vertical and horizontal phone placement for charging.
- Phone cases up to 3mm (0.12 inch) thick are generally supported. Cases with magnetic or metal attachments should be removed to prevent interference.

Figure 5.1: The charging station supports both vertical and horizontal orientation for smartphone charging.

Figure 5.2: Illustration of case-friendly charging, indicating compatibility with phone cases up to 3mm thickness, while advising against magnetic or metal attachments.

5.2. Apple Watch Charging

Place your Apple Watch on the dedicated magnetic charging module. Ensure the watch is properly aligned and secured to initiate charging.

5.3. AirPods Charging

Place your AirPods charging case on the flat wireless charging pad located at the base of the station. The charging indicator will confirm active charging.

5.4. Alarm Clock Functions

The integrated digital alarm clock offers adjustable settings for time, alarm, brightness, and volume.

Figure 5.3: Overview of alarm clock features including 9-minute snooze, 3 volume levels, 6 dimmer levels, and 12/24-hour mode.

- **Setting Time:** Use the 'TIME' button to enter time setting mode. Use the '+' and '-' buttons to adjust hours and minutes. Press 'TIME' again to confirm.
- **Setting Alarm:** Use the 'ALARM' button to enter alarm setting mode. Use the '+' and '-' buttons to adjust the alarm time. Press 'ALARM' again to confirm.
- **Snooze Function:** When the alarm sounds, press the 'SNOOZE' button to activate a 9-minute snooze.
- **Adjusting Brightness:** Use the 'DIMMER' button to cycle through 6 levels of display brightness.
- **Adjusting Volume:** Use the 'VOLUME' button to cycle through 3 levels of alarm volume.

- **Time Mode:** Press the '12/24H' button to switch between 12-hour (with AM/PM indicator) and 24-hour time formats.

6. COMPATIBILITY

The ANJANK 4-in-1 Wireless Charging Station is compatible with a wide range of devices:

Figure 6.1: Diagram illustrating universal compatibility with various iPhone models, Apple Watch Series, AirPods, and other Qi-enabled smartphones.

- **iPhones:** iPhone 16/16 Plus/16 Pro/16 Pro Max, 15/15 Plus/15 Pro/15 Pro Max, 14/14 Plus/14 Pro/14 Pro Max, 13/13 Mini/13 Pro/13 Pro Max, 12/12 Mini/12 Pro/12 Pro Max, 11/11 Pro/11 Pro Max, X/XR/XS/XS Max, 8/8 Plus.
- **Apple Watch:** iWatch Ultra 9/8/7/6/5/4/3/2/SE. **Note: Not compatible with Samsung Watch.**
- **AirPods:** AirPods Pro/Pro 2/3/2.
- **Other Qi-enabled Phones:** Compatible with LG (VS980/G3/G6/G6+/G7/G7 ThinQ/G7+ ThinQ/G8/G8 ThinQ), Google (Pixel 3/3XL, NEXUS 4/5/6), Sony (Xperia Z3v/XZ2/XZ2 Premium/XZ3), Nokia (Lumia 720/735/810/820/822/830), HTC (PH98100/PG32100/PJ53100/PL83200/PM23100), and other devices supporting wireless charging.

7. MAINTENANCE

To ensure the longevity and optimal performance of your charging station, follow these maintenance guidelines:

- **Cleaning:** Disconnect the power before cleaning. Use a soft, dry cloth to wipe the surface of the device. Avoid using abrasive cleaners, solvents, or harsh chemicals.
- **Heat Dissipation:** The ANJANK charging station features cooling holes on its back and bottom for efficient heat dissipation. Ensure these vents are not blocked to maintain optimal operating temperature.

Figure 7.1: Illustration highlighting the two ventilation holes designed for improved heat dissipation, ensuring cooler and safer charging.

8. TROUBLESHOOTING

If you encounter issues with your ANJANK charging station, refer to the following common problems and solutions:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Device not charging	Incorrect placement, phone case too thick, power not connected, incompatible device.	Ensure device is centered on the charging pad. Remove phone case if thicker than 3mm or if it has metal/magnetic attachments. Verify power adapter is securely plugged in. Check device compatibility.
Alarm clock not working/display issues	Incorrect settings, power interruption.	Refer to Section 5.4 for detailed instructions on setting time and alarm. Ensure continuous power supply.
Flashing blue light on base	Indicates full charge or a connection issue (e.g., device not properly aligned, foreign object detected).	This can indicate your device is fully charged. If it flashes while charging, reposition your device on the pad. Ensure no foreign objects are between the device and the charging pad.
Slow charging	Using a non-18W power adapter, device misalignment, background apps.	Use the provided 18W power adapter. Ensure proper alignment of the device on the charging pad. Close unnecessary background applications on your device.

9. SPECIFICATIONS

Feature	Detail
Model Number	AC199-Black
Input Voltage	5 Volts
Wattage	18 Watts
Connector Type	USB Type C
Item Weight	14.9 ounces
Package Dimensions	6.5 x 6.1 x 3.31 inches
Special Features	3-in-1 Wireless Charging (Phone+AirPods+Apple Watch), Alarm Clock, Display Dimmer, 12/24H Time Mode, Snooze, Adjustable Volume, Charging Indicator, Space-Saving, Easy Setup

10. SAFETY INFORMATION

To ensure safe operation and prevent damage to the device or injury, please observe the following safety

precautions:

- Do not disassemble, modify, or repair the device yourself.
- Keep the device away from water, moisture, and high temperatures.
- Avoid exposing the device to direct sunlight for extended periods.
- Use only the provided power adapter and cable. Using unauthorized accessories may cause damage or fire.
- This device incorporates multiple protection features, including over-current protection, over-voltage protection, and over-charging protection, to ensure safe charging.
- Ensure proper ventilation by not blocking the cooling holes on the device.

11. WARRANTY AND SUPPORT

ANJANK products come with a standard manufacturer's warranty. If you have any questions, concerns, or require technical assistance, please do not hesitate to contact our customer service team. We are committed to providing the best solution within 24 hours.

For support, please refer to the contact information provided on the product packaging or the official ANJANK website.

Related Documents - AC199-Black

	[ANJANK Clock-AC003 User Manual: Features, Setup, and Operation](#) Comprehensive user guide for the ANJANK Clock-AC003 digital alarm clock, covering setup, features like FM radio, dual alarms, USB charging, and operation.
	[ANJANK AC-190 Wireless Charging FM Radio Alarm Clock: Instruction Manual and Warranty](#) Comprehensive instruction manual and warranty information for the ANJANK AC-190 Wireless Charging FM Radio Alarm Clock, covering features, setup, operation, and specifications.
	[ANJANK AC190BT Bluetooth Speaker Alarm Clock with Wireless Charging User Manual](#) Comprehensive user manual for the ANJANK AC190BT Bluetooth Speaker Alarm Clock, detailing features, setup, operation, alarm settings, FM radio, wireless charging, and FCC compliance information.

	ANJANK AC-196 Digital Alarm Clock Radio User Manual and Warranty Comprehensive user manual and warranty information for the ANJANK AC-196 digital alarm clock radio, featuring dual alarms, FM radio, sleep timer, and USB charging.
	Anjank AC209 User Manual: White Noise Machine, Bluetooth Speaker, and Alarm Clock Comprehensive user manual for the Anjank AC209, a versatile device featuring a white noise machine with 20 soothing sounds, a Bluetooth speaker, an alarm clock with multiple ringtones, and a 7-color night light. Includes setup instructions, features, operation guides, and FCC compliance information.
	ANJANK CT008 Gym Timer User Manual: Setup, Features, and Operation Guide Comprehensive user manual for the ANJANK CT008 Gym Timer. Learn how to set up, use functions like countdown, count-up, EMOM, stopwatch, custom intervals, and understand FCC compliance. Includes video guide link.