Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Karl home 31.5-inch Mobile Side Table with Wheels

Karl home 31.5-inch Mobile Side Table with Wheels Instruction Manual

Model: 31.5-inch Mobile Side Table with Wheels (Rustic Brown)

1. Introduction

Thank you for choosing the Karl home 31.5-inch Mobile Side Table with Wheels. This manual provides essential information for the safe assembly, operation, and maintenance of your new side table. Please read these instructions carefully before assembly and retain them for future reference.



Image 1.1: The Karl home Mobile Side Table in a bedroom, showcasing its rustic brown finish and compact design.

2. Safety Information

WARNING:

- Ensure the desk is properly anchored to prevent tipping.
- Do not exceed the weight limit of 30 lbs (13 kg). Overloading can cause instability and damage.
- Keep small parts away from children during assembly to prevent choking hazards.
- Do not stand or sit on the table.

3. Package Contents

Please verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact Karl home customer support.

- Tabletop (1)

- Support Legs (2)
- Base Frames (2)
- Locking Casters (4)
- Connecting Bar (1)
- Adjustment Knobs (2)
- Assembly Hardware (Screws, Allen Wrench)
- User Manual (This document)

4. Setup and Assembly

The design of this adjustable computer desk is simple, and all panel materials are pre-drilled for easy installation. One person is recommended for assembly. A screwdriver is the only tool recommended for assembly, in addition to the included Allen wrench.

1. **Attach Casters to Base Frames:** Secure the four locking casters to the bottom of the two base frames using the provided screws. Ensure they are firmly attached.
2. **Connect Support Legs to Base Frames:** Attach the support legs to the base frames. Make sure the holes for the adjustment knobs are facing the correct direction for easy access.
3. **Install Connecting Bar:** Secure the connecting bar between the two support legs. This enhances stability.
4. **Attach Tabletop:** Place the tabletop onto the top of the support legs and secure it with the remaining screws.
5. **Insert Adjustment Knobs:** Insert the adjustment knobs into the designated holes on the support legs. Do not tighten them fully yet.



Image 4.1: Dimensional overview of the table, indicating its adjustable height range and maximum weight capacity of 30 lbs.



Image 4.2: Close-up of the rotary adjustment knob, illustrating how to loosen and tighten it for height changes.

5. Operating Instructions

5.1. Adjustable Height

The mobile side table is height adjustable from 27.16 inches to 38.58 inches. To adjust the height:

1. Loosen the two adjustment knobs on the support legs by turning them counter-clockwise.
2. Carefully raise or lower the tabletop to your desired height.
3. Once the desired height is reached, tighten both adjustment knobs by turning them clockwise until secure. Ensure both sides are at the same height and firmly locked before use.




Image 5.1: Visual guide to the rotary adjustment, showing the range of height adjustment from 27.16 to 37.79 inches (note: product specs state up to 38.58 inches).

5.2. Removable Design and Mobility

The table features four locking casters for easy movement and stability.

- **To Move:** Unlock all four casters by flipping their levers to the 'unlocked' position. Gently push the table to its new location.

- **To Lock:** Once the table is in the desired position, press down on the levers of all four casters to engage the locks. This will prevent the table from rolling.



Image 5.2: Detail of a caster wheel, highlighting its movable and lockable functions for easy positioning and stability.



Image 5.3: An illustration of the 360-degree rotation and locking mechanism of the casters.

5.3. Versatile Use

This C-shaped desk is designed for various uses:

- As a computer desk for laptops.
- As a side table for snacks, drinks, or books.
- Can be positioned over a sofa or bed for convenient access.



Image 5.4: Examples of versatile use, showing the table holding a laptop, snack, iPad, coffee, and book.



Image 5.5: The side table conveniently placed next to a sofa, demonstrating its C-shape design.



Image 5.6: The side table extending over a bed, providing a convenient surface for a laptop and books.

6. Maintenance

- **Cleaning:** Wipe the table surface with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Tightening:** Periodically check and tighten all screws and adjustment knobs to ensure the table remains stable.
- **Avoid Moisture:** Do not expose the table to excessive moisture or direct sunlight for prolonged periods, as this can cause warping or discoloration.

7. Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Table is wobbly.	Screws or adjustment knobs are loose.	Check and tighten all assembly screws and adjustment knobs. Ensure the table is on a flat surface.
Casters not rolling smoothly.	Debris in casters; casters locked.	Clean any debris from the caster wheels. Ensure caster locks are in the 'unlocked' position.
Difficulty adjusting height.	Adjustment knobs are too tight.	Loosen the adjustment knobs sufficiently before attempting to change height.

8. Specifications

Feature	Detail
Brand	Karl home
Model	31.5-inch Mobile Side Table with Wheels
Product Dimensions (L x W x H)	31.5" x 15.75" x 27.16"-38.58"
Adjustable Height Range	27.16" to 38.58"
Color	Rustic Brown
Material	P2 15MM Chipboard and Alloy Steel
Maximum Weight Recommendation	30 pounds (13 kg)
Special Features	Adjustable Height, Locking Casters, C-shape Design
Included Components	4 Locking Casters, User Manual

9. Warranty and Support

Karl home is committed to providing quality products. If you encounter any difficulties during installation or use, please contact Karl home customer support for assistance. We will provide a satisfactory solution.
For further support, please visit the official Karl home store or contact us through your purchase platform.

Online Store: Karl home Store on Amazon

© 2023 Karl home. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CG6BWJFC

More documents and user manuals: **https://manuals.plus/**