Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Tchibo S9192958

Tchibo Cafissimo Pure Plus Coffee Machine User Manual

Brand: Tchibo | **Model:** S9192958

1. Product Overview

The Tchibo Cafissimo Pure Plus is a capsule coffee machine designed for easy preparation of Caffè Crema, Espresso, and Coffee. It features a patented three-pressure brewing system to ensure optimal brewing pressure for each coffee type, delivering a high-quality coffee experience at home.



Image 1: The Tchibo Cafissimo Pure Plus coffee machine in white, with a freshly brewed coffee in a glass cup.

Key Features:

- **Versatile Coffee Preparation:** Enjoy Caffè Crema, Espresso, and Coffee with a single touch.
- **Patented Three-Pressure Brewing System:** Ensures optimal brewing pressure for each coffee type, mimicking professional coffee preparation.
- **Compact and Space-Saving Design:** With a width of 11.9 cm, it fits easily into various kitchen spaces.
- **Energy Efficient:** Automatic shut-off after 9 minutes of inactivity to save energy.
- **Easy to Clean:** Removable components like the drip tray are dishwasher safe, and an integrated descaling function simplifies maintenance.
- **Flexible Cup Shelf:** Adjustable for small cups or larger mugs (up to 15.4 cm height).
- **Sustainable Coffee:** Uses recyclable capsules and coffee from 100% sustainable cultivation.

2. Setup and First Use

Unpacking and Initial Preparation:

1. Carefully remove the coffee machine from its packaging.
2. Place the machine on a stable, level surface near a power outlet.
3. Remove the water tank from the back of the machine.
4. Rinse the water tank and the drip tray with clean water before first use.
5. Fill the water tank with fresh, cold drinking water up to the MAX mark.
6. Place the water tank back into the machine securely.
7. Connect the power plug to a suitable wall socket.

First Rinse Cycle:

Before brewing your first coffee, perform a rinse cycle to clean the internal system.

1. Place an empty cup or container (at least 200ml capacity) under the coffee spout.
2. Press any of the coffee preparation buttons (e.g., Espresso button) without inserting a capsule.
3. The machine will dispense hot water. Repeat this process 2-3 times until the water runs clear.
4. The machine is now ready for use.





Image 2: Front view of the machine, showing the coffee spout and drip tray, ready for cup placement.

3. Operating the Coffee Machine

The Cafissimo Pure Plus uses a patented three-pressure brewing system, which automatically adjusts the brewing pressure for optimal results for Espresso, Caffè Crema, and Coffee capsules.



Image 3: Illustration of the patented three-pressure brewing system, highlighting its capability for three different coffee types.

Brewing Coffee:

1. Ensure the water tank is filled with fresh water.
2. Open the capsule holder by lifting the lever.
3. Insert a Tchibo Cafissimo capsule into the holder. Ensure it is correctly seated.
4. Close the capsule holder by pushing the lever down firmly until it clicks.
5. Place your cup under the coffee spout. Adjust the cup shelf if using a taller mug.
6. Press the button corresponding to the desired coffee type (Espresso, Caffè Crema, or Coffee). The machine will start brewing.
7. Once brewing is complete, the machine will stop automatically.
8. Lift the lever to open the capsule holder. The used capsule will automatically drop into the integrated capsule

container.

9. Close the lever.



Image 4: A selection of Tchibo Cafissimo capsules, demonstrating the variety available for the machine.



Image 5: A user operating the Cafissimo Pure Plus machine, illustrating the ease of use.

4. Maintenance and Cleaning

Regular cleaning and maintenance ensure the longevity and optimal performance of your Cafissimo Pure Plus machine.

Daily Cleaning:

- **Drip Tray and Capsule Container:** Empty and rinse the drip tray and the used capsule container daily or after every 6 capsules. These components are dishwasher safe.
- **Water Tank:** Rinse the water tank regularly and refill with fresh water.
- **Machine Exterior:** Wipe the exterior of the machine with a soft, damp cloth. Do not use abrasive cleaners or solvents.

Descaling:

The machine has an integrated descaling function. The frequency of descaling depends on the water hardness in your

area and usage frequency. Refer to the full manual for detailed descaling instructions, typically involving a descaling solution and a specific program.

Important: Use only descaling agents recommended for coffee machines. Follow the instructions on the descaling agent packaging carefully.

5. Troubleshooting

This section addresses common issues you might encounter with your Cafissimo Pure Plus machine.

Problem	Possible Cause	Solution
Machine does not turn on.	No power supply.	Check if the power plug is securely inserted into the wall socket and the machine. Check the fuse.
No coffee is dispensed.	Water tank is empty; capsule not inserted correctly; machine is clogged.	Fill the water tank. Ensure the capsule is properly seated and the lever is closed. Perform a descaling cycle if necessary.
Coffee tastes weak or watery.	Incorrect capsule type for selected button; machine needs descaling.	Ensure you are using the correct capsule for the chosen coffee type. Descale the machine.
Water leaks from the machine.	Water tank not properly seated; drip tray is full.	Re-seat the water tank firmly. Empty and clean the drip tray.
Machine makes unusual noises.	Air in the system; machine needs descaling.	Run a rinse cycle without a capsule. Descale the machine if the issue persists.

If the problem persists after attempting these solutions, please contact Tchibo customer support.

6. Technical Specifications



Image 6: The machine's dimensions illustrated with a human figure for scale, indicating a height of 24 cm.

Feature	Value
Brand	Tchibo

Feature	Value
Model Number	S9192958
Product Dimensions (L x W x H)	35 x 16 x 29 cm
Item Weight	3 kg
Voltage	230 Volts (AC)
Wattage	1250 watts
Water Tank Capacity	0.8 Litres (approx.)
Capsule Container Capacity	Up to 6 used capsules
Automatic Shut-off	After 9 minutes

7. Warranty and Support

Tchibo products are manufactured to high-quality standards. For information regarding the warranty period and terms, please refer to the warranty card included with your product or visit the official Tchibo website.

For technical support, spare parts, or further assistance, please contact Tchibo customer service. Contact details can typically be found on the official Tchibo website or in the product packaging.

Online Resources: For the most up-to-date information, FAQs, and video tutorials, please visit the official Tchibo Cafissimo support page.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CG9XHW6N

More documents and user manuals: **https://manuals.plus/**