Maxuni M-18F8

Maxuni USB WiFi Adapter M-18F8 User Manual

AC1300Mbps Dual Band Network Adapter

1. INTRODUCTION

Thank you for choosing the Maxuni USB WiFi Adapter M-18F8. This device provides high-speed wireless connectivity for your desktop or laptop computer, supporting both 2.4GHz and 5GHz bands. With its USB 3.0 interface and dual 5dBi high-gain antennas, it ensures a stable and fast internet connection. This manual will guide you through the installation, operation, and maintenance of your new WiFi adapter.

2. KEY FEATURES

- **Dual-Band Connectivity:** Supports 5GHz (up to 867Mbps) and 2.4GHz (up to 400Mbps) for flexible and high-speed wireless connections.

- **USB 3.0 Interface:** Provides data transfer speeds up to 10 times faster than USB 2.0, ensuring optimal performance.

- **Dual 5dBi High-Gain Antennas:** Enhances signal reception and transmission range, improving connection stability even in areas with weak signals.

- **Wide Operating System Compatibility:** Compatible with Windows 11, 10, 8.1, 8, 7, Vista, and XP.

- **Receive & Transmit WiFi:** Functions as both a receiver for your desktop/laptop and a transmitter to share your computer's internet connection with other devices.

3. SYSTEM REQUIREMENTS

- Available USB 3.0 or USB 2.0 port.

- Operating System: Windows 11 / 10 / 8.1 / 8 / 7 / Vista / XP.

- CD-ROM drive (for driver installation, if not using download link).

4. PACKAGE CONTENTS

- Maxuni USB WiFi Adapter M-18F8

- Mini CD with Drivers

- User Manual

5. Setup and Driver Installation

Follow these steps to install your Maxuni USB WiFi Adapter:

1. **Do not plug in the WiFi adapter yet.**

2. **Install Drivers:**
   - **For Windows 11/10:** The adapter is generally plug-and-play. You may proceed to step 3. If drivers are not automatically installed, follow the instructions for other systems.
   - **For Windows 8.1/8/7/Vista/XP:** Insert the provided Mini CD into your computer's CD-ROM drive. Run the setup program (e.g., `Setup.exe`) and follow the on-screen instructions to complete the driver installation.
   - **Alternative Driver Download:** If your computer lacks a CD-ROM drive, download the latest drivers from the official link: https://bit.ly/2tsbuS7. Download and install the appropriate driver for your operating system.

3. **Plug in the Adapter:** Once the drivers are installed (or if using Windows 11/10 and expecting plug-and-play), insert the Maxuni USB WiFi Adapter into an available USB 3.0 port on your desktop or laptop.

4. **Antenna Adjustment:** Adjust the dual 5dBi antennas for optimal signal reception. They can be rotated to find the best orientation.

Image: The Maxuni USB WiFi Adapter connected to a laptop, illustrating its broad compatibility with various Windows

| 1300M	2.4G hz	5G hz	(USB icon)	(WiFi icon)	((•))
Dual Band	400Mbps	867Mbps	USB3.0	WIFI Transmition	WIFI Reception

Image: This diagram illustrates the dual functionality of the adapter: receiving WiFi for a desktop PC from a router, and transmitting WiFi from a laptop with the adapter to a mobile phone.

6. OPERATING THE WIFI ADAPTER

Once the adapter is plugged in and drivers are installed, your computer should recognize the device. Follow these steps to connect to a wireless network:

1. **Access Network Settings:** Click on the WiFi icon in your computer's system tray (usually in the bottom-right corner of the screen).
2. **Select Network:** A list of available wireless networks will appear. Select your desired network (SSID).
3. **Connect:** Click 'Connect' and enter the network security key (password) if prompted.
4. **Verify Connection:** Once connected, the WiFi icon will indicate an active internet connection.

Using as a WiFi Transmitter (Soft AP Mode): Some operating systems and driver utilities allow the adapter to function as a wireless access point, sharing your computer's wired internet connection. Refer to your operating system's documentation or the driver utility for specific instructions on enabling this feature.

Dual 5dbi High Gain Antenna Increase Range

Enjoy a strong and stable WIFI connection throughout your home

Maxuni WIFI adapter-
High Gain Antenna

Regular Adapter-
Regular Antenna

Image: This diagram illustrates how the dual 5dBi high-gain antennas of the Maxuni adapter provide a stronger and more stable WiFi connection with increased range throughout a home compared to a standard adapter.

7. MAINTENANCE

- **Keep Clean:** Periodically clean the adapter with a soft, dry cloth. Avoid using liquid cleaners.
- **Avoid Obstructions:** Ensure the antennas are not obstructed by other objects to maintain optimal signal strength.
- **Firm Connection:** Ensure the adapter is firmly seated in the USB port.
- **Software Updates:** Check the official Maxuni website or the driver download link periodically for updated drivers to ensure best performance and compatibility.

8. TROUBLESHOOTING

- **No WiFi Networks Detected:**
  - Ensure the adapter is properly plugged into a USB port.
  - Verify that the drivers are correctly installed. Check Device Manager for any yellow exclamation marks next to the adapter.
  - Try restarting your computer.

- Ensure your router is powered on and broadcasting a WiFi signal.

- **Slow Connection Speed:**
  - Ensure the adapter is plugged into a USB 3.0 port for maximum speed.
  - Adjust the antennas for better signal reception.
  - Move closer to your wireless router or reduce interference from other electronic devices.
  - Ensure your router is configured for dual-band operation and you are connected to the 5GHz band if available and desired for higher speeds.

- **Intermittent Connection:**
  - Check for driver updates.
  - Ensure there are no physical obstructions blocking the signal path between the adapter and the router.
  - Try connecting to a different USB port.

- **Driver Installation Issues:**
  - Temporarily disable antivirus software during driver installation.
  - Download drivers from the provided link if the Mini CD is not working or unavailable.

9. SPECIFICATIONS

Brand	Maxuni
Model	M-18F8
Hardware Interface	USB 3.0
Data Transfer Rate	Up to 1300 Mbps (867 Mbps on 5GHz, 400 Mbps on 2.4GHz)
Frequency Bands	2.4GHz, 5GHz
Antennas	Dual 5dBi High Gain Antennas
Compatible Operating Systems	Windows 11 / 10 / 8.1 / 8 / 7 / Vista / XP
Compatible Devices	Desktop, Laptop
Item Weight	0.05 Kilograms

10. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation included with your purchase or visit the official Maxuni website. If you encounter issues not covered in this manual, please contact Maxuni customer service for assistance.