Philips X3001/00

Philips Shaver Series 3000x - Electric Wet & Dry Shaver (Model X3001/00) User Manual

For a Comfortable, Clean Shave with SkinProtect Technology

1. Introduction

Thank you for choosing the Philips Shaver Series 3000x. This electric shaver is designed to provide a comfortable and smooth shaving experience, whether you prefer wet or dry shaving. Featuring SkinProtect technology and self-sharpening PowerCut blades, it ensures a close shave while protecting your skin. This manual provides essential information for safe and optimal use, setup, operation, and maintenance of your shaver.

Figure 1.1: Philips Shaver Series 3000x, including the shaver unit, USB-A charging cable, and protective cap.

2. Safety Information

Please read all safety warnings carefully before using the appliance to prevent injury or damage.

- Always maintain good contact with the skin during use to minimize the risk of cuts.
- Ensure the shaver is fully charged before use.
- Avoid using the shaver near water or while charging to prevent electric shock or damage to the device.
- This appliance is designed for shaving facial hair only. Do not use it for other purposes.
- Keep the appliance out of reach of children.

3. Setup and Charging

3.1 Initial Charge

Before first use, fully charge your Philips Shaver Series 3000x. A full charge takes approximately 1 hour and provides up to 40 minutes of cordless shaving time. The shaver also features a 5-minute quick charge function, providing enough power for one shave.

- Connect the provided USB-A charging cable to the shaver.
- Plug the USB-A end into a compatible USB power adapter (not included). Ensure the power adapter provides **5V and 1A or higher** output. Using an incompatible adapter may damage the shaver.
- The battery indicator on the shaver will show charging status.

Figure 3.1: The Philips Shaver Series 3000x with its USB-A charging cable. Note that a power adapter is not included.

4. Operating Instructions

4.1 Shaving Your Face

The Philips Shaver Series 3000x is designed for both wet and dry shaving, offering flexibility for your personal preference.

Dry Shaving

- Ensure your face is clean and dry.
- Press the power button to turn on the shaver.
- Move the shaver in small, circular motions over your face, applying gentle pressure. The 4D Flex heads will adapt to your facial contours for an efficient shave.

Wet Shaving

- You can use the shaver with shaving foam, gel, or even in the shower.
- Apply your preferred shaving product to your face.
- Press the power button to turn on the shaver.
- Move the shaver in small, circular motions, applying gentle pressure. Rinse the shaving heads under running water during shaving to prevent clogging.

Figure 4.1: The shaver's 4D Flex heads maintain even contact with the skin, adapting to facial contours for a smooth shave.

Figure 4.2: The shaver is suitable for wet shaving with foam or gel, or for use in the shower.

4.2 Using the Pop-up Trimmer

The integrated pop-up trimmer is ideal for maintaining your mustache and sideburns.

- Slide the trimmer release button upwards to activate the pop-up trimmer.
- Use the trimmer to shape and define your mustache and sideburns.
- After use, push the trimmer back down until it clicks into place.

Figure 4.3: The pop-up trimmer allows for precise grooming of sideburns and mustaches.

5. Maintenance and Cleaning

Regular cleaning and maintenance will ensure optimal performance and extend the lifespan of your shaver.

5.1 Daily Cleaning

- After each shave, turn off the shaver.
- Press the 'One-touch open' button to release the shaving head unit.
- Rinse the shaving heads thoroughly under warm running water to remove hair clippings and residue.
- Shake off excess water and allow the shaving heads to air dry before closing the unit.

5.2 Blade Maintenance

The Philips Shaver Series 3000x features self-sharpening PowerCut blades designed to last up to 2 years. For continued optimal performance, it is recommended to replace the shaving heads every two years. Replacement shaving heads can be purchased from authorized Philips retailers.

Figure 5.1: Close-up view of the self-sharpening PowerCut blades, designed for a smooth and consistent shave.

6. Troubleshooting

If you encounter any issues with your shaver, please refer to the following common solutions:

- **Shaver not turning on:** Ensure the shaver is fully charged. If the battery is completely depleted, it may take a few minutes of charging before the shaver responds.
- **Poor shaving performance:**
  - Ensure the shaver heads are clean and free of hair clippings.
  - Apply gentle pressure and use circular motions.
  - The blades are self-sharpening, but if performance significantly degrades after prolonged use (e.g., 2 years), consider replacing the shaving heads.
- **Charging issues:**
  - Verify that your USB power adapter provides 5V and 1A or higher output.
  - Check the USB cable for any damage.
  - Ensure the charging port on the shaver is clean and free of debris.

- **Skin irritation:**
  - Always shave on clean skin.
  - For sensitive skin, consider wet shaving with foam or gel.
  - Avoid pressing too hard on the skin.

If the problem persists, please contact Philips customer support for further assistance.

7. Specifications

Feature	Specification
Model Number	X3001/00
Brand	Philips
Shaving System	PowerCut Blades, 4D Flex Heads
Shaving Type	Wet & Dry
Special Features	SkinProtect Technology, Pop-up Trimmer, USB-A Charging
Power Source	Rechargeable Battery
Battery Type	NiMH
Battery Life	Up to 40 minutes cordless shaving
Charging Time	1 hour for full charge, 5-minute quick charge
Input Voltage (Charger)	5V (USB-A)
Blade Material	Stainless Steel
Color	Deep Black
Product Dimensions	8 x 10 x 19 cm
Item Weight	337 g
Country of Origin	Indonesia

8. Warranty and Support

8.1 Warranty Information

Your Philips Shaver Series 3000x comes with a standard manufacturer's warranty. It is recommended to register your product on the official Philips website to activate any extended warranty offers, such as a 3-year warranty, if applicable in your region.

8.2 Customer Support

For further assistance, product information, or to purchase replacement parts, please visit the official Philips support website or contact their customer service directly. Contact details can typically be found on the Philips website or in the product packaging.

You can also visit the Philips Store on Amazon for more information and products.