Manuals+
Q & A | Deep Search | Upload

Hamee BT21 minini Cooky

Hamee BT21 minini Cooky Squishy Toy Keychain Instruction Manual

Model: BT21 minini Cooky
Brand: Hamee

1. Introduction

This manual provides essential information for the proper use and care of your Hamee BT21 minini Cooky Squishy Toy Keychain. Please read these instructions carefully to ensure optimal enjoyment and longevity of your product.

2. Safety Information

- **Choking Hazard:** This product contains small parts (keychain attachment) and is not suitable for children under 3 years of age. Adult supervision is recommended.
- **Not Edible:** This squishy toy is not food. Do not attempt to eat or chew the product.
- **Avoid Excessive Force:** While designed for squeezing, excessive stretching or tearing can damage the material.
- **Keep Away from Heat:** Do not expose the product to direct sunlight for prolonged periods or high temperatures, as this may affect its material and color.

3. Usage Instructions (Operating)

The Hamee BT21 minini Cooky Squishy Toy is designed for tactile enjoyment and as a decorative accessory.

1. **Squeezing:** Gently squeeze the squishy toy to experience its slow-rising texture. Release and observe as it slowly returns to its original shape.
2. **Keychain Attachment:** Use the attached metal chain to secure the squishy toy to keys, bags, backpacks, or other personal items. Ensure the attachment is securely fastened to prevent loss.
3. **Decorative Use:** Display the squishy toy on desks, shelves, or other surfaces as a collectible item.

Image: A hand gently squeezing the pink Cooky squishy toy, demonstrating its soft, compressible nature.

Image: The Tata squishy toy, similar to Cooky, attached to a yellow and green checkered bag via its keychain, illustrating its use as an accessory.

4. Care and Maintenance

- **Cleaning:** To clean the surface, gently wipe with a damp cloth and mild soap. Avoid harsh chemicals or abrasive cleaners. Allow to air dry completely.
- **Storage:** Store the squishy toy in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Sharp Objects:** Keep the product away from sharp objects to prevent punctures or tears.

5. Troubleshooting

Issue	Possible Cause	Solution
Toy is not slow-rising	Material may be cold or compressed for too long.	Allow the toy to warm up to room temperature. Gently knead to restore elasticity.

Issue	Possible Cause	Solution
Surface appears dirty	Accumulation of dust or minor stains.	Wipe gently with a damp cloth and mild soap.
Small tear or crack	Excessive force, sharp objects, or prolonged stress on material.	Discontinue use if the tear is significant. Small tears may be repaired with appropriate flexible adhesive, though results may vary.

6. Specifications

Product Dimensions: 6 x 5 x 2 inches

Item Weight: 0.88 ounces

Recommended Age: 3 years and up

Material: Polyurethane foam (typical for squishy toys)

7. Product Overview

The Hamee BT21 minini Cooky Squishy Toy is part of the officially licensed BT21 minini series. It features a soft, slow-rising texture and is designed for stress relief, decorative purposes, or as a keychain accessory.

Image: A close-up front view of the pink Cooky squishy toy, showcasing its facial features and round shape.

Image: A display of several BT21 minini squishy toys, including Cooky, Tata, Chimmy, Mang, Koya, Shooky, and RJ, highlighting the full collection.

Image: Individual Hamee BT21 minini squishy toys, including Cooky, shown in their clear plastic packaging, ready for retail.

8. Official Product Videos

The following videos provide additional visual information about Hamee squishy products. Please note that not all videos may feature the exact Cooky minini model, but demonstrate similar product characteristics.

BT21 Capsule Series 2 (Sushi)

Your browser does not support the video tag.

Video: This video showcases the BT21 Capsule Series 2, featuring various BT21 characters designed as sushi. It demonstrates the unboxing and appearance of these collectible squishy toys.

NEW Hamee x LINE FRIENDS BT21 Jumbo Buddy SquiSHU - MANG

Your browser does not support the video tag.

Video: A demonstration of the Hamee x LINE FRIENDS BT21 Jumbo Buddy SquiSHU featuring the character MANG. The video highlights the slow-rising feature and the toy's texture.

NEW Hamee x LINE FRIENDS BT21 Surprise Blind Capsule - Halloween Series

Your browser does not support the video tag.

Video: This video presents the Hamee x LINE FRIENDS BT21 Surprise Blind Capsule Halloween Series, showing different characters in Halloween costumes and their squishy properties.

9. Warranty and Support

For any questions, concerns, or support regarding your Hamee BT21 minini Cooky Squishy Toy, please contact Hamee customer service through their official channels. Specific warranty details may vary by region and retailer. Please refer to your purchase receipt or the retailer's policy for more information.
You can visit the official Hamee store for more products and information:Hamee Store on Amazon

© 2024 Hamee. All rights reserved. BT21 is a registered trademark.