Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PKPOWER 6ft AC Power Cord Cable

PKPOWER 6ft AC Power Cord Cable User Manual

For Joha JDS-850 Wireless Bluetooth Party Speaker

1. Introduction

This manual provides essential information for the safe and effective use of your PKPOWER 6ft AC Power Cord Cable. This cable is specifically designed to provide power to the Joha JDS-850 Wireless Bluetooth Party Speaker. Please read this manual thoroughly before use to ensure proper setup, operation, and maintenance.

2. Product Overview

The PKPOWER 6ft AC Power Cord Cable is a replacement or spare power cable for compatible devices, including the Joha JDS-850 Wireless Bluetooth Party Speaker. It features a standard two-prong US plug on one end and a figure-8 (C7) connector on the other, ensuring a secure and reliable power connection.

2.1 Key Features

- **Input:** 100-240V 50-60Hz, suitable for global use.
- **Safety Certifications:** CE / FCC / RoHS certified, meeting high safety and quality standards.
- **Protection Features:** Equipped with Over Voltage output Protection (OVP), Over Current output Protection (OCP), and Short Circuit output Protection (SCP) for enhanced safety.
- **Length:** 6 feet (approximately 1.8 meters) for flexible placement.
- **Color:** Black.

2.2 Product Images



Image 1: A black 6ft AC power cord, neatly coiled and secured with a tie, showing both the two-prong US standard plug and the figure-8 (C7) connector.



Image 2: A straight view of the 6ft AC power cord, clearly displaying the two-prong US standard plug on one end and the figure-8 (C7) connector on the other, with the cable extending downwards.



Image 3: A close-up view of both ends of the power cord, highlighting the details of the two-prong US standard plug and the figure-8 (C7) connector.



Image 4: The 6ft AC power cord, partially uncoiled, showing the flexibility and length of the cable, with both ends visible.



Image 5: The 6ft AC power cord, coiled, with a clear view of the two-prong US standard plug and the figure-8 (C7) connector, emphasizing its compact storage.

3. Specifications

Attribute	Value
Product Dimensions	6 x 4 x 2 inches (packaged)
Item Weight	3 ounces
ASIN	B0CJXL5K4S
Date First Available	September 27, 2023
Manufacturer	Shenzhen Sunshine Technological Co., Ltd
Brand	PKPOWER
Connector Type	PC (Figure-8 / C7)
Compatible Devices	Joha JDS-850 Wireless Bluetooth Party Speaker, and other devices requiring a figure-8 AC cord.
Color	Black
Input Voltage	100-240 Volts (AC)

Power Source	Corded Electric

4. Setup Instructions

Setting up your PKPOWER AC Power Cord Cable is a straightforward process. Follow these steps to connect your Joha JDS-850 Wireless Bluetooth Party Speaker to a power source:

1. **Identify the Power Port:** Locate the power input port on your Joha JDS-850 Wireless Bluetooth Party Speaker. This port is typically a figure-8 shaped receptacle.
2. **Connect to Speaker:** Insert the figure-8 (C7) connector end of the PKPOWER cable firmly into the power input port of your speaker. Ensure it is fully seated to establish a secure connection.
3. **Connect to Power Outlet:** Insert the two-prong US standard plug end of the PKPOWER cable into a standard wall power outlet (100-240V AC).
4. **Verify Connection:** Once both ends are connected, your speaker should now be receiving power. Refer to your speaker's manual for instructions on powering it on.

Safety Note: Always ensure the power outlet is easily accessible and that the cable is not pinched or placed under heavy objects. Do not force the connectors into incompatible ports.

5. Operating the Power Cord

The PKPOWER AC Power Cord Cable operates as a passive power conduit. Once properly connected, it facilitates the flow of electricity from the wall outlet to your compatible device. There are no operational controls on the cable itself.

- **Plug and Play:** The cable is designed for immediate use upon connection.
- **Stable Power Delivery:** Provides a stable and consistent power supply to your device within the specified voltage range.
- **Safety Features:** Built-in OVP, OCP, and SCP protections help safeguard your device from electrical irregularities.

Important: Always disconnect the power cord from the wall outlet before disconnecting it from your device, especially if you are performing maintenance or moving the device.

6. Care and Maintenance

Proper care and maintenance will extend the lifespan of your PKPOWER AC Power Cord Cable and ensure safe operation.

- **Cleaning:** Disconnect the cable from all power sources before cleaning. Wipe the cable and connectors with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Storage:** When not in use, coil the cable loosely. Avoid tight coiling or bending the cable sharply, especially near the connectors, as this can damage the internal wires. Store in a cool, dry place away from direct sunlight and extreme temperatures.
- **Inspection:** Periodically inspect the cable for any signs of damage, such as cuts, fraying, exposed wires, or bent/corroded prongs. If any damage is observed, discontinue use immediately and replace the cable.
- **Avoid Overstretching:** Do not pull or stretch the cable excessively. Always grasp the plug or connector when inserting or removing it from an outlet or device.

7. Troubleshooting

If your device is not receiving power when connected with the PKPOWER AC Power Cord Cable, consider the following troubleshooting steps:

Problem	Possible Cause	Solution
Device not powering on.	Cable not fully inserted.	Ensure both ends of the cable are firmly and completely inserted into the device and the wall outlet.
Device not powering on.	Wall outlet is not active.	Test the wall outlet with another known working appliance. Check if a circuit breaker has tripped.
Device not powering on.	Cable is damaged.	Inspect the cable for any visible damage (cuts, fraying, bent prongs). If damaged, replace the cable immediately. Do not use a damaged cable.
Device not powering on.	Device power switch is off or faulty.	Ensure the power switch on your Joha JDS-850 speaker is in the 'On' position. Refer to your speaker's manual for specific power-on procedures.

If the problem persists after following these steps, please contact customer support.

8. Warranty and Support

PKPOWER is committed to providing high-quality products and excellent customer service.

8.1 After-Sale Service

Our friendly and reliable customer service team is available to assist you. We aim to respond to all inquiries within 24 hours.

8.2 How to Contact Us

For any questions, concerns, or support needs regarding your PKPOWER product, you can contact us directly through your purchase platform:

- Locate your order in your account.
- Click on the "Problem with this order?" button.
- Select the "Contact Seller" button to send an e-mail message.

Your patience and support are greatly appreciated as we work to resolve any issues you may encounter.

© 2023 PKPOWER. All rights reserved.
For more information, visit the PKPOWER Store on Amazon.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CJXL5K4S

More documents and user manuals: **https://manuals.plus/**