**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**TRIUMPHKEY 0162**

# TRIUMPHKEY Electric Height Adjustable Standing Desk

Model: 0162

## 1. Introduction

Thank you for choosing the TRIUMPHKEY Electric Height Adjustable Standing Desk. This manual provides essential information for the safe assembly, operation, and maintenance of your new desk. Please read it thoroughly before use and retain it for future reference.

**Safety Warning:**

Ensure the desk is securely assembled according to these instructions. The desk supports a maximum weight of 60 kg (including the desktop). Improper assembly or exceeding the weight limit can lead to stability issues, damage to the product, or personal injury.

## 2. Package Contents

Before assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Desktop sections (Rustic Brown, 160 x 70 cm)
- Electric lifting columns (legs)
- Foot bases
- Control panel with smart memory function
- Monitor stand / Storage shelf
- Headphone hooks
- Cable management grommets
- Assembly hardware (screws, bolts, tools)
- Power adapter and cable
- User Manual (this document)

## 3. Setup & Assembly

Assembly is designed to be straightforward. It is recommended to have two people for assembly, especially when handling the desktop sections. Please follow the numbered steps carefully.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Attach Foot Bases:** Secure the foot bases to the bottom of the lifting columns using the provided screws.

3. **Assemble Frame:** Connect the lifting columns with the crossbar frame. Ensure all connections are tight and secure.
4. **Attach Desktop Sections:** Place the desktop sections onto the assembled frame. Align the pre-drilled holes and secure the desktop to the frame using the appropriate screws.
5. **Install Control Panel:** Mount the intelligent control panel to the underside of the desktop in the designated area.
6. **Connect Cables:** Connect the motor cables from the lifting columns to the control box, and then connect the control panel cable to the control box. Finally, connect the power adapter to the control box and plug it into a power outlet.
7. **Install Monitor Stand:** Attach the monitor stand to the desktop as desired. It can also function as an open storage cube.
8. **Attach Accessories:** Install the headphone hooks and cable management grommets as needed.
9. **Final Check:** Double-check all screws and connections to ensure they are secure before operating the desk.




*Figure 3.1: Assembly overview with components and estimated setup time. A detailed assembly video is also available for visual guidance.*

## 4. Operating Instructions

Your TRIUMPHKEY desk features an intelligent control panel for easy height adjustment and memory functions.




*Figure 4.1: Intelligent Multifunction Control Unit.*

- **Height Adjustment:** Use the **Up (▲)** and **Down (▼)** arrow buttons to raise or lower the desk to your desired height. The current height is displayed on the LED digital display. The desk can be adjusted from 72 cm to 117 cm.
- **Memory Presets:**
    a. Adjust the desk to your preferred sitting height.
    b. Press and hold the **"1"** button until the display flashes or beeps to save this height.

c. Adjust the desk to your preferred standing height.
d. Press and hold the "2" button until the display flashes or beeps to save this height.
e. To recall a saved height, simply press the corresponding memory button ("1" or "2"). The desk will automatically move to the saved position.

- **Child Lock:** The control panel may include a child lock feature. Refer to the specific instructions on the control panel for activation and deactivation.

## 5. Key Features

The TRIUMPHKEY standing desk is designed with several features to enhance your workspace:

- **Adjustable Height Range:** Seamlessly transition between sitting (72 cm) and standing (117 cm) positions to promote better posture and productivity.
- **Smart Memory Panel:** Two programmable height presets allow for quick and convenient adjustments to your preferred working positions.
- **Integrated Monitor Stand:** An ergonomic monitor stand provides an elevated viewing experience and additional storage space. This can also be used as an open storage cube.




*Figure 5.1: Multifunction Monitor Stand.*

- **Robust Construction:** Built with an industrial-grade steel frame, ensuring stability and durability with a static load capacity of 60 kg.





*Figure 5.2: Product Dimensions and Weight Capacity.*

- **Smooth and Quiet Operation:** The electric motor operates at less than 45dB, providing a quiet adjustment experience.




*Figure 5.3: Quiet Operation.*

- **Cable Management:** Features two wire collection holes to keep your cables organized and your workspace tidy.
- **Adjustable Feet:** Four adjustable feet ensure stability on uneven surfaces.
- **Headphone Hooks:** Convenient hooks for hanging headphones or other accessories.




*Figure 5.4: Stable Lifting and Lowering Features.*

- **Anti-Collision Protection:** The desk is equipped with an anti-collision sensor to prevent damage if it encounters an obstacle during adjustment.

## 6. Maintenance

Proper care will extend the life of your TRIUMPHKEY standing desk.

- **Cleaning:** Wipe the desktop and frame with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, which can damage the finish.
- **Regular Checks:** Periodically check all screws and connections to ensure they remain tight.

- **Cable Management:** Ensure cables are neatly managed and not pinched or tangled, which could affect desk operation or cause damage.
- **Weight Distribution:** Distribute weight evenly across the desktop to maintain stability and prevent strain on the lifting mechanism.

## 7. Troubleshooting

If you encounter any issues with your desk, refer to the following common problems and solutions:

| Problem | Possible Cause | Solution |
|---|---|---|
| Desk does not move. | Power cable disconnected; motor cable loose; overload. | Check power connection. Ensure all motor and control panel cables are securely plugged in. Reduce weight on the desk. |
| Desk moves unevenly or makes unusual noise. | Loose screws; uneven weight distribution; obstruction. | Check and tighten all assembly screws. Redistribute weight evenly. Check for any obstructions under or around the desk. |
| Height presets not working. | Memory not saved correctly. | Re-save the memory presets by following the instructions in Section 4. |
| Anti-collision feature triggered frequently. | Obstruction in path. | Ensure there are no obstacles in the desk's path during adjustment. |

If the problem persists after attempting these solutions, please contact TRIUMPHKEY customer support for further assistance.

## 8. Specifications

| Feature | Detail |
|---|---|
| Brand | TRIUMPHKEY |
| Model Number | 0162 |
| Color | Rustic Brown |
| Product Dimensions (L x W x H) | 160 x 70 x 117 cm (max height) |
| Adjustable Height Range | 72 cm to 117 cm |
| Material | Engineered Wood (desktop), Alloy Steel (base) |
| Weight Capacity (Static) | 60 kg |
| Special Features | Storage shelf, Ergonomic, Height adjustable, Electric, Monitor shelves, Anti-collision protection |
| Item Weight | 30.9 Kilograms |
| Country of Origin | China |

## 9. Warranty & Support

TRIUMPHKEY products are manufactured to high-quality standards. For warranty information and customer support, please refer to the documentation included with your purchase or visit the official TRIUMPHKEY website.
For any questions, technical assistance, or to report missing/damaged parts, please contact:
**TRIUMPHKEY Customer Support**
*(Specific contact details such as email or phone number are not provided in the product data. Please refer to your purchase receipt or the manufacturer's website for the most up-to-date contact information.)*

© 2025 TRIUMPHKEY. All rights reserved.
This manual is for informational purposes only. Product specifications are subject to change without notice.

### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

**Open the live page**

**https://manuals.plus/asin/B0CJYFR68N**

More documents and user manuals: **https://manuals.plus/**