Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Walker Edison HANB5BBLC

Walker Edison Modern 6-Drawer Dresser Instruction Manual

Model: HANB5BBLC

Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your Walker Edison Modern 6-Drawer Dresser. Please read all instructions carefully before beginning assembly and retain this manual for future reference. Proper assembly and care will ensure the longevity and stability of your furniture.

Safety Information

WARNING: This product can expose you to chemicals including formaldehyde, which is known to the State of California to cause cancer. For more information, go to www.P65Warnings.ca.gov.

- Always assemble the dresser on a soft, clean surface to prevent scratches.
- Ensure all hardware is securely tightened before use. Periodically check and re-tighten hardware as needed.
- Do not allow children to climb on or play with the dresser.
- For safety, it is recommended to anchor the dresser to a wall using appropriate anti-tip hardware (not always included, but highly recommended for tall furniture).
- Do not overload drawers. Distribute weight evenly.

Package Contents

Before beginning assembly, verify that all parts and hardware are present. Refer to the packing list included with your product. If any components are missing or damaged, contact Walker Edison customer support.

- Dresser panels (top, bottom, sides, back)
- Drawer components (fronts, sides, backs, bottoms)
- Tapered legs
- Hardware pack (screws, dowels, cam locks, drawer slides, etc.)
- Assembly instructions

Assembly Instructions

Before You Begin

- Clear a spacious area for assembly.

- Gather necessary tools: Phillips head screwdriver, hammer (optional, for dowels), and possibly a power drill with appropriate bits (use with caution to avoid overtightening).
- Have a second person assist with assembly, especially for lifting and aligning larger components.

Step-by-Step Assembly

Follow the numbered steps provided in the included assembly guide. The general sequence involves:

1. **Attach Legs:** Secure the tapered legs to the bottom panel of the dresser.
2. **Assemble Frame:** Connect the side panels to the bottom and top panels using the provided hardware.
3. **Install Back Panel:** Fasten the back panel to the assembled frame.
4. **Assemble Drawers:** Construct each of the six drawers by attaching the sides, back, and bottom to the drawer front. Ensure drawer slides are correctly installed on both the drawers and the dresser frame.
5. **Insert Drawers:** Carefully slide the assembled drawers into their respective compartments.
6. **Final Checks:** Ensure all connections are secure and the dresser is stable.



Figure 1: Front view of the assembled Walker Edison Modern 6-Drawer Dresser in black, showcasing its six drawers and tapered legs.




Figure 2: Dimensional diagram illustrating the overall size of the dresser (52 inches wide, 17.75 inches deep, 32.67 inches high) and internal drawer measurements.



Figure 3: Close-up detail of the dresser's black finish, showing a tapered leg and the integrated cut-out handle design on a drawer front.

Operating Instructions

The Walker Edison 6-Drawer Dresser is designed for easy access and storage. To operate the drawers, simply pull the integrated cut-out handles to open and push to close. The drawers are equipped with smooth metal glides for effortless movement. Avoid forcing drawers open or closed if they encounter resistance.

Care and Maintenance

- **Cleaning:** Wipe the dresser surfaces with a dry cloth to remove dust and debris. Avoid using harsh chemicals or abrasive cleaners, which can damage the laminate finish.
- **Spills:** Immediately blot any spills with a clean, dry cloth to prevent staining or damage to the finish.
- **Sunlight:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration over time.
- **Humidity:** Maintain a stable room temperature and humidity level to prevent warping or cracking of the wood composite materials.
- **Hardware:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten as necessary to maintain structural integrity.

Troubleshooting

- **Missing Parts:** If you find any parts or hardware missing upon opening the package, refer to the contact information provided by Walker Edison for assistance. Do not attempt to assemble with incomplete parts.
- **Wobbly Dresser:** Ensure all cam locks and screws are fully tightened. Check that the dresser is placed on a level surface. Adjust leg levelers if applicable.
- **Drawers Not Sliding Smoothly:** Verify that the drawer slides are correctly installed and aligned on both the drawer and the dresser frame. Ensure no debris is obstructing the glides.
- **Drawer Misalignment:** Check that the drawer box is assembled squarely and that the drawer front is attached evenly. Adjust as needed.

Product Specifications

Feature	Detail
Brand	Walker Edison
Model Name	Modern
Product Dimensions	17.75"D x 52"W x 32.67"H
Color	Black Cut-out
Room Type	Bedroom
Furniture Finish	Laminate (over warp-resistant MDF)
Assembly Required	Yes
Item Weight	125 Pounds
Number of Drawers	6

Warranty and Support

This Walker Edison product comes with a Limited Warranty. For specific details regarding warranty coverage, terms, and conditions, please refer to the documentation included with your purchase or visit the official Walker Edison website.
For customer support, missing parts, or technical assistance, please contact Walker Edison directly through their official website or the contact information provided on your purchase receipt. When contacting support, please have your model number (HANB5BBLC) and proof of purchase readily available.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CKDGK9V1

More documents and user manuals: **https://manuals.plus/**