Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Best Choice Products SKY6943

Best Choice Products 15-inch Frosted Ceramic Christmas Tree Instruction Manual

Model: SKY6943

Introduction

This manual provides essential information for the safe and proper use of your Best Choice Products 15-inch Frosted Ceramic Christmas Tree. Please read all instructions carefully before assembly and operation. Retain this manual for future reference.





Image: The Best Choice Products 15-inch Frosted Ceramic Christmas Tree, showcasing its vibrant multicolored lights and clear star topper.

Safety Information

- This product is intended for indoor use only. Do not use outdoors.
- Do not mount or place the product near sources of heat such as fireplaces, candles, or heaters.
- Do not cover the product with cloth, paper, or other flammable materials when in use.
- Ensure wiring is not damaged, cut, or in contact with sharp tools.
- Do not use anything not supplied with this product.
- Do not use the product if the cord or wire insulation is frayed or otherwise damaged.
- Do not use the product if there are cracks in the ceramic, loose connections, or exposed copper wire.
- This product may contain glitter. Assemble only on a protected or disposable surface to prevent unwanted property damage and cleanup.

- To reduce the risk of electric shock, this product has a polarized plug (one blade is wider than the other). This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to use this product if the plug does not fit. Do not alter or replace the plug.
- **Proposition 65 Warning:** This product may contain chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

Package Contents

Verify that all components are present and undamaged before assembly.

- 1x Ceramic Christmas Tree (Frosted with Multicolored Bulbs)
- 1x Power Cord with On/Off Switch (5 ft)
- 2x Star Toppers (one clear, one gold)
- 1x Set of Spare Decorative Bulbs (various colors)
- 1x Assembly Guide



Image: A detailed view of the tree's festive lights and the two included star toppers, one clear and one gold.

Setup

1. **Unpack:** Carefully remove all components from the packaging. Inspect for any damage.
2. **Placement:** Choose a stable, flat surface for the tree, away from heat sources and out of reach of children or pets.
3. **Insert Star Topper:** Gently insert your preferred star topper (clear or gold) into the opening at the top of the ceramic tree. Ensure it is seated firmly.
4. **Connect Power:** Locate the power port at the bottom of the tree. Insert the power cord's connector into this port.
5. **Plug In:** Plug the power adapter into a standard electrical outlet.



Image: The built-in 5-foot power cord with its convenient on/off switch, ready for connection.

▶ **Watch video online**
Small Ceramic Christmas Tree Hand-Painted Vintage Tabletop Green White Christmas Tree Holiday

Video: Demonstration of setting up a similar small ceramic Christmas tree, including placing the star and connecting power.

Operating Instructions

To operate your ceramic Christmas tree:

- Once the tree is plugged into an electrical outlet, locate the on/off switch on the power cord.
- Flip the switch to the "ON" position to illuminate the tree.
- Flip the switch to the "OFF" position to turn off the tree.




Image: The power cord with its integrated on/off switch, illustrating easy operation.

Maintenance

- **Cleaning:** To clean the tree, unplug it from the power source. Wipe the ceramic surface with a soft, dry cloth. Do not use abrasive cleaners or harsh chemicals.
- **Bulb Replacement:** The decorative bulbs are designed to be securely attached. If a bulb needs replacement, gently pull it out and insert a new one from the provided spare set. The main internal bulb can be accessed from the bottom of the tree for replacement.
- **Storage:** When not in use, store the tree in its original packaging in a cool, dry place to protect it from damage.

Troubleshooting

Problem	Possible Cause	Solution
Tree lights do not illuminate.	Power cord not properly connected or plugged in. On/off switch is in the "OFF" position. Internal bulb is faulty.	Ensure the power cord is securely connected to the tree and plugged into a working electrical outlet. Flip the on/off switch to the "ON" position. Access the internal bulb from the bottom of the tree and replace it with a new one.
Star topper does not light up.	Star topper not fully inserted.	Gently push the star topper further into the opening at the top of the tree to ensure proper contact with the internal light source.
Some decorative bulbs are dim or not lit.	Individual decorative bulb is faulty or loose.	Gently remove the faulty bulb and replace it with a spare bulb from the provided set.

Specifications

Feature	Detail
Brand	Best Choice Products
Model Number	SKY6943

Feature	Detail
Product Dimensions	8.5"D x 8.5"W x 15"H
Color	Frosted W/ Multicolored Lights
Material	Ceramic, PS
Item Weight	3 Pounds
Power Cord Length	5 feet
Special Feature	Flocked, Light Up, Prelit
Light Color	Multi
Number of Items	1
UPC	842957134038

Product Dimensions



Image: Visual representation of the product dimensions, indicating a height of 15 inches and a base diameter of 8.5 inches.

Warranty and Support

For warranty information or product support, please refer to the included Assembly Guide or contact Best Choice Products customer service directly. Keep your purchase receipt for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CKNHVZNN

More documents and user manuals: **https://manuals.plus/**