Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Metz MTD8500

Metz MTD8500 32-inch HD LED Google Smart TV User Manual

Model: MTD8500

1. Introduction

Thank you for choosing the Metz MTD8500 32-inch HD LED Google Smart TV. This manual provides essential information for the safe and efficient use of your television. Please read these instructions carefully before operating the device and retain them for future reference.



Front view of the Metz MTD8500 32-inch Smart TV, highlighting its Google TV integration, Wide Color Gamut, Wonder Audio technology, Surging Soundbar, Dolby Audio support, and Flicker Free display.

2. What's in the Box

Carefully unpack your new Metz MTD8500 TV and ensure all items are present. If any items are missing or damaged, please contact your retailer.

- Metz MTD8500 32-inch HD LED Google Smart TV
- Remote Control
- User Manual (this document)

3. Setup

3.1 Physical Setup

Before connecting any cables, ensure the TV is placed on a stable surface or securely mounted to a wall. For optimal viewing, a distance of 1 to 1.5 meters is recommended for this 32-inch TV.



Side view of the Metz MTD8500 Smart TV, illustrating its slim design.



Rear view of the Metz MTD8500 Smart TV, showing the back panel where connections are located.

3.2 Connecting Peripherals

Your TV offers various connectivity options. Refer to the image below for port locations.



Detailed view of the Metz MTD8500 Smart TV's input/output ports, including CI slot, AV IN, RF Input, USB 2.0, HDMI (x3), and LAN/Interface port.

- **HDMI:** Connect external devices such as Blu-ray players, game consoles, or set-top boxes. The TV has 3 HDMI ports.
- **USB:** Insert USB drives for media playback.
- **RF Input:** Connect your antenna or cable for DVB-T/T2, DVB-C, DVB-S/S2, or analog signals.
- **LAN/Ethernet:** For a wired internet connection.
- **AV IN:** For older devices using composite video and stereo audio.
- **CI Slot:** For Conditional Access Modules (CAMs) to decrypt pay-TV channels.

3.3 Initial Power On and Configuration

1. Connect the power cord to the TV and then to a power outlet (100-240V~50/60Hz).
2. Press the power button on the TV or remote control to turn it on.
3. Follow the on-screen instructions to complete the initial setup, including language selection, network connection (Wi-Fi or LAN), and Google TV account setup.

4. Perform a channel scan to find available TV channels.

4. Operating the TV

4.1 Remote Control Overview

The remote control provides access to all TV functions, including navigation, volume, channel selection, and direct access to streaming services.



The remote control for the Metz MTD8500 Smart TV, featuring dedicated buttons for popular streaming services like Netflix, YouTube, and Prime Video, along with Google Play.

4.2 Google TV Features

Your Metz MTD8500 TV runs on the Google TV operating system, offering a personalized experience with access to a vast library of apps and content.



The Google TV interface displaying a selection of integrated applications such as Netflix, YouTube, Google Play, and Prime Video.

- **App Access:** Download and stream content from applications like NETFLIX, YouTube, Google Play, Prime Video, and more.
- **Voice Control:** Use the built-in Google Assistant for voice commands (if supported by remote).
- **Chromecast Built-in:** Cast content from your smartphone or tablet directly to the TV.

4.3 Audio and Video Settings

The TV features LED display technology with a 16:9 aspect ratio and 1366x768 resolution. Innovative HDR technology provides clear and defined images. The integrated soundbar with Wonder Audio technology delivers an immersive audio experience with 2x10W output, an equalizer, and Dolby Digital Plus support.



A graphic illustrating the "Wonder Audio" technology, which features a new software tuning algorithm designed to enhance treble and bass for a more realistic virtual surround sound experience.



A cutaway diagram showing the integrated soundbar components within the Metz MTD8500 TV, illustrating the "Surging Soundbar" feature.

- **Picture Modes:** Adjust brightness, contrast, color, and sharpness.
- **Sound Modes:** Select from various audio presets or customize the equalizer settings.
- **HDR:** High Dynamic Range provides enhanced contrast and color detail.
- **Wide Color Gamut:** Experience a broader spectrum of colors for more vibrant images.



A visual comparison demonstrating the enhanced color reproduction of Wide Color Gamut technology compared to a normal display, showing richer and more vibrant colors.

5. Maintenance

5.1 Cleaning the TV

- Always unplug the TV before cleaning.
- Use a soft, dry cloth to wipe the screen and cabinet.
- For stubborn marks, lightly dampen the cloth with water or a mild, non-abrasive screen cleaner.
- Avoid using alcohol, benzene, thinners, or other volatile substances.

5.2 Software Updates

Your Google TV may receive automatic software updates. Ensure your TV is connected to the internet to receive these updates, which can improve performance and add new features.

6. Troubleshooting

If you encounter issues with your TV, refer to the following common solutions:

- **No Power:** Check the power cord connection and the power outlet. Ensure the TV is switched on.
- **No Picture/Sound:** Verify input source selection. Check cable connections to external devices.
- **Poor Picture Quality:** Adjust picture settings. Check antenna/cable connection. Ensure the source content is high quality.
- **Remote Control Not Working:** Replace batteries. Ensure no obstructions between the remote and the TV's IR sensor.

- **No Internet Connection:** Check Wi-Fi settings or LAN cable connection. Restart your router.

For more complex issues, consult the online support resources or contact Metz customer service.



An illustration representing the Flicker Free technology, which aims to reduce screen flickering for a more comfortable viewing experience.



A diagram illustrating the concept of blue light reduction, showing how the TV minimizes harmful blue light emissions to protect eye health.

7. Specifications

Feature	Specification
Brand	Metz
Model Number	32MTD8500
Screen Size	32 inches (80 cm)
Display Technology	LED
Resolution	1366x768 (720p)

Aspect Ratio	16:9
Refresh Rate	60 Hz
Operating System	Google TV
Audio Output Power	2x10W
Special Audio Features	Integrated Soundbar, Wonder Audio Technology, Dolby Digital Plus
Connectivity	3x HDMI, 1x USB 2.0, Wi-Fi, LAN, Bluetooth, AV IN, RF Input, CI Slot
Tuner	DVB-T/T2, DVB-C, DVB-S/S2, Analog
Video Encoding Support	HEVC
Energy Efficiency Class	E
Power Consumption (SDR)	26W
Power Supply	100-240V~50/60Hz
Product Dimensions (W x D x H)	71.9 x 16.5 x 45.3 cm
Product Weight	4.6 kg
Country of Origin	Italy
First Available	November 3, 2023

8. Warranty and Support

Metz provides a warranty for this product. Standard return and warranty policies apply. For detailed information regarding warranty coverage, returns, or technical support, please refer to the documentation provided with your purchase or contact your retailer. You may also visit the official Metz website for support resources.

© 2023 Metz. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CMCYWL9B

More documents and user manuals: **https://manuals.plus/**